



**YAMAHA**

**2008**

**SERVICE MANUAL**

**XT250X**

**XT250XC**

***XT250***



EAS20050

**XT250X  
XT250XC  
SERVICE MANUAL**  
©2008 by Yamaha Motor Corporation, U.S.A.  
First edition, August 2007  
All rights reserved.  
Any reproduction or unauthorized use  
without the written permission of  
Yamaha Motor Corporation, U.S.A.  
is expressly prohibited.  
Printed in U.S.A.  
P/N LIT-11616-21-52

## NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

### NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

## IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.

### CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

### NOTE:

A NOTE provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title is shown at the top of each page “1”.
- Sub-section titles appear in smaller print than the section title “2”.
- To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section “3”.
- Numbers are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step “4”.
- Symbols indicate parts to be lubricated or replaced “5”.
- Refer to “SYMBOLS”.
- A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc “6”.
- Jobs requiring more information (such as special tools and technical data) are described sequentially “7”.

### CLUTCH

**Removing the clutch**

**Order**    **Job/Parts to remove**    **O'y**    **Remarks**

1	Clutch spring	5	
2	Pressure plate	1	
3	Adjusting screw	1	
4	Push plate	1	
5	Friction plate	6	
6	Clutch plate	5	
7	Clutch damper spring	1	
8	Clutch damper spring seal	1	
9	Primary drive gear nut	1	
10	Lock washer	1	
11	Oil washer	1	
12	Clutch boss nut	1	
13	Lock washer	1	
14	Clutch boss	1	
15	Pin/roll washer	1	
16	Clutch housing	1	
17	Ball	1	
18	Clutch push rod	1	
19	Primary drive gear	1	

For installation, reverse the removal procedure.

5-31

### CLUTCH

**REMOVING THE CLUTCH**

- Straighten the lock washer tab.
- Loosen:
  - Primary drive gear nut "1"

**NOTE:** \_\_\_\_\_  
Insert aluminum plate "a" between primary drive gear "2" and primary driven gear "3", and loosen the primary drive gear nut.

- Loosen:
  - Clutch boss nut "1"

**NOTE:** \_\_\_\_\_  
While holding the clutch boss "1" with the universal clutch holder "2", loosen the clutch boss nut.

**Universal clutch holder**  
90890-04086  
YM-91042

**NOTE:** \_\_\_\_\_  
Measure the friction plate at four places.

Friction plate thickness	2.70-2.90 mm (0.106-0.114 in)
Wear limit	2.60 mm (0.1024 in)

**CHECKING THE CLUTCH PLATES**  
The following procedure applies to all of the clutch plates.

- Check:
  - Clutch plate  
Damage Replace the clutch plates as a set.
- Measure:
  - Clutch plate warpage  
(with a surface plate and thickness gauge "1")  
Out of specification Replace the clutch plates as a set.

Warpage limit	0.20 mm (0.0079 in)
---------------	---------------------

**CHECKING THE CLUTCH SPRINGS**  
The following procedure applies to all of the clutch springs.

- Check:
  - Clutch spring  
Damage Replace the clutch springs as a set.
- Measure:


5-33

## SYMBOLS

The following symbols are used in this manual for easier understanding.

### NOTE:

The following symbols are not relevant to every vehicle.



1. Serviceable with engine mounted
2. Filling fluid
3. Lubricant
4. Special tool
5. Tightening torque
6. Wear limit, clearance
7. Engine speed
8. Electrical data
9. Engine oil
10. Gear oil
11. Molybdenum-disulfide oil
12. Brake fluid
13. Wheel-bearing grease
14. Lithium-soap-based grease
15. Molybdenum-disulfide grease
16. Silicone grease
17. Apply locking agent (LOCTITE®)
18. Replace the part

# TABLE OF CONTENTS

<b>GENERAL INFORMATION</b>	<b>1</b>
<b>SPECIFICATIONS</b>	<b>2</b>
<b>PERIODIC CHECKS AND ADJUSTMENTS</b>	<b>3</b>
<b>CHASSIS</b>	<b>4</b>
<b>ENGINE</b>	<b>5</b>
<b>FUEL SYSTEM</b>	<b>6</b>
<b>ELECTRICAL SYSTEM</b>	<b>7</b>
<b>TROUBLESHOOTING</b>	<b>8</b>





---

## GENERAL INFORMATION

<b>IDENTIFICATION .....</b>	<b>1-1</b>
VEHICLE IDENTIFICATION NUMBER.....	1-1
MODEL LABEL .....	1-1
<b>IMPORTANT INFORMATION .....</b>	<b>1-2</b>
PREPARATION FOR REMOVAL AND DISASSEMBLY .....	1-2
REPLACEMENT PARTS .....	1-2
GASKETS, OIL SEALS AND O-RINGS .....	1-2
LOCK WASHERS/PLATES AND COTTER PINS.....	1-2
BEARINGS AND OIL SEALS.....	1-2
CIRCLIPS.....	1-3
<b>CHECKING THE CONNECTIONS.....</b>	<b>1-4</b>
<b>SPECIAL TOOLS.....</b>	<b>1-5</b>


EAS20130

## IDENTIFICATION

EAS20140

### VEHICLE IDENTIFICATION NUMBER


The vehicle identification number "1" is stamped into the right side of the steering head pipe.



EAS20150

### MODEL LABEL

The model label "1" is affixed to the frame. This information will be needed to order spare parts.




EAS20180

## IMPORTANT INFORMATION


EAS20190

### PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.



2. Use only the proper tools and cleaning equipment. Refer to "SPECIAL TOOLS" on page 1-5.
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.




4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EAS20200

### REPLACEMENT PARTS

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.



EAS20210


### GASKETS, OIL SEALS AND O-RINGS

1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.

EAS20220

### LOCK WASHERS/PLATES AND COTTER PINS


After removal, replace all lock washers/plates "1" and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EAS20230

### BEARINGS AND OIL SEALS


Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals "1", lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.



ECA13300

**CAUTION:**


Do not spin the bearing with compressed air because this will damage the bearing surfaces.



EAS20240

**CIRCLIPS**

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip "1", make sure the sharp-edged corner "2" is positioned opposite the thrust "3" that the circlip receives.



# CHECKING THE CONNECTIONS

EAS20250

## CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:


- Lead
- Coupler
- Connector

2. Check:

- Lead
- Coupler
- Connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.




3. Check:

- All connections
- Loose connection → Connect properly.

**NOTE:**

If the pin "1" on the terminal is flattened, bend it up.



4. Connect:

- Lead
- Coupler
- Connector

**NOTE:**

Make sure all connections are tight.

5. Check:



- Continuity  
(with the pocket tester)



**Pocket tester**  
**90890-03132**

**NOTE:**

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.



EAS20260








## SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country. When placing an order, refer to the list provided below to avoid any mistakes.









**NOTE:**

For U.S.A. and Canada, use part number starting with "YM-", "YU-", or "ACC-".









For others, use part number starting with "90890-".

Tool name/Tool No.	Illustration	Reference pages
Pocket tester 90890-03132		1-4, 3-7, 3-8, 5-52, 7-35, 7-36, 7-37, 7-40, 7-41, 7-42, 7-43, 7-44, 7-45, 7-47
Special thickness gauge 90890-01399		3-5
Tappet adjusting tool 90890-01311 Six piece tappet set YM-A5970	90890-01311 	3-6
	YM-08035-A 	
Digital tachometer 90890-06760 YU-39951-B		3-7, 3-8, 3-11
Timing light 90890-03141 Inductive clamp timing light YU-03141		3-11
Compression gauge 90890-03081 Engine compression tester YU-33223		3-12

# SPECIAL TOOLS








Tool name/Tool No.	Illustration	Reference pages
Steering nut wrench 90890-01403 Spanner wrench YU-33975		3-23
Ring nut wrench 90890-01268 Spanner wrench YU-01268		3-24, 4-49
Spoke wrench 90890-01522		3-27
Cylinder cup installer 90890-01996		4-22, 4-33
Damper rod holder 90890-01460		4-42, 4-44
T-handle 90890-01326 T-handle 3/8" drive 60 cm long YM-01326		4-44
Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7	90890-01367 	4-44, 4-45
	YM-A9409-7/YM-A5142-4 	

# SPECIAL TOOLS








Tool name/Tool No.	Illustration	Reference pages
Fork seal driver attachment (ø35) 90890-01369 Replacement 35 mm YM-A9409-5		4-44
Slide hammer bolt 90890-01083 Slide hammer bolt 6 mm YU-01083-1		5-14
Weight 90890-01084 YU-01083-3	90890-01084 	5-14
	YU-01083-3 	
Valve spring compressor 90890-04019 YM-04019		5-18, 5-23
Valve guide remover (ø6) 90890-04064 Valve guide remover (6.0 mm) YM-04064-A		5-20
Valve guide installer (ø6) 90890-04065 Valve guide installer (6.0 mm) YM-04065-A		5-20
Valve guide reamer (ø6) 90890-04066 Valve guide reamer (6.0 mm) YM-04066		5-20



# SPECIAL TOOLS

Tool name/Tool No.	Illustration	Reference pages
Universal clutch holder 90890-04086 YM-91042	90890-04086 	5-33, 5-35
	YM-91042 	
Sheave holder 90890-01701 Primary clutch holder YS-01880-A		5-47, 5-48
Flywheel puller 90890-01362 Heavy duty puller YU-33270-B		5-47
Yamaha bond No. 1215 (Three Bond No.1215®) 90890-85505		5-56
Crankcase separating tool 90890-01135 Crankcase separator YU-01135-B	90890-01135 	5-59
	YU-01135-B 	

# SPECIAL TOOLS

Tool name/Tool No.	Illustration	Reference pages
Crankshaft installer pot 90890-01274 Installing pot YU-90058	90890-01274 	5-60
	YU-90058/YU-90059 	
Crankshaft installer bolt 90890-01275 Bolt YU-90060	 <p>M14×P1.5</p>	5-60
Adapter (M10) 90890-01383 Adapter #2 YU-90062	 <p>M10×P1.25</p> <p>M14×P1.5</p>	5-60
Spacer 90890-01288	 <p>ø55</p> <p>35</p>	5-60
Ignition checker 90890-06754 Opama pet-4000 spark checker YM-34487		7-43
Digital circuit tester 90890-03174 Model 88 Multimeter with tachometer YU-A1927		7-46

---

## SPECIFICATIONS

GENERAL SPECIFICATIONS .....	2-1
ENGINE SPECIFICATIONS .....	2-2
CHASSIS SPECIFICATIONS.....	2-9
ELECTRICAL SPECIFICATIONS.....	2-11
TIGHTENING TORQUES.....	2-13
GENERAL TIGHTENING TORQUE SPECIFICATIONS.....	2-13
ENGINE TIGHTENING TORQUES.....	2-13
CHASSIS TIGHTENING TORQUES.....	2-15
LUBRICATION POINTS AND LUBRICANT TYPES .....	2-18
ENGINE.....	2-18
CHASSIS.....	2-19
LUBRICATION SYSTEM CHART AND DIAGRAMS .....	2-21
ENGINE OIL LUBRICATION CHART .....	2-21
LUBRICATION DIAGRAMS .....	2-23
CABLE ROUTING.....	2-25

# GENERAL SPECIFICATIONS

---

EAS20280

## GENERAL SPECIFICATIONS

---

### Model

Model	3C58 (U49) 3C59 (CAL)
-------	--------------------------

---

### Dimensions

Overall length	2150 mm (84.6 in)
Overall width	805 mm (31.7 in)
Overall height	1160 mm (45.7 in)
Seat height	810 mm (31.9 in)
Wheelbase	1360 mm (53.5 in)
Ground clearance	285 mm (11.22 in)
Minimum turning radius	1900 mm (74.8 in)

---

### Weight

With oil and fuel	132.0 kg (291 lb)
Maximum load	160.0 kg (353 lb)

# ENGINE SPECIFICATIONS

EAS20290

## ENGINE SPECIFICATIONS

### Engine

Engine type	Air cooled 4-stroke, SOHC
Displacement	249.0 cm <sup>3</sup>
Cylinder arrangement	Forward-inclined single cylinder
Bore × stroke	74.0 × 58.0 mm (2.91 × 2.28 in)
Compression ratio	9.50 :1
Starting system	Electric starter

### Fuel

Recommended fuel	Unleaded gasoline only
Fuel tank capacity	9.1 L (2.40 US gal) (2.00 Imp.gal) (CAL) 9.8 L (2.59 US gal) (2.16 Imp.gal) (U49)
Fuel reserve amount	1.9 L (0.50 US gal) (0.42 Imp.gal)

### Engine oil

Lubrication system	Wet sump
Type	YAMALUBE 4, SAE10W30 or SAE20W40
Recommended engine oil grade	API service SG type or higher, JASO standard MA
Engine oil quantity	
Total amount	1.40 L (1.48 US qt) (1.23 Imp.qt)
Without oil filter element replacement	1.20 L (1.27 US qt) (1.06 Imp.qt)
With oil filter element replacement	1.30 L (1.37 US qt) (1.14 Imp.qt)
Oil filter type	Paper

### Oil pump


Oil pump type	Trochoid
Inner-rotor-to-outer-rotor-tip clearance	0.150 mm (0.0059 in)
Limit	0.200 mm (0.0079 in)
Outer-rotor-to-oil-pump-housing clearance	0.100–0.151 mm (0.0039–0.0059 in)
Limit	0.221 mm (0.0087 in)
Oil-pump-housing-to-inner-and-outer-rotor clearance	0.04–0.09 mm (0.0016–0.0035 in)
Limit	0.16 mm (0.0063 in)
Pressure check location	HEAD CYLINDER

### Spark plug (s)

Manufacturer/model	NGK/DR7EA
Spark plug gap	0.6–0.7 mm (0.024–0.028 in)

### Cylinder head

Volume	20.50–21.50 cm <sup>3</sup> (1.25–1.31 cu.in)
Warpage limit	0.03 mm (0.0012 in)




### Camshaft

Drive system	Chain drive (right)
Camshaft journal diameter	25.021–25.039 mm (0.9851–0.9858 in)

# ENGINE SPECIFICATIONS

## Camshaft lobe dimensions

Intake A	36.520–36.620 mm (1.4378–1.4417 in)
Limit	36.460 mm (1.4354 in)
Intake B	30.201–30.301 mm (1.1890–1.1930 in)
Limit	30.151 mm (1.1870 in)
Exhaust A	36.564–36.664 mm (1.4395–1.4435 in)
Limit	36.514 mm (1.4376 in)
Exhaust B	30.216–30.316 mm (1.1896–1.1935 in)
Limit	30.166 mm (1.1876 in)



Camshaft runout limit	0.030 mm (0.0012 in)
-----------------------	----------------------

## Timing chain


Model/number of links	DID SCR-0404 SV/104
Tensioning system	Automatic

## Rocker arm/rocker arm shaft


Rocker arm inside diameter	12.000–12.018 mm (0.4724–0.4731 in)
Limit	12.036 mm (0.4739 in)
Rocker arm shaft outside diameter	11.981–11.991 mm (0.4717–0.4721 in)
Limit	11.950 mm (0.4705 in)
Rocker-arm-to-rocker-arm-shaft clearance	0.009–0.037 mm (0.0004–0.0015 in)

## Valve, valve seat, valve guide

Valve clearance (cold)	
Intake	0.05–0.10 mm (0.0020–0.0039 in)
Exhaust	0.10–0.15 mm (0.0039–0.0059 in)
Valve dimensions	
Valve head diameter A (intake)	33.90–34.10 mm (1.3346–1.3425 in)
Valve head diameter A (exhaust)	28.40–28.60 mm (1.1181–1.1260 in)




Valve face width B (intake)	2.260 mm (0.0890 in)
Valve face width B (exhaust)	2.260 mm (0.0890 in)




Valve seat width C (intake)	0.90–1.10 mm (0.0354–0.0433 in)
Valve seat width C (exhaust)	0.90–1.10 mm (0.0354–0.0433 in)

# ENGINE SPECIFICATIONS




Valve margin thickness D (intake)  
Valve margin thickness D (exhaust)

0.80–1.20 mm (0.0315–0.0472 in)  
0.80–1.20 mm (0.0315–0.0472 in)



Valve stem diameter (intake)  
Limit  
Valve stem diameter (exhaust)  
Limit  
Valve guide inside diameter (intake)  
Limit  
Valve guide inside diameter (exhaust)  
Limit  
Valve-stem-to-valve-guide clearance (intake)  
Limit  
Valve-stem-to-valve-guide clearance (exhaust)  
Limit  
Valve stem runout

5.975–5.990 mm (0.2352–0.2358 in)  
5.950 mm (0.2343 in)  
5.960–5.975 mm (0.2346–0.2352 in)  
5.935 mm (0.2337 in)  
6.000–6.012 mm (0.2362–0.2367 in)  
6.042 mm (0.2379 in)  
6.000–6.012 mm (0.2362–0.2367 in)  
6.042 mm (0.2379 in)  
0.010–0.037 mm (0.0004–0.0015 in)  
0.080 mm (0.0032 in)  
0.025–0.052 mm (0.0010–0.0020 in)  
0.100 mm (0.0039 in)  
0.030 mm (0.0012 in)



Cylinder head valve seat width (intake)  
Limit  
Cylinder head valve seat width (exhaust)  
Limit

0.90–1.10 mm (0.0354–0.0433 in)  
1.7 mm (0.07 in)  
0.90–1.10 mm (0.0354–0.0433 in)  
1.7 mm (0.07 in)


## Valve spring

### Inner spring


Free length (intake)  
Limit  
Free length (exhaust)  
Limit  
Installed length (intake)  
Installed length (exhaust)  
Spring rate K1 (intake)  
Spring rate K2 (intake)  
Spring rate K1 (exhaust)  
Spring rate K2 (exhaust)  
Installed compression spring force (intake)  
Installed compression spring force (exhaust)  
Spring tilt (intake)  
Spring tilt (exhaust)

36.17 mm (1.42 in)  
34.47 mm (1.36 in)  
36.17 mm (1.42 in)  
34.47 mm (1.36 in)  
30.50 mm (1.20 in)  
30.50 mm (1.20 in)  
14.70 N/mm (83.94 lb/in) (1.50 kgf/mm)  
19.00 N/mm (108.49 lb/in) (1.94 kgf/mm)  
14.70 N/mm (83.94 lb/in) (1.50 kgf/mm)  
19.00 N/mm (108.49 lb/in) (1.94 kgf/mm)  
75.00–91.70 N (16.86–20.61 lbf) (7.65–9.35 kgf)  
75.00–91.70 N (16.86–20.61 lbf) (7.65–9.35 kgf)  
2.5 °/1.6 mm  
2.5 °/1.6 mm

# ENGINE SPECIFICATIONS



Winding direction (intake)	Counter clockwise
Winding direction (exhaust)	Counter clockwise
<b>Outer spring</b>	
Free length (intake)	36.63 mm (1.44 in)
Limit	34.63 mm (1.36 in)
Free length (exhaust)	36.63 mm (1.44 in)
Limit	34.63 mm (1.36 in)
Installed length (intake)	32.00 mm (1.26 in)
Installed length (exhaust)	32.00 mm (1.26 in)
Spring rate K1 (intake)	30.90 N/mm (176.44 lb/in) (3.15 kgf/mm)
Spring rate K2 (intake)	40.80 N/mm (232.97 lb/in) (4.16 kgf/mm)
Spring rate K1 (exhaust)	30.90 N/mm (176.44 lb/in) (3.15 kgf/mm)
Spring rate K2 (exhaust)	40.80 N/mm (232.97 lb/in) (4.16 kgf/mm)
Installed compression spring force (intake)	128.50–157.90 N (28.89–35.50 lbf) (13.10–16.10 kgf)
Installed compression spring force (exhaust)	128.50–157.90 N (28.89–35.50 lbf) (13.10–16.10 kgf)
Spring tilt (intake)	2.5 °/1.6 mm
Spring tilt (exhaust)	2.5 °/1.6 mm



Winding direction (intake)	Clockwise
Winding direction (exhaust)	Clockwise

---

## Cylinder

Bore	74.000–74.016 mm (2.9134–2.9140 in)
Wear limit	74.100 mm (2.9173 in)
Taper limit	0.050 mm (0.0020 in)
Out of round limit	0.010 mm (0.0004 in)
Warp limit	0.10 mm (0.0039 in)


---

## Piston

Piston-to-cylinder clearance	0.010–0.025 mm (0.0004–0.0010 in)
Limit	0.15 mm (0.0059 in)
Diameter D	73.983–73.998 mm (2.9127–2.9133 in)
Height H	11.0 mm (0.43 in)



# ENGINE SPECIFICATIONS



Offset	0.50 mm (0.0197 in)
Offset direction	Intake side
Piston pin bore inside diameter	16.002–16.013 mm (0.6300–0.6304 in)
Limit	16.043 mm (0.6316 in)
Piston pin outside diameter	15.991–16.000 mm (0.6296–0.6299 in)
Limit	15.971 mm (0.6288 in)
Piston-pin-to-piston-pin-bore clearance	0.002–0.022 mm (0.0001–0.0009 in)

## Piston ring


### Top ring

Ring type

Barrel

Dimensions (B × T)

0.90 × 2.75 mm (0.04 × 0.11 in)



End gap (installed)

0.19–0.31 mm (0.0075–0.0122 in)

Limit

0.56 mm (0.0220 in)

Ring side clearance

0.030–0.065 mm (0.0012–0.0026 in)

Limit

0.115 mm (0.0045 in)


### 2nd ring

Ring type

Taper

Dimensions (B × T)

0.80 × 2.80 mm (0.03 × 0.11 in)



End gap (installed)

0.30–0.45 mm (0.0118–0.0177 in)

Limit

0.80 mm (0.0314 in)

Ring side clearance

0.020–0.055 mm (0.0008–0.0022 in)


Limit

0.115 mm (0.0045 in)

### Oil ring

Dimensions (B × T)

1.50 × 2.60 mm (0.06 × 0.10 in)




End gap (installed)

0.10–0.35 mm (0.0039–0.0138 in)

# ENGINE SPECIFICATIONS

## Crankshaft

Width A	69.25–69.30 mm (2.726–2.728 in)
Runout limit C	0.030 mm (0.0012 in)
Big end side clearance D	0.350–0.850 mm (0.0138–0.0335 in)



## Balancer

Balancer drive method	Gear
-----------------------	------

## Clutch

Clutch type	Wet, multiple-disc
Clutch release method	Inner push, cam push
Clutch lever free play	10.0–15.0 mm (0.39–0.59 in)
Friction plate thickness	2.70–2.90 mm (0.106–0.114 in)
Wear limit	2.60 mm (0.1024 in)
Plate quantity	6 pcs
Clutch plate thickness	1.50–1.70 mm (0.059–0.067 in)
Plate quantity	5 pcs
Warping limit	0.20 mm (0.0079 in)
Clutch spring free length	40.10 mm (1.58 in)
Limit	38.10 mm (1.50 in)
Spring quantity	5 pcs
Clutch housing thrust clearance	0.100–0.350 mm (0.0039–0.0138 in)
Clutch housing radial clearance	0.010–0.044 mm (0.0004–0.0017 in)
Push rod bending limit	0.500 mm (0.0197 in)

## Transmission

Transmission type	Constant mesh 5-speed
Primary reduction system	Spur gear
Primary reduction ratio	74/24 (3.083)
Secondary reduction system	Chain drive
Secondary reduction ratio	48/15 (3.200)
Operation	Left foot operation
Gear ratio	
1st	37/13 (2.846)
2nd	29/16 (1.812)
3rd	29/22 (1.318)
4th	29/28 (1.035)
5th	23/28 (0.821)
Main axle runout limit	0.08 mm (0.0032 in)
Drive axle runout limit	0.08 mm (0.0032 in)
Main axle assembly width	102.20–102.40 mm (4.02–4.03 in)

## Shifting mechanism

Shift mechanism type	Shift drum and guide bar
Shift fork thickness	4.76–4.89 mm (0.1874–0.1925 in)

# ENGINE SPECIFICATIONS

---

## Air filter

Air filter element	Oil-coated paper element
--------------------	--------------------------

---

## Carburetor

Type × quantity	MV33 x 1
Manufacturer	TEIKEI
ID mark	3C58 00 (U49) 3C59 00 (CAL)
Main jet	#135
Main air jet	1.20
Jet needle	5A21-1
Needle jet	2.585
Pilot air jet 1	0.90
Pilot outlet	0.8x1.2
Pilot jet	#34
Bypass 1	0.8
Bypass 2	0.8
Bypass 3	0.8
Bypass 4	0.8
Pilot screw turn out	2–1/2
Valve seat size	0.50
Starter jet 1	#90
Starter jet 2	#78
Throttle valve size	33
Float height	11.9 mm (0.47 in)

---

## Idling condition

Engine idling speed	1300–1500 r/min
CO%	0.5–1.5 %
Intake vacuum	29.0–37.0 kPa (8.6–10.9 inHg) (218–278 mm-Hg)
Oil temperature	95.0–105.0 °C (203.00–221.00 °F)
Throttle cable free play	3.0–5.0 mm (0.12–0.20 in)

# CHASSIS SPECIFICATIONS

EAS20300

## CHASSIS SPECIFICATIONS

### Chassis

Frame type	Semi double cradle
Caster angle	26.42 °
Trail	106.0 mm (4.17 in)

### Front wheel

Wheel type	Spoke wheel
Rim size	21x1.60
Rim material	Aluminum
Wheel travel	225.0 mm (8.86 in)
Radial wheel runout limit	2.0 mm (0.08 in)
Lateral wheel runout limit	2.0 mm (0.08 in)
Wheel axle bending limit	0.25 mm (0.01 in)

### Rear wheel

Wheel type	Spoke wheel
Rim size	18M/C x MT2.15
Rim material	Aluminum
Wheel travel	180.0 mm (7.09 in)
Radial wheel runout limit	2.0 mm (0.08 in)
Lateral wheel runout limit	2.0 mm (0.08 in)
Wheel axle bending limit	0.25 mm (0.01 in)

### Front tire

Type	With tube
Size	2.75-21 45P
Manufacturer/model	CHENG SHIN/C-6006
Manufacturer/model	DUNLOP/D605F
Wear limit (front)	0.8 mm (0.03 in)

### Rear tire

Type	With tube
Size	120/80-18M/C 62P
Manufacturer/model	CHENG SHIN/C-6006
Manufacturer/model	DUNLOP/D605
Wear limit (rear)	0.8 mm (0.03 in)

### Tire air pressure (measured on cold tires)

Loading condition	0–90 kg (0–198 lb)
Front	125 kPa (18 psi) (1.25 kgf/cm <sup>2</sup> )
Rear	150 kPa (22 psi) (1.50 kgf/cm <sup>2</sup> )
Loading condition	90 kg–Maximum load
Front	150 kPa (22 psi) (1.50 kgf/cm <sup>2</sup> )
Rear	175 kPa (25 psi) (1.75 kgf/cm <sup>2</sup> )

### Front brake

Type	Single disc brake
Operation	Right hand operation
Front brake lever free play	2.0–5.0 mm (0.08–0.20 in)
Front disc brake	
Disc outside diameter × thickness	245.0 × 3.5 mm (9.65 × 0.14 in)
Brake disc thickness limit	3.0 mm (0.12 in)

## CHASSIS SPECIFICATIONS

---

Brake disc deflection limit	0.15 mm (0.0059 in)
Brake pad lining thickness (inner)	5.3 mm (0.21 in)
Limit	0.8 mm (0.03 in)
Brake pad lining thickness (outer)	5.3 mm (0.21 in)
Limit	0.8 mm (0.03 in)
Master cylinder inside diameter	11.00 mm (0.43 in)
Caliper cylinder inside diameter	26.99 mm (1.06 in)
Caliper cylinder inside diameter	22.22 mm (0.87 in)
Recommended fluid	DOT 4

---

### Rear brake

Type	Single disc brake
Operation	Right foot operation
Brake pedal position	20.0 mm (0.79 in)
Rear disc brake	
Disc outside diameter × thickness	203.0 × 4.5 mm (7.99 × 0.18 in)
Brake disc thickness limit	4.0 mm (0.16 in)
Brake disc deflection limit	0.15 mm (0.0059 in)
Brake pad lining thickness (inner)	5.2 mm (0.20 in)
Limit	1.0 mm (0.04 in)
Brake pad lining thickness (outer)	5.2 mm (0.20 in)
Limit	1.0 mm (0.04 in)
Master cylinder inside diameter	12.7 mm (0.50 in)
Caliper cylinder inside diameter	30.23 mm (1.19 in)
Recommended fluid	DOT 4

---

### Steering

Steering bearing type	Taper roller bearing
Center to lock angle (left)	51.0 °
Center to lock angle (right)	51.0 °

---

### Front suspension

Type	Telescopic fork
Spring/shock absorber type	Coil spring/oil damper
Front fork travel	225.0 mm (8.86 in)
Fork spring free length	482.0 mm (18.98 in)
Limit	472.3 mm (18.59 in)
Installed length	472.2 mm (18.59 in)
Spring rate K1	3.65 N/mm (20.84 lb/in) (0.37 kgf/mm)
Spring stroke K1	0.0–225.0 mm (0.00–8.86 in)
Optional spring available	No
Recommended oil	Yamaha fork oil 15WT
Quantity	385.0 cm <sup>3</sup> (13.02 US oz) (13.58 Imp.oz)
Level	125.0 mm (4.92 in)

---

### Swingarm

Swingarm end free play limit (radial)	1.0 mm (0.04 in)
Swingarm end free play limit (axial)	1.0 mm (0.04 in)

---

### Drive chain

Type/manufacturer	428V/DAIDO
Link quantity	128
Drive chain slack	40.0–45.0 mm (1.57–1.77 in)
15-link length limit	191.5 mm (7.54 in)

# ELECTRICAL SPECIFICATIONS

EAS20310

## ELECTRICAL SPECIFICATIONS

### Voltage

System voltage 12 V

### Ignition system

Ignition system CDI  
Advancer type Digital  
Ignition timing (B.T.D.C.) 10.0 °/1400 r/min

### CDI

Magneto model/manufacturer F5XT/YAMAHA  
Pickup coil resistance 248–372 Ω (Red–white)  
CDI unit model/manufacturer 3C5/YAMAHA

### Ignition coil

Model/manufacturer 2JN/YAMAHA  
Minimum ignition spark gap 6.0 mm (0.24 in)  
Primary coil resistance 0.18–0.28 Ω  
Secondary coil resistance 6.32–9.48 kΩ

### Spark plug cap

Material Resin  
Resistance 10.0 kΩ

### AC magneto

Model/manufacturer F5XT/YAMAHA  
Standard output 14.0 V, 190 W@5000 r/min  
Stator coil resistance 0.688–1.032 Ω (White–white)  
Rectifier/regulator  
Regulator type Semi conductor-short circuit  
Model/manufacturer SH629A-12/SHINDENGEN  
No load regulated voltage 14.1–14.9 V  
Rectifier capacity 10.0 A  
Withstand voltage 200.0 V

### Battery

Model YTZ7S  
Voltage, capacity 12 V, 6.0 Ah  
Specific gravity 1.310  
Manufacturer GS YUASA  
Ten hour rate amperage 0.60 A

### Headlight

Bulb type Halogen bulb

### Bulb voltage, wattage × quantity

Headlight 12 V, 60 W/55.0 W × 1  
Tail/brake light 12 V, 8.0 W/27.0 W × 1  
Front turn signal/position light 12 V, 27 W/5.0 W × 2  
Rear turn signal light 12 V, 27.0 W × 2  
License plate light 12 V, 8.0 W × 1

### Indicator light

Neutral indicator light LED  
Turn signal indicator light LED  
High beam indicator light LED

# ELECTRICAL SPECIFICATIONS

---

## Electric starting system

System type Constant mesh

---

## Starter motor

Model/manufacture 3C5/YAMAHA  
Power output 0.40 kW  
Armature coil resistance 0.0126–0.0154  $\Omega$   
Brush overall length 10.0 mm (0.39 in)  
Limit 3.50 mm (0.14 in)  
Brush spring force 5.52–8.28 N (19.87–29.80 oz) (563–844 gf)  
Commutator diameter 22.0 mm (0.87 in)  
Limit 21.0 mm (0.83 in)  
Mica undercut (depth) 1.50 mm (0.06 in)

---

## Starter relay

Model/manufacture 2768096-A/JIDECO  
Amperage 180.0 A  
Coil resistance 4.18–4.62  $\Omega$

---

## Horn

Horn type Plane  
Quantity 1 pcs  
Model/manufacture HF-12/NIKKO  
Maximum amperage 3.0 A  
Coil resistance 1.01–1.11  $\Omega$   
Performance 108–116 dB/2m

---

## Turn signal relay

Relay type Full transistor  
Model/manufacture FE218BH/DENSO  
Built-in, self-canceling device No  
Turn signal blinking frequency 75–95 cycles/min

---

## Starting circuit cut-off relay

Model/manufacture ACM33211 M04/MATSUSHITA  
Coil resistance 86.4–105.6  $\Omega$   
Carburetor warmer resistance 4.7–9.5 W 20°C (68°F)

---

## Fuses

Main fuse 20.0 A  
Spare fuse 20.0 A

# TIGHTENING TORQUES


EAS20320

## TIGHTENING TORQUES

EAS20330

### GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



- A. Distance between flats
- B. Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m•kg	ft•lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94








EAS20340

### ENGINE TIGHTENING TORQUES




Item	Thread size	Q'ty	Tightening torque	Remarks
Camshaft sprocket cover bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Timing chain tensioner bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Intake manifold bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Air induction system pipe	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Cylinder bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Clutch cover bolt	M6	13	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Oil filter element drain bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Generator rotor cover bolt	M6	9	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Speed sensor bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Crankcase bolt	M6	12	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Drive sprocket cover bolt	M6	3	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Cylinder head bolt (226 mm)	M8	4	22 Nm (2.2 m•kg, 16 ft•lb)	
Cylinder head bolt (45 mm)	M8	2	20 Nm (2.0 m•kg, 15 ft•lb)	
Camshaft retainer bolt	M6	1	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Tappet cover	M55	2	18 Nm (1.8 m•kg, 13 ft•lb)	



## TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Breather plate bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Spark plug	M12	1	18 Nm (1.8 m•kg, 13 ft•lb)	
Exhaust pipe stud bolt	M8	2	15 Nm (1.5 m•kg, 11 ft•lb)	
Oil check bolt	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Generator rotor bolt	M10	1	60 Nm (6.0 m•kg, 43 ft•lb)	
Balancer driven gear nut	M12	1	55 Nm (5.5 m•kg, 40 ft•lb)	lock washer use
Locknut (valve clearance adjusting screw)	M6	2	14 Nm (1.4 m•kg, 10 ft•lb)	
Camshaft sprocket bolt	M10	1	60 Nm (6.0 m•kg, 43 ft•lb)	
Timing chain tensioner cap bolt	M6	1	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Timing chain guide (intake side)	M6	2	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Oil filter element cover bolt	M6	3	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Oil delivery pipe bolt	M10	1	20 Nm (2.0 m•kg, 15 ft•lb)	
Oil delivery pipe bolt	M8	1	17 Nm (1.7 m•kg, 12 ft•lb)	
Oil pump cover screw	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Oil pump assembly bolt	M6	3	6 Nm (0.6 m•kg, 4.3 ft•lb)	
Air filter case bolt	M6	3	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Air cut-off valve bolt	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Exhaust pipe joint bolt	M8	1	20 Nm (2.0 m•kg, 15 ft•lb)	
Exhaust pipe nut	M8	2	18 Nm (1.8 m•kg, 13 ft•lb)	
Muffler bolt	M8	2	42 Nm (4.2 m•kg, 30 ft•lb)	
Stator assembly lead holder bolt	M5	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Engine oil drain bolt	M12	1	20 Nm (2.0 m•kg, 15 ft•lb)	
Clutch cable holder bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Neutral switch lead holder bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Starter clutch idle gear cover bolt	M6	3	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Bearing retainer	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Starter clutch bolt	M8	3	30 Nm (3.0 m•kg, 22 ft•lb)	
Primary drive gear nut	M16	1	80 Nm (8.0 m•kg, 58 ft•lb)	lock washer use

## TIGHTENING TORQUES




Item	Thread size	Q'ty	Tightening torque	Remarks
Clutch boss nut	M16	1	75 Nm (7.5 m•kg, 54 ft•lb)	lock washer use
Clutch spring bolt	M6	5	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Lock nut (Push lever adjusting screw)	M6	1	8 Nm (0.8 m•kg, 5.8 ft•lb)	
Push lever holding bolt	M8	1	12 Nm (1.2 m•kg, 8.7 ft•lb)	
Drive sprocket nut	M18	1	110 Nm (11.0 m•kg, 80 ft•lb)	lock washer use
Stopper lever bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Neutral switch	M10	1	20 Nm (2.0 m•kg, 15 ft•lb)	
Starter motor bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Pickup coil bolt	M6	2	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Stator assembly bolt	M6	3	10 Nm (1.0 m•kg, 7.2 ft•lb)	

EAS20350


### CHASSIS TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Engine mounting nut	M10	3	60 Nm (6.0 m•kg, 43 ft•lb)	
Engine bracket nut	M8	2	44 Nm (4.4 m•kg, 32 ft•lb)	
Down tube nut	M10	5	60 Nm (6.0 m•kg, 43 ft•lb)	
Drive chain tensioner bolt	M8	1	23 Nm (2.3 m•kg, 17 ft•lb)	
Mudguard bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Front fender bolt	M6	4	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Grab bar bolt	M8	4	23 Nm (2.3 m•kg, 17 ft•lb)	
Rear side cover bolt	M6	2	9 Nm (0.9 m•kg, 6.5 ft•lb)	
Tool box bolt	M6	3	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Horn bracket bolt	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Battery/Electrical box bolt	M6	3	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Rectifier/regulator bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Starter motor lead bolt	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Ignition coil bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Pivot shaft nut	M12	1	80 Nm (8.0 m•kg, 58 ft•lb)	
Rear shock absorber assembly upper nut	M12	2	50 Nm (5.0 m•kg, 36 ft•lb)	

## TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Relay arm nut (frame side)	M12	2	50 Nm (5.0 m•kg, 36 ft•lb)	
Steering stem nut	M22	1	110 Nm (11.0 m•kg, 80 ft•lb)	
Lower ring nut	M22	1	–	See NOTE
Fuel tank bolt	M6	3	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Brake hose union bolt	M10	3	30 Nm (3.0 m•kg, 22 ft•lb)	
Brake hose holding bolt	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Front brake hose holding bolt (holder and lower bracket)	M6	1	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Handlebar holder bolt	M8	4	23 Nm (2.3 m•kg, 17 ft•lb)	
Sidestand nut	M10	1	44 Nm (4.0 m•kg, 32 ft•lb)	
Brake pedal bolt	M10	1	30 Nm (3.0 m•kg, 22 ft•lb)	
Rear brake caliper cover	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Rear brake master cylinder bolt	M6	2	13 Nm (1.3 m•kg, 9.4 ft•lb)	
Passenger footrest bracket bolt	M8	4	23 Nm (2.3 m•kg, 17 ft•lb)	
Upper bracket pinch bolt	M8	4	23 Nm (2.3 m•kg, 17 ft•lb)	
Meter stay bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Headlight unit bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Rear shock absorber assembly lower nut	M10	2	40 Nm (4.0 m•kg, 29 ft•lb)	
Connecting arm bolt (relay arm side)	M12	1	59 Nm (5.9 m•kg, 43 ft•lb)	
Connecting arm bolt (swingarm side)	M12	1	59 Nm (5.9 m•kg, 43 ft•lb)	
Rear drive chain guide bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Lower bracket pinch bolt	M8	4	23 Nm (2.3 m•kg, 17 ft•lb)	
Front fork cap bolt	M30	2	23 Nm (2.3 m•kg, 17 ft•lb)	
Damper rod bolt	M8	2	18 Nm (1.8 m•kg, 13 ft•lb)	
Front wheel axle nut	M14	1	85 Nm (8.5 m•kg, 62 ft•lb)	
Front brake disc bolt	M6	6	10 Nm (1.0 m•kg, 7.2 ft•lb)	
Front brake caliper bracket bolt	M10	2	40 Nm (4.0 m•kg, 29 ft•lb)	
Front brake caliper support bolt	M10	2	32 Nm (3.2 m•kg, 23 ft•lb)	
Bleed screw	M7	2	6 Nm (0.6 m•kg, 4.3 ft•lb)	
Rear wheel axle nut	M14	1	85 Nm (8.5 m•kg, 62 ft•lb)	
Rear wheel sprocket self-locking nut	M8	1	33 Nm (3.3 m•kg, 24 ft•lb)	

## TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Rear brake disc bolt	M8	3	28 Nm (2.8 m•kg, 21 ft•lb)	
Front brake master cylinder holder bolt	M6	2	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Front brake lever nut	M6	1	7 Nm (0.7 m•kg, 5.1 ft•lb)	
Rear brake hose joint (caliper side)	M10	1	26 Nm (2.6 m•kg, 19 ft•lb)	
Rear brake hose joint (hose side)	M10	1	14 Nm (1.4 m•kg, 10 ft•lb)	
Rear brake pad support bolt	M10	2	17 Nm (1.7 m•kg, 12 ft•lb)	

**NOTE:**

- Tighten the lower ring nut with the specified torque (38 Nm (3.8 m•kg, 28 ft•lb)).
- Check the front fork leg operates smoothly by turning it to the right and left.
- Loosen the lower ring nut completely and retighten it with the specified torque (4 Nm (0.4 m•kg, 2.9 ft•lb)).


























# LUBRICATION POINTS AND LUBRICANT TYPES

EAS20360








## LUBRICATION POINTS AND LUBRICANT TYPES

EAS20370

### ENGINE















Lubrication point	Lubricant
Oil seal lips	
All O-rings	
All bearing retainers	
Seat surface of cylinder head bolt (226 mm)	
Threaded portion of cylinder head bolt (226 mm)	
Cylinder inner surface	
Crankshaft pin surface	
Thrust end surface of connecting rod big end	
Piston pin surface	
Piston surface	
Buffer boss surface	
Valve stem (intake/exhaust)	
Valve stem end (intake/exhaust)	
Rocker arm shaft surface (intake/exhaust)	
Camshaft profile	
Rocker arm inner surface (intake/exhaust)	
Inside of oil pump assembly	
Oil pump gasket	
Starter clutch idle gear 1	
Starter clutch idle gear 2	
Starter clutch gear	
Clutch push rod surface, and surface end	
Adjusting screw surface, and surface end (push lever)	
Primary driven gear (clutch housing)	
Push lever shaft surface	

# LUBRICATION POINTS AND LUBRICANT TYPES

















Lubrication point	Lubricant
Ball surface (clutch push rod)	
Main axle assembly	
Drive axle assembly	
Shift fork guide bar	
Shift drum assembly	
Shift shaft assembly	
Shift pedal (bolt mount inner surface)	
Crankcase mating surface	Yamaha bond No. 1215 (Three Bond No. 1215®)
Threaded portion of starter motor bolt	Yamaha bond No. 1215 (Three Bond No. 1215®)

EAS20380

## CHASSIS

Lubrication point	Lubricant
Upper bearings and oil seal lip (steering head)	
Lower bearings and oil seal lip (steering head)	
Front wheel oil seal lip (left/right)	
Rear wheel oil seal lip (left/right)	
Brake pedal bolt shaft	
Throttle grip and throttle cable end	
Throttle cable housing inner surface	
Brake lever bolt shaft	
Brake lever and front brake master cylinder moving parts	
Adjusting screw end (brake lever)	
Rear brake master cylinder pushrod (boot mount groove)	
Brake caliper piston seal	
Brake caliper support bolt shaft	
Brake pad support bolt shaft	

## LUBRICATION POINTS AND LUBRICANT TYPES

Lubrication point	Lubricant
Clutch lever cable mount	
Clutch lever bolt shaft	
Clutch lever moving parts	
Pivot shaft surface	
Swing arm bushing, spacer, and oil seal lip	
Relay arm bushing, spacer, and oil seal lip	
Relay arm bolt shaft (on the frame and connecting arm)	
Relay arm bolt shaft	
Connecting arm bolt shaft	
Lower bolt shaft of rear shock absorber assembly	
Rear wheel axle surface	
Sidestand switch end and contact	
Frame and sidestand link moving parts	
Sidestand bolt collar surface	
Drive chain roller collar surface	
Tandem footrest moving parts	



# LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20390

## LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20400

## ENGINE OIL LUBRICATION CHART





# LUBRICATION SYSTEM CHART AND DIAGRAMS


---

1. Camshaft
2. Oil filter element
3. Oil level check window
4. Oil pump assembly
5. Oil strainer
6. Drive axle
7. Main axle
8. Plunger pin
9. Crankshaft
10. Cylinder head
11. Oil pan

# LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20410

## LUBRICATION DIAGRAMS



# LUBRICATION SYSTEM CHART AND DIAGRAMS


---

1. Crankshaft
2. Oil pump assembly
3. Oil strainer
4. Camshaft
5. Push lever shaft
6. Drive axle
7. Main axle
8. Oil filter element

# CABLE ROUTING


EAS20430

## CABLE ROUTING



1. Headlight relay (lead having gray tape)
  2. Starting circuit cut-off relay
  3. Carburetor warmer lead
  4. Throttle pulley
  5. Throttle cable (decelerator cable )
  6. Throttle cable (accelerator cable)
  7. Horn lead
  8. Starter motor lead
  9. Diode1
  10. Negative battery lead
  11. Diode3
  12. Rear brake light switch
  13. Rear brake light switch lead
  14. Starter relay lead
  15. Turn signal relay
  16. Wire harness
  17. Rear turn signal light leads (left/right)
  18. Positive battery lead
  19. Clutch cable
  20. Toolbox
  21. Clamp
  22. Battery box
- A. 35 mm (1.38 in)
  - B. Clamp the wire harness using plastic locking tie. Face the cable tie end upwards, and cut off the excess end of the tie. When clamping, locate the connection of relay leads below the seat rails, but at the side of the fuel tank bracket (rear fuel tank bolt mount).
  - C. 30 mm (1.18 in)
  - D. Route the starter motor cable outside each lead.
  - E. Clamp the wire harness using a plastic locking tie. Face the plastic locking tie end upwards, and cut off the excess end of the tie.
  - F. 30 mm (1.18 in)
  - G. Clamp the wire harness, clutch cable, and carburetor warmer lead using plastic locking tie. Enter the cable tie in the frame opening. Face the cable tie end upwards, and cut off the excess end of the tie.
  - H. Secure the right handlebar switch lead, front brake light switch lead, right front turn signal light lead, and meter assembly leads using clamp. Face the clamp opening downwards.
  - I. Route the throttle cable inside of each lead.
  - J. Route each lead without slack.
  - K. Route the leads from the cutout of front right sidecover to inside of the sidecover.
  - L. Pass the throttle cable through the guide.
  - M. Each lead should not be exposed to the outside of the right front sidecover.
  - N. Pass the horn lead inside of the throttle cable and secure it to the T-stud of the frame.
  - O. Route the throttle cable above the cylinder head breather hose.
  - P. Clamp the clutch cable, starter motor lead, and carburetor warmer lead using plastic locking tie. Face the cable tie end outwards and cut off the excess end of the tie. Take care not to make the latchet face inwards towards the vehicle.
  - Q. Install diode 1 in the battery/electric parts box.
  - R. Pass the negative battery lead behind the wire harness. Also, pass the battery lead from the battery/electric parts box through the inside of the vehicle.
  - S. Gray tape (headlight relay lead)
  - T. Install diode 3 in front of the headlight relay.
  - U. Clamp the rear brake light switch lead using clamps. Face the clamp opening inwards .
  - V. Pass the rear brake light switch lead along the frame, and install the rear brake light switch.
  - W. Secure the rear brake light switch lead to the frame using clamps.
  - X. Clamp the wire harness, tail/brake light leads, rear turn signal light leads (left and right), and rear brake light switch lead using plastic locking tie. Face the end of the locking tie upward and cut off the excess end of the tie.
  - Y. Route leads between the frames and inside of the vehicle as shown in the illustration.
  - Z. Pass a plastic locking tie through the front side hole of the frame bracket and then clamp the rear turn signal light leads (left and right) and tail/brake light leads. Face the end of the locking tie upward and cut off the excess end of the locking tie.
  - AA. Route the rear turn signal light leads (left and right), tail/brake light leads, and rear brake light switch lead under the battery band.
  - AB. Route the negative battery lead outside other leads.
  - AC. Do not route the rear turn signal light leads (left and right) above the top panel of the battery/ electric parts box.
  - AD. Clamp the starter relay lead, headlight relay lead, starting circuit cut-off relay lead, diode1 lead, and diode3 lead using plastic locking tie. Insert the latchet and the excess tail of the cable tie into the inside.
  - AE. Pass the rear brake light switch lead between the battery/electric parts box and the positive battery lead.
  - AF. Less than 2 mm (0.08 in)
  - AG. Route the carburetor warmer lead outside the clutch cable and starter motor lead.
  - AH. Route the carburetor warmer lead outside the wire harness.
  - AI. Pass the left handlebar switch lead, clutch switch lead, main switch lead, and front left turn signal light lead through the boot. Push and hold the boot onto the coupler end.
  - AJ. Pass the horn lead, meter assembly lead, right handlebar switch lead, front brake light switch lead, and front right turn signal light lead through the boot. Push and hold the boot onto the coupler end.
  - AK. The boot should be located under the toolbox end.
  - AL. Clamp the rear brake switch lead, taillight lead and two negative battery leads using plastic locking tie. The cable tie end should face downward. Do not clamp the couplers.
  - AM. Pass a plastic locking tie through the hole of frame gasket and then clamp the rear turn signal light leads and tail light lead. Face the end of the locking tie upward and cut off the excess end of the locking tie.
  - AN. The relay with the diode is front side and the relay with gray tape is rear side.


# CABLE ROUTING



# CABLE ROUTING

1. Clutch cable
  2. Starter cable
  3. Air induction system hose (from air filter case to air cut-off valve)
  4. Cylinder head breather hose
  5. Sidestand switch lead
  6. Speed sensor lead
  7. Neutral switch lead
  8. Stator assembly lead
  9. Main switch lead
  10. Meter assembly leads
  11. Front brake hose
  12. Throttle cable (decelerator cable)
  13. Throttle cable (accelerator cable)
  14. Right handlebar switch lead
  15. Front brake light switch lead
  16. Left handlebar switch lead
  17. Clutch switch lead
  18. Negative battery lead
  19. Speed sensor
  20. Rear turn signal light
  21. Carburetor fuel drain hose
  22. Rear turn signal light bracket
- A. Each lead should not be exposed to the outside of the front left sidecover.
  - B. Secure the left handlebar switch lead, clutch switch lead, front left turn signal light lead, and main switch lead using clamp. Face the clamp opening downwards.
  - C. Pass the clutch cable through the guide.
  - D. Enter each lead from the cutout of front left sidecover and run inside of the sidecover. Install each lead above the clutch cable without slack.
  - E. Clamp the starter cable using plastic locking tie and cut off the excess end of the tie. Face the end of the tie downwards.
  - F. Pass the starter cable through the square shape of air cut-off valve bracket, and route outside the air induction system hose (from air filter case to air cut-off valve) and cylinder head breather hose.
  - G. Secure the ignition coil lead, stator assembly lead, sidestand switch lead, neutral switch lead, and speed sensor lead using clamp. Face the clamp opening upward.
  - H. Secure the sidestand switch lead to the frame using clamps.
  - I. Secure the neutral switch lead and speed sensor lead using clamp. Face the clamp opening backward.
  - J. Secure the stator assembly lead using clamps. The clamp opening should face downwards away from the vehicle.
  - K. Secure the wire harness boot onto the guide.
  - L. Route the clutch cable above the cylinder head breather hose.
  - M. Route the clutch cable at the rear of the guide.
  - N. Pass the ignition coil lead, stator assembly lead, sidestand switch lead, neutral switch lead, and speed sensor lead through the boot. Insert all couplers into the boot.
  - O. Secure two carburetor air vent hoses, carburetor fuel drain hose, and negative battery lead using clamp. Face the clamp holders on the left of the vehicle.
  - P. Pass the speed sensor lead between each hose and the crankcase.
  - Q. Secure two carburetor air vent hoses, carburetor fuel drain hose, and neutral switch lead using clamp.
  - R. Secure the neutral switch lead using clamp.
  - S. Pass the rear turn signal light leads (left and right) through the opening of rear turn signal light bracket, and secure the leads using plastic locking tie. Face the cable tie end inward, and cut off the excess end of the tie.
  - T. Route the carburetor fuel drain hose through the guide.
  - U. Route the carburetor fuel drain hose through the rear of frame cross tube as shown in the illustration. (Except for California)
  - V. Using plastic locking tie, secure the neutral switch lead and speed sensor lead onto the clamp as shown in the illustration.



# CABLE ROUTING






1. Clutch cable
  2. Front brake hose
  3. Front brake light switch lead
  4. Right handlebar switch lead
  5. Throttle cable (decelerator cable)
  6. Throttle cable (accelerator cable)
  7. Carburetor warmer lead
  8. Starter motor lead
  9. Rear brake light switch lead
  10. Negative battery lead
  11. Tail/brake light lead/
  12. Rear turn signal light leads
  13. Thermo switch
  14. Rectifier/regulator lead
  15. Clutch switch lead
  16. Left handlebar switch lead
  17. Rectifier/regulator
- A. Enter two wire harnesses from the opening of frame cross tube, pass them through the inside of the vehicle, and secure them using plastic locking tie. Face the cable tie end backwards away from the frame cross tube, and cut off the excess end of the tie.
  - B. Less than 2 mm (0.08 in)
  - C. Clamp rear turn signal light leads (left and right) and tail/brake light leads using plastic locking tie. Face the cable tie end outwards and cut off the excess end of the tie.
  - D. Install each lead under the frame without slack.
  - E. Secure the rear turn signal light leads (left and right) and tail/brake light leads with clamp. Face the clamp opening upwards.
  - F. Secure the rear left turn signal light lead to the end of rear fender bracket (soldered to the frame) using plastic locking ties. Face the cable tie end backward, and cut off the excess end of the tie if longer than 3 mm (0.12 in).
  - G. Install the left rear turn signal light lead under the frame without slack.
  - H. Secure the thermo switch lead, rectifier/regulator lead, and rectifier/regulator ground lead using clamps.
  - I. Secure the wire harness to the T-stud of the frame.
  - J. Clamp the clutch cable, throttle cable (accelerator cable), and throttle cable (decelerator cable) using plastic locking tie. Face the tied end inward, and cut off the excess end of the tie.
  - K. Route the clutch cable between the throttle cable (accelerator cable) and the throttle cable (decelerator cable).
  - L. Install the rectifier/regulator lead in horizontal to the vehicle.
  - M. Clamp the plastic locking tie onto the bends of handle as shown in the illustration.
  - N. Face the plastic locking tie end downwards.

# CABLE ROUTING



1. Throttle cable (accelerator cable)
  2. Throttle cable (decelerator cable)
  3. Meter assembly leads
  4. Clutch cable
  5. Left front turn signal light lead
  6. Main switch lead
  7. Right front turn signal light lead
  8. Front brake hose
- 
- A. Route the meter assembly leads, and main switch leads from the top of the guide to the backward of vehicle.
  - B. To the meter assembly.
  - C. Install the left front turn signal light lead to the cap.
  - D. Route the clutch cable and front left turn signal light lead at the rear of the guide. However, route the main switch leads at the front of the guide.
  - E. Install the 3-pin coupler for the meter assembly and left handlebar switch as shown in the illustration.
  - F. To the headlight.
  - G. Band the meter assembly leads, handlebar switch leads (left and right), front brake light switch lead, front turn signal light leads (left and right), clutch switch lead, and main switch leads with plastic locking tie. The plastic locking tie should position bottom end of the main switch, and face tail forward.
  - H. Bottom end of the main switch
  - I. Install the front right turn signal light lead to the cap.
  - J. Never clamp the throttle cable (accelerator cable) and the throttle cable (decelerator cable) using plastic locking tie.
  - K. Position the 3-pin coupler for the meter assembly and left handlebar switch at the front of vehicle.
  - L. Forward of the vehicle.
  - M. Face the latchet side of the band outward.

# CABLE ROUTING



1. Fuel tank
  2. Roll over valve
  3. Canister
  4. Canister breather hose
- 
- A. Face the end of clip toward the vehicle.
  - B. Install the hose to fuel tank by facing the white paint mark left side of the vehicle.
  - C. Pass through the hose in the space of the tool box.
  - D. Install the hose to the roll over valve and canister.
  - E. Install the hose to the carburetor and canister.
  - F. Pass through the hose to the guide.
  - G. The clip may be installed, which ever direction end of the clip.
  - H. Pass through the canister breather hose to the guide.
  - I. Install the end of the canister breather hose to inside of the frame by facing the cut end of the hose downward.
  - J. Install the hose to the carburetor by facing the white paint mark left side of the vehicle.
  - K. Pass through the hose onto the guide.
  - L. Face the end of clip right side of the vehicle.
  - M. Face the end of clip downward of the vehicle.
  - N. Fasten the hose and cylinder head breather hose by using the clamp.



---

# PERIODIC CHECKS AND ADJUSTMENTS

<b>PERIODIC MAINTENANCE</b> .....	<b>3-1</b>
INTRODUCTION.....	3-1
Periodic maintenance chart for the emission control system .....	3-1
General maintenance and lubrication chart.....	3-2
<b>ENGINE</b> .....	<b>3-5</b>
ADJUSTING THE VALVE CLEARANCE .....	3-5
ADJUSTING THE ENGINE IDLING SPEED .....	3-6
ADJUSTING THE THROTTLE CABLE FREE PLAY .....	3-7
CHECKING THE SPARK PLUG .....	3-8
CHECKING THE IGNITION TIMING.....	3-8
MEASURING THE COMPRESSION PRESSURE.....	3-9
CHECKING THE ENGINE OIL LEVEL .....	3-10
CHANGING THE ENGINE OIL .....	3-11
ADJUSTING THE CLUTCH CABLE FREE PLAY.....	3-12
REPLACING THE AIR FILTER ELEMENT .....	3-13
CHECKING THE CARBURETOR JOINT AND INTAKE MANIFOLD .....	3-14
CHECKING THE FUEL LINE .....	3-14
CHECKING THE CYLINDER HEAD BREATHER HOSE .....	3-14
CHECKING THE EXHAUST SYSTEM .....	3-14
<b>CHASSIS</b> .....	<b>3-16</b>
ADJUSTING THE FRONT DISC BRAKE.....	3-16
ADJUSTING THE REAR DISC BRAKE .....	3-16
CHECKING THE BRAKE FLUID LEVEL .....	3-17
CHECKING THE FRONT BRAKE PADS.....	3-17
CHECKING THE REAR BRAKE PADS .....	3-18
CHECKING THE FRONT BRAKE HOSE .....	3-18
CHECKING THE REAR BRAKE HOSE.....	3-18
ADJUSTING THE REAR BRAKE LIGHT SWITCH.....	3-18
BLEEDING THE HYDRAULIC BRAKE SYSTEM .....	3-19
ADJUSTING THE DRIVE CHAIN SLACK.....	3-20
LUBRICATING THE DRIVE CHAIN.....	3-20
CHECKING AND ADJUSTING THE STEERING HEAD.....	3-21
CHECKING THE FRONT FORK.....	3-22
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY.....	3-22
CHECKING THE TIRES.....	3-23
CHECKING THE WHEELS .....	3-24
CHECKING AND TIGHTENING THE SPOKES.....	3-25
CHECKING AND LUBRICATING THE CABLES .....	3-25
LUBRICATING THE LEVERS.....	3-25
LUBRICATING THE PEDAL .....	3-25
LUBRICATING THE SIDESTAND .....	3-25
LUBRICATING THE REAR SUSPENSION .....	3-25
<b>ELECTRICAL SYSTEM</b> .....	<b>3-26</b>
CHECKING AND CHARGING THE BATTERY.....	3-26
CHECKING THE FUSES .....	3-26
REPLACING THE HEADLIGHT BULB .....	3-26
ADJUSTING THE HEADLIGHT BEAM .....	3-26

# PERIODIC MAINTENANCE

EAS20450

## PERIODIC MAINTENANCE

EAS20460

### INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

#### NOTE:

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EWA10340



**Modifications not approved by Yamaha may cause loss of performance, excessive emissions, and render the vehicle unsafe for use. Consult a Yamaha dealer before attempting any changes.**

EAS17580

### Periodic maintenance chart for the emission control system

No	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (6000 km) or 6 months	7000 mi (11000 km) or 12 months	10000 mi (16000 km) or 18 months	13000 mi (21000 km) or 24 months	16000 mi (26000 km) or 30 months	
1 *	Fuel hose	<ul style="list-style-type: none"> <li>● Check fuel hoses for cracks or damage.</li> <li>● Replace if necessary.</li> </ul>		√	√	√	√	√	√
2	Spark plug	<ul style="list-style-type: none"> <li>● Check condition.</li> <li>● Adjust gap and clean.</li> <li>● Replace at 7000 mi (11000 km) or 12 months and thereafter every 6000 mi (10000 km) or 12 months.</li> </ul>		√	Replace.	√	Replace.	√	√
3	Spark arrester	<ul style="list-style-type: none"> <li>● Clean.</li> </ul>		√	√	√	√	√	√
4 *	Valve clearance	<ul style="list-style-type: none"> <li>● Check and adjust valve clearance when engine is cold.</li> </ul>	√	√	√	√	√	√	√
5 *	Crankcase breather system	<ul style="list-style-type: none"> <li>● Check breather hose for cracks or damage.</li> <li>● Replace if necessary.</li> </ul>		√	√	√	√	√	√
6 *	Idle speed	<ul style="list-style-type: none"> <li>● Check and adjust engine idle speed.</li> </ul>		√	√	√	√	√	√
7 *	Exhaust system	<ul style="list-style-type: none"> <li>● Check for leakage.</li> <li>● Tighten if necessary.</li> <li>● Replace gasket(s) if necessary.</li> </ul>		√	√	√	√	√	√
8 *	Evaporative emission control system (For California only)	<ul style="list-style-type: none"> <li>● Check control system for damage.</li> <li>● Replace if necessary.</li> </ul>			√		√		



# PERIODIC MAINTENANCE

No	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (6000 km) or 6 months	7000 mi (11000 km) or 12 months	10000 mi (16000 km) or 18 months	13000 mi (21000 km) or 24 months	16000 mi (26000 km) or 30 months	
9 *	<b>Air induction system</b>	<ul style="list-style-type: none"> <li>● Check the air cut-off valve, reed valve, and hose for damage.</li> <li>● Replace any damaged parts.</li> </ul>			√			√	

\* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

EAS32164

## General maintenance and lubrication chart

No	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (6000 km) or 6 months	7000 mi (11000 km) or 12 months	10000 mi (16000 km) or 18 months	13000 mi (21000 km) or 24 months	16000 mi (26000 km) or 30 months	
1 *	<b>Air filter element</b>	<ul style="list-style-type: none"> <li>● Check condition and for damage.</li> <li>● Replace if necessary.</li> </ul>		√	√	√		Replace.	√
		<ul style="list-style-type: none"> <li>● Replace.</li> </ul>	Replace at 13000 mi (21000 km) and there after every 12000 mi (20000 km).						
2 *	<b>Clutch</b>	<ul style="list-style-type: none"> <li>● Check operation.</li> <li>● Adjust or replace cable.</li> </ul>	√	√	√	√	√	√	√
3 *	<b>Front brake</b>	<ul style="list-style-type: none"> <li>● Check operation, fluid level, and for fluid leakage.</li> <li>● Replace brake pads if necessary.</li> </ul>	√	√	√	√	√	√	√
4 *	<b>Rear brake</b>	<ul style="list-style-type: none"> <li>● Check operation, fluid level, and for fluid leakage.</li> <li>● Replace brake pads if necessary.</li> </ul>	√	√	√	√	√	√	√
5 *	<b>Brake hose</b>	<ul style="list-style-type: none"> <li>● Check for cracks or damage.</li> </ul>		√	√	√	√	√	√
		<ul style="list-style-type: none"> <li>● Replace.</li> </ul>	Every 4 years						
6 *	<b>Wheels</b>	<ul style="list-style-type: none"> <li>● Check runout, spoke tightness and for damage.</li> <li>● Tighten spokes if necessary.</li> </ul>		√	√	√	√	√	√
7 *	<b>Tires</b>	<ul style="list-style-type: none"> <li>● Check tread depth and for damage.</li> <li>● Replace if necessary.</li> <li>● Check air pressure.</li> <li>● Correct if necessary.</li> </ul>		√	√	√	√	√	√
8 *	<b>Wheel bearings</b>	<ul style="list-style-type: none"> <li>● Check bearings for smooth operation.</li> <li>● Replace if necessary.</li> </ul>		√	√	√	√	√	√
9 *	<b>Swingarm pivot bushes</b>	<ul style="list-style-type: none"> <li>● Check bush assemblies for looseness.</li> <li>● Lubricate with lithium-soap-based grease.</li> </ul>		√	√	√	√	√	√

# PERIODIC MAINTENANCE

No	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (6000 km) or 6 months	7000 mi (11000 km) or 12 months	10000 mi (16000 km) or 18 months	13000 mi (21000 km) or 24 months	16000 mi (26000 km) or 30 months	
10	Drive chain	<ul style="list-style-type: none"> <li>● Check chain slack, alignment and condition.</li> <li>● Adjust and lubricate chain with a special O-ring chain lubricant thoroughly.</li> </ul>	Every 300 mi (500 km) and after washing the motorcycle or riding in the rain						
11	* Steering bearings	<ul style="list-style-type: none"> <li>● Check bearing assemblies for looseness.</li> <li>● Moderately repack with lithium-soap-based grease.</li> </ul>	√	√	√	√	Repack.	√	
12	* Chassis fasteners	<ul style="list-style-type: none"> <li>● Check all chassis fitting and fasteners.</li> <li>● Correct if necessary.</li> </ul>		√	√	√	√	√	
13	Brake lever pivot shaft	<ul style="list-style-type: none"> <li>● Apply silicone grease lightly.</li> </ul>		√	√	√	√	√	
14	Brake pedal pivot shaft	<ul style="list-style-type: none"> <li>● Apply lithium-soap-based grease lightly.</li> </ul>		√	√	√	√	√	
15	Clutch lever pivot shaft	<ul style="list-style-type: none"> <li>● Apply lithium-soap-based grease lightly.</li> </ul>		√	√	√	√	√	
16	Shift pedal pivot shaft	<ul style="list-style-type: none"> <li>● Apply lithium-soap-based grease lightly.</li> </ul>		√	√	√	√	√	
17	Sidestand pivot	<ul style="list-style-type: none"> <li>● Check operation.</li> <li>● Apply lithium-soap-based grease lightly.</li> </ul>		√	√	√	√	√	
18	* Sidestand switch	<ul style="list-style-type: none"> <li>● Check operation and replace if necessary.</li> </ul>	√	√	√	√	√	√	
19	* Front fork	<ul style="list-style-type: none"> <li>● Check operation and for oil leakage.</li> <li>● Replace if necessary.</li> </ul>		√	√	√	√	√	
20	* Shock absorber assembly	<ul style="list-style-type: none"> <li>● Check operation and for oil leakage.</li> <li>● Replace if necessary.</li> </ul>		√	√	√	√	√	
21	* Rear suspension link pivots	<ul style="list-style-type: none"> <li>● Check operation.</li> <li>● Correct if necessary.</li> </ul>			√		√		
22	Engine oil	<ul style="list-style-type: none"> <li>● Change (warm engine before draining).</li> </ul>	√	√	√	√	√	√	
23	Engine oil filter element	<ul style="list-style-type: none"> <li>● Replace.</li> </ul>	√		√		√		
24	* Front and rear brake switches	<ul style="list-style-type: none"> <li>● Check operation.</li> </ul>	√	√	√	√	√	√	
25	* Control cables	<ul style="list-style-type: none"> <li>● Apply Yamaha chain and cable lube or engine oil SAE 10W-30 thoroughly.</li> </ul>	√	√	√	√	√	√	
26	* Throttle grip housing and cable	<ul style="list-style-type: none"> <li>● Check operation and free play.</li> <li>● Adjust the throttle cable free play if necessary.</li> <li>● Lubricate the throttle grip housing and cable.</li> </ul>		√	√	√	√	√	

# PERIODIC MAINTENANCE

No	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (6000 km) or 6 months	7000 mi (11000 km) or 12 months	10000 mi (16000 km) or 18 months	13000 mi (21000 km) or 24 months	16000 mi (26000 km) or 30 months	
27	* <b>Lights, signals and switches</b>	<ul style="list-style-type: none"> <li>● Check operation.</li> <li>● Adjust headlight beam.</li> </ul>	√	√	√	√	√	√	

\* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

**NOTE:**

From 19000 mi (31000 km) or 36 months, repeat the maintenance intervals starting from 7000 mi (11000 km) or 12 months.

**NOTE:**

- **Air filter**
  - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
  - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- **Hydraulic brake service**
  - After disassembling the brake master cylinders and calipers, always change the fluid. Regularly check the brake fluid levels and fill the reservoirs as required.
  - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
  - Replace the brake hoses every four years and if cracked or damaged.

EAS20471

## ENGINE

EAS20520

### ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

**NOTE:**


- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.

1. Remove:

- Fuel tank  
Refer to "FUEL TANK" on page 6-1.

2. Remove:

- Intake tappet cover "1"
- Exhaust tappet cover "2"
- Camshaft sprocket cover "3"




3. Remove:

- Spark plug cap
- Spark plug

4. Remove:

- Timing mark accessing screw "1"
- Crankshaft end cover "2"



5. Measure:

- Valve clearance  
Out of specification → Adjust.



### Valve clearance (cold)

#### Intake


0.05–0.10 mm (0.0020–0.0039 in)

#### Exhaust


0.10–0.15 mm (0.0039–0.0059 in)



- Turn the crankshaft counterclockwise.
- When the piston is in the compression stroke, align camshaft sprocket mark "a" with cylinder head mark "b". This is the Top Dead Center (TDC).




- Make sure that generator rotor mark "c" aligns with generator rotor cover mark "d".



- Measure the valve clearance using special thickness gauge "1".  
Out of specification → Adjust.



**Special thickness gauge**  
90890-01399






6. Adjust:
- Valve clearance



- Loosen the locknut "1"
- Insert special thickness gauge "2" between the adjusting screw and the valve stem end.
- Using tappet adjusting tool "3", turn the adjusting screw "4" in direction "a" or "b" to adjust the valve clearance.



**Direction "a"**  
Increases the valve clearance.  
**Direction "b"**  
Decreases the valve clearance.

	<p><b>Tappet adjusting tool</b> 90890-01311 <b>Six piece tappet set</b> YM-A5970</p>
--	--

- Hold the adjusting screw to prevent it from moving and tighten the locknut to specification.

	<p><b>Lock nut (valve clearance adjusting screw)</b> 14 Nm (1.4 m•kg, 10 ft•lb)</p>
--	---

- Measure the valve clearance again.
- If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



7. Install:
- O-ring **New**
  - Crankshaft end cover
  - O-ring **New**
  - Timing mark accessing screw

8. Install:
- Spark plug
  - Spark plug cap

	<p><b>Spark plug</b> 18 Nm (1.8 m•kg, 13 ft•lb)</p>
--	---

9. Install:
- O-ring **New**
  - Camshaft sprocket cover
  - O-ring **New**
  - Exhaust tappet cover
  - O-ring **New**
  - Intake tappet cover

	<p><b>Camshaft sprocket cover bolt</b> 10 Nm (1.0 m•kg, 7.2 ft•lb) <b>Exhaust tappet cover</b> 18 Nm (1.8 m•kg, 13 ft•lb) <b>Intake tappet cover</b> 18 Nm (1.8 m•kg, 13 ft•lb)</p>
--	---

10. Install:
- Fuel tank
- Refer to "FUEL TANK" on page 6-1.


EAS20610

## ADJUSTING THE ENGINE IDLING SPEED


**NOTE:** Before adjusting the engine idling speed, the air filter element should be clean, and the engine should have adequate compression.

1. Install:
- Pocket tester (temperature probe) "1"
  - (To oil drain bolt)
  - Digital tachometer

	<p><b>Pocket tester</b> 90890-03132 <b>Digital tachometer</b> 90890-06760 YU-39951-B</p>
--	--



2. Start the engine and let it warm up until it reaches specified oil temperature.

	<b>Oil temperature</b> 95.0–105.0 °C (203.00–221.00 °F)
---	--

3. Check:
  - Engine idling speed
 Out of specification → Adjust.


	<b>Engine idling speed</b> 1300–1500 r/min
---	---

4. Adjust:
  - Engine idling speed




- a. Adjust the engine idling speed by turning the throttle stop screw “1” in direction “a” or “b”.

<p><b>Direction “a”</b> Increases the engine idling speed.</p> <p><b>Direction “b”</b> Decreases the engine idling speed.</p>
---



5. Adjust:
  - Throttle cable play
 Refer to “ADJUSTING THE THROTTLE CABLE FREE PLAY” on page 3-9.

	<b>Throttle cable free play</b> 3.0–5.0 mm (0.12–0.20 in)
---	--


EAS20640


## ADJUSTING THE THROTTLE CABLE FREE PLAY

### NOTE:

Before adjusting the throttle cable free play, the engine idling speed should be adjusted properly.

1. Check:
  - Throttle cable play “a”
 Out of specification → Adjust.




	<b>Throttle cable free play</b> 3.0–5.0 mm (0.12–0.20 in)
---	--

2. Adjust:
  - Throttle cable free play



### Carburetor side

- a. Loosen locknut “1” of the pulling (accelerating) throttle cable.
- b. Adjust dimension “a” to approximately 5 mm by turning the adjusting nut “2” as shown.
- c. Tighten the locknut “1”.






## Handlebar side

- a. Loosen the locknut "1".
- b. Adjust the play of throttle cable by turning the adjusting nut "2" in direction "a" or "b".

**Direction "a"**  
Increases the throttle cable play.  
**Direction "b"**  
Decreases the throttle cable play.

- c. Tighten the locknut.



EWA12920

### **WARNING**

After adjusting the throttle cable free play, start the engine and turn the handlebars to the right and to the left to ensure that this does not cause the engine idling speed to change.



EAS20690

## CHECKING THE SPARK PLUG

1. Disconnect:
  - Spark plug cap
2. Remove:
  - Spark plug

ECA13330

### **CAUTION:**


Before removing the spark plug, blow away any dirt accumulated in the spark plug well with compressed air to prevent it from falling into the cylinder.

3. Check:
  - Spark plug type  
Incorrect → Change.

**Manufacturer/model**  
NGK/DR7EA

4. Check:
  - Electrode "1"  
Damage/wear → Replace the spark plug.
  - Insulator "2"  
Abnormal color → Replace the spark plug.  
Normal color is medium-to-light tan.
5. Clean:
  - Spark plug  
(with a spark plug cleaner or wire brush)
6. Measure:
  - Spark plug gap "a"  
(with a wire thickness gauge)  
Out of specification → Regap.

**Spark plug gap**  
0.6–0.7 mm (0.024–0.028 in)



7. Install:
  - Spark plug

**Spark plug**  
18 Nm (1.8 m•kg, 13 ft•lb)

**NOTE:**  
Before installing the spark plug, clean the spark plug and gasket surface.


8. Connect:
  - Spark plug cap

EAS20700


## CHECKING THE IGNITION TIMING


**NOTE:**  
Before checking the ignition timing, check the wiring connections of the entire ignition system. Make sure all connections are tight and free of corrosion.

1. Remove:
  - Timing mark accessing screw "1"



2. Connect:
  - Timing light "1"
  - Digital tachometer

	<b>Timing light</b> 90890-03141 <b>Inductive clamp timing light</b> YU-03141 <b>Digital tachometer</b> 90890-06760 YU-39951-B
---	---




3. Check:
  - Ignition timing



- a. Start the engine, warm it up to the specified oil temperature, then adjust to the standard idling speed.

	<b>Engine idling speed</b> 1300–1500 r/min
---	---

- b. Check the firing range as shown.  
Out of the firing range → Check the ignition system



**NOTE:** \_\_\_\_\_  
The ignition timing is not adjustable.



4. Remove:
  - Digital tachometer
  - Timing light
5. Install:
  - Timing mark accessing screw

EAS20710

## MEASURING THE COMPRESSION PRESSURE

The following procedure applies to all of the cylinders.

**NOTE:** \_\_\_\_\_  
Insufficient compression pressure will result in a loss of performance.

1. Measure:
  - Valve clearance  
Out of specification → Adjust.  
Refer to "ADJUSTING THE VALVE CLEARANCE" on page 3-5.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Disconnect:
  - Spark plug cap
4. Remove:
  - Spark plug

ECA13340


**CAUTION:** \_\_\_\_\_  
**Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.**

5. Install:
  - Compression gauge "1"





**Compression gauge  
90890-03081  
Engine compression tester  
YU-33223**



**6. Measure:**

- Compression pressure  
Out of specification → Refer to steps (c) and (d).



**Standard compression pressure  
1200 kPa (12.0 kg/cm<sup>2</sup>/300 rpm)  
Minimum compression pressure  
1050 kPa (10.5 kg/cm<sup>2</sup>/300 rpm)  
Maximum compression pressure  
1300 kPa (13.0 kg/cm<sup>2</sup>/300 rpm)**

- a. Set the main switch to "ON".
- b. With the throttle wide open, crank the engine until the reading on the compression gauge stabilizes.

EWA12960



**WARNING**

**To prevent sparking, ground the spark plug lead before cranking the engine.**

**NOTE:**

- Make use the battery is fully charged when taking measurements.
  - Make sure there is no compression leakage from the connecting section of the compression gauge.
- c. If the compression pressure is above the maximum specification, check the cylinder head, valve surfaces and piston crown for carbon deposits.  
Carbon deposits → Eliminate.
- d. If the compression pressure is below the minimum specification, pour a teaspoonful of engine oil into the spark plug bore and measure again.  
Refer to the following table.

Compression pressure (with oil applied into the cylinder)	
Reading	Diagnosis
Higher than without oil	Piston ring(s) wear or damage → Repair.
Same as without oil	Piston, valves, cylinder head gasket or piston possibly defective → Repair.



**7. Install:**

- Spark plug



**Spark plug  
18 Nm (1.8 m•kg, 13 ft•lb)**

**8. Connect:**

- Spark plug cap


EAS20730

**CHECKING THE ENGINE OIL LEVEL**

1. Stand the vehicle on a level surface.

**NOTE:**

- Place the vehicle on a suitable stand.
  - Make sure the vehicle is upright.
2. Start the engine, warm it up for several minutes, and then turn it off.
  3. Check:
    - Engine oil level  
The engine oil level should be between the minimum level mark "a" and maximum level mark "b".  
Below the minimum level mark → Add the recommended engine oil to the proper level.







**Type**  
**YAMALUBE 4, SAE10W30 or SAE20W40**  
**Recommended engine oil grade**  
**API service SG type or higher,**  
**JASO standard MA**  
**ACEA standard**  
**G4 or G5**

ECA13360

**CAUTION:**

- Engine oil also lubricates the clutch and the wrong oil types or additives could cause clutch slippage. Therefore, do not add any chemical additives or use engine oils with a grade of CD or higher and do not use oils labeled “ENERGY CONSERVING II”.
- Do not allow foreign materials to enter the crankcase.



**NOTE:**

Before checking the engine oil level, wait a few minutes until the oil has settled.

4. Start the engine, warm it up for several minutes, and then turn it off.
5. Check the engine oil level again.

**NOTE:**

Before checking the engine oil level, wait a few minutes until the oil has settled.



EAS20810

**CHANGING THE ENGINE OIL**

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place a container under the engine oil drain bolt.

3. Remove:

- Engine oil filler cap “1”
- Engine oil drain bolt “2” (along with the gasket)
- Oil filter element drain bolt “3”




4. Drain:

- Engine oil (completely from the crankcase)

5. If the oil filter element is also to be replaced, perform the following procedure.

- a. Remove the oil filter element cover “1” and oil filter element “2”.
- b. Replace the O-rings “3”. **New**




- c. Install the new oil filter element and the oil filter element cover.


	<p><b>Oil filter element cover bolt (M10)</b>  <b>10 Nm (1.0 m•kg, 7.2 ft•lb)</b></p>
--	---



6. Check:
  - Engine oil drain bolt gasket
  - Oil filter element drain bolt gasket  
Damage → Replace.
7. Install:
  - Engine oil drain bolt
  - Oil filter element drain bolt  
(along with the gasket)

	<b>Engine oil drain bolt</b> <b>20 Nm (2.0 m•kg, 15 ft•lb)</b> <b>Oil filter element drain bolt</b> <b>10 Nm (1.0 m•kg, 7.2 ft•lb)</b>
---	---


8. Fill:
  - Crankcase  
(with the specified amount of the recommended engine oil)

	<b>Engine oil quantity</b> <b>Total amount</b> <b>1.40 L (1.48 US qt) (1.23 Imp.qt)</b> <b>Without oil filter element replacement</b> <b>1.20 L (1.27 US qt) (1.06 Imp.qt)</b> <b>With oil filter element replacement</b> <b>1.30 L (1.37 US qt) (1.14 Imp.qt)</b>
---	--


9. Install:
  - Engine oil filler cap
10. Start the engine, warm it up for several minutes, and then turn it off.
11. Check:
  - Engine  
(for engine oil leaks)
12. Check:
  - Engine oil level  
Refer to “CHECKING THE ENGINE OIL LEVEL” on page 3-12.
13. Check:
  - Engine oil pressure



- a. Slightly loosen the oil check bolt “1”.



- b. Start the engine and keep it idling until engine oil starts to seep from the oil check bolt. If no engine oil comes out after one minute, turn the engine off so that it will not seize.
- c. Check the engine oil passages, the oil filter cartridge and the oil pump for damage or leakage. Refer to “INSTALL THE OIL PUMP AND BALANCER GEAR” on page 5-41.
- d. Start the engine after solving the problem(s) and check the engine oil pressure again.
- e. Tighten the oil check bolt to specification.


	<b>Oil check bolt</b> <b>7 Nm (0.7 m•kg, 5.1 ft•lb)</b>
--	--




EAS20870

## ADJUSTING THE CLUTCH CABLE FREE PLAY

1. Check:
  - Clutch cable free play “a”  
Out of specification → Adjust.

	<b>Clutch cable free play</b> <b>10.0–15.0 mm (0.39–0.59 in)</b>
---	---




2. Adjust:
  - Clutch cable free play



## Clutch lever side

- a. Slide rubber cover "1" from the clutch lever.
- b. Loosen the locknut "2".
- c. Fully tighten the adjusting bolt "3".
- d. Tighten the locknut "2".
- e. Slide and return rubber cover "1" to original position.




## Clutch cable side

- a. Slide rubber cover "1" from the clutch lever.
- b. Loosen the locknut "2".
- c. Adjust the play of clutch cable by turning the adjusting bolt "3" in direction "a" or "b".

**Direction "a"**  
Increases the clutch cable play.  
**Direction "b"**  
Decreases the clutch cable play.

- d. Tighten the locknut "2".
- e. Slide and return rubber cover "1" to original position.



EAS20961


## REPLACING THE AIR FILTER ELEMENT

1. Check:
  - Air filter check hose

## NOTE:

Check the air filter check hose locating at the bottom of air filter case. If a foreign material such as dust and water is found, replace the air filter element. Also, clean the air filter case and air filter check hose.


2. Remove:
  - Seat  
Refer to "GENERAL CHASSIS" on page 4-1.
3. Remove:
  - Air filter case cap "1"



4. Check:
  - Air filter element "1"  
Damage/obstruction → Replace.

## NOTE:

- Replace the air filter element every 20.000 km (12,427.42 mi) of operation.
- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.



5. Install:
  - Air filter element
  - Air filter case cap

ECA14401

## CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect carburetor synchronization, leading to poor engine performance and possible overheating.

**NOTE:**

Make sure that the air filter element is installed securely in the air filter case to prevent any air leaks.

6. Install:

- Seat  
Refer to “GENERAL CHASSIS” on page 4-1.

EAS20990


**CHECKING THE CARBURETOR JOINT AND INTAKE MANIFOLD**

1. Remove:

- Fuel tank  
Refer to “FUEL TANK” on page 6-1.

2. Check:

- Carburetor joint “1”
- Intake manifold “2”  
Cracks/damage → Replace.  
Refer to “CARBURETOR” on page 6-3.



3. Install:

- Fuel tank  
Refer to “FUEL TANK” on page 6-1.

EAS21030

**CHECKING THE FUEL LINE**


The following procedure applies to all of the fuel, vacuum and breather hoses.

1. Remove:

- Left fuel tank side cover  
Refer to “GENERAL CHASSIS” on page 4-1.

2. Check:

- Fuel hose “1”
- Vacuum hose
- Breather hose  
Cracks/damage → Replace.  
Loose connection → Connect properly or replace the clip hose.



3. Install:

- Left fuel tank side cover  
Refer to “GENERAL CHASSIS” on page 4-1.

EAS21050

**CHECKING THE CYLINDER HEAD BREATHER HOSE**

1. Remove:

- Left fuel tank side cover
- Right fuel tank side cover  
Refer to “GENERAL CHASSIS” on page 4-1.


2. Check:

- Cylinder head breather hose “1”  
Cracks/damage → Replace.  
Loose connection → Connect properly.

ECA14920

**CAUTION:**

**Make sure the cylinder head breather hose is routed correctly.**



3. Install:

- Right fuel tank side cover
- Left fuel tank side cover  
Refer to “GENERAL CHASSIS” on page 4-1.

EAS21080

**CHECKING THE EXHAUST SYSTEM**

The following procedure applies to all of the exhaust pipes and gaskets.

1. Check:


- Exhaust pipe “1”
- Muffler “2”  
Cracks/damage → Replace.
- Gasket




Exhaust gas leaks → Replace.

2. Check:

Tightening torque

- Exhaust pipe nut “3”
- Exhaust pipe joint bolt “4”
- Muffler bolt “5”

	<b>Exhaust pipe nut</b> 18 Nm (1.8 m•kg, 13 ft•lb)
	<b>Exhaust pipe joint bolt</b> 20 Nm (2.0 m•kg, 15 ft•lb)
	<b>Muffler bolt</b> 42 Nm (4.2 m•kg, 30 ft•lb)



EAS21140


## CHASSIS

EAS21170

### ADJUSTING THE FRONT DISC BRAKE

1. Check:

- Brake lever free play “a”  
Out of specification → Adjust.



	<b>Brake lever free play</b> 2.0–5.0 mm (0.08–0.20 in)
--	---


2. Adjust:

- Brake lever free play

- Loosen the locknut “1”.
- Turn the adjusting screw “2” in direction “a” or “b” until the specified brake lever free play is obtained.

<b>Direction “a”</b> Brake lever free play is increased. <b>Direction “b”</b> Brake lever free play is decreased.
--

c. Tighten the locknut “1”.



EWA13050

### WARNING

A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will consid-

erably reduce braking performance.

ECA13490

### CAUTION:

After adjusting the brake lever position, make sure there is no brake drag.


EAS21200

### ADJUSTING THE REAR DISC BRAKE

1. Check:

- Brake pedal position  
(Height “b” from footrest position “a” to brake pedal top position)  
Out of specification → Adjust.

	<b>Brake pedal position</b> 20.0 mm (0.79 in)
--	--




2. Adjust:


- Brake pedal position

- Loosen the locknut “1”.
- Turn the adjusting nut “2” in direction “a” or “b” until the specified brake pedal position is obtained.

<b>Direction “a”</b> Brake pedal is raised. <b>Direction “b”</b> Brake pedal is lowered.
---



c. Tighten the locknut "1" to specification.

	<b>Locknut</b> 17 Nm (1.7 m•kg, 12.5 ft•lb)
---	--

EWA5UXB005

**WARNING**

A soft or spongy feeling in the brake pedal can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance and could result in loss of control and possibly an accident. Therefore, check and, if necessary, bleed the brake system.

ECA13510

**CAUTION:**

After adjusting the brake pedal position, make sure there is no brake drag.



3. Adjust:

- Rear brake light switch  
Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" on page 3-20.

EAS21240

**CHECKING THE BRAKE FLUID LEVEL**

1. Stand the vehicle on a level surface.

**NOTE:**


- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.

2. Check:


- Brake fluid level  
Below the minimum level mark "a" → Add the recommended brake fluid to the proper level.

	<b>Recommended fluid</b> DOT 4
---	-----------------------------------

A



B



A. Front

B. Rear

EWA13090

**WARNING**

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

**CAUTION:**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilled brake fluid immediately.

**NOTE:**

In order to ensure a correct reading of the brake fluid level, make sure the top of the brake fluid reservoir is horizontal.

EAS21250

**CHECKING THE FRONT BRAKE PADS**


The following procedure applies to all of the brake pads.

1. Operate the brake.





Direction "a"  
 Brake light comes on sooner.  
 Direction "b"  
 Brake light comes on later.



EAS21350

## BLEEDING THE HYDRAULIC BRAKE SYSTEM

EWA13100

### **WARNING**

Bleed the hydraulic brake system whenever:

- the system is disassembled.
- a brake hose is loosened, disconnected or replaced.
- the brake fluid level is very low.
- brake operation is faulty.

1. Remove:
  - Brake master cylinder reservoir cap

#### NOTE:



- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir to overflow.
- When bleeding the hydraulic brake system, make sure there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the hydraulic brake system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.

2. Bleed:
  - Hydraulic brake system



- a. Fill the brake fluid reservoir to the proper level with the recommended brake fluid.
- b. Install the diaphragm (brake master cylinder reservoir or brake fluid reservoir).
- c. Connect clear plastic hose "1" tightly to bleed

screw "2", and place an oil pan under the plastic hose end.




- A. Front  
 B. Rear

- d. Place the other end of the hose into a container.
- e. Slowly apply the brake several times.
- f. Fully pull the brake lever or fully press down the brake pedal and hold it in position.
- g. Loosen the bleed screw.

#### NOTE:

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or the brake pedal to fully extend.

- h. Tighten the bleed screw and then release the brake lever or brake pedal.
- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Tighten the bleed screw to specification.

	<b>Bleed screw</b> <b>6 Nm (0.6 m•kg, 4.3 ft•lb)</b>
---	---

- k. Fill the brake fluid reservoir to the proper level with the recommended brake fluid.  
 Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-19.

EWA13110

### **WARNING**

**After bleeding the hydraulic brake system,**

## check the brake operation.



EAS21420

### ADJUSTING THE DRIVE CHAIN SLACK

#### NOTE:

The drive chain slack must be checked at the tightest point on the chain.

ECA13550

#### CAUTION:

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swing-arm or cause an accident. Therefore, keep the drive chain slack within the specified limits.

- Stand the vehicle on a level surface.

EWA13120


#### WARNING

Securely support the vehicle so that there is no danger of it falling over.

#### NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- Spin the rear wheel several times and find the tightest position of drive chain.
- Check:
  - Drive chain slack "a"  
Out of specification → Adjust.



	<b>Drive chain slack</b> <b>40.0–45.0 mm (1.57–1.77 in)</b>
--	--

#### NOTE:

- Measure the drive chain slack in the intermediate position between drive axle center and rear wheel axle center.
- If the chain contacts the drive chain guide, this is the limit of chain slack.


- Adjust:

- Drive chain slack



- Loosen the wheel axle nut "1".
- Turn the drive chain adjusting plate "2" in direction "a" or "b" until the specified drive chain slack is obtained.

<b>Direction "a"</b> <b>Drive chain is tightened.</b> <b>Direction "b"</b> <b>Drive chain is loosened.</b>
---



#### NOTE:

To maintain the proper wheel alignment, adjust both sides evenly.

- Tighten the wheel axle nut to specification.

	<b>Rear wheel axle nut</b> <b>85 Nm (8.5 m•kg, 62 ft•lb)</b>
--	---




EAS21440

### LUBRICATING THE DRIVE CHAIN

The drive chain consists of many interacting parts. If the drive chain is not maintained properly, it will wear out quickly. Therefore, the drive chain should be serviced, especially when the vehicle is used in dusty areas.

This vehicle has a drive chain with small rubber O-rings between each side plate. Steam cleaning, high-pressure washing, certain solvents, and the use of a coarse brush can damage these O-rings. Therefore, use only kerosene to clean the drive chain. Wipe the drive chain dry and thoroughly lubricate it with engine oil or chain lubricant that is suitable for O-ring chains. Do not use any other lubricants on the drive chain since they may contain solvents that could damage the O-rings.



**Recommended lubricant**  
 Engine oil or chain lubricant  
 suitable for O-ring chains

EAS21510

## CHECKING AND ADJUSTING THE STEERING HEAD

1. Stand the vehicle on a level surface.

EWA13120



**WARNING**

Securely support the vehicle so that there is no danger of it falling over.

### NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Check:

- Steering head  
 Grasp around the outer tube of the front fork legs and gently rock the front fork.  
 Binding/looseness → Adjust the steering head.

3. Remove:


- Upper bracket  
 Refer to "STEERING HEAD" on page 4-47.

4. Adjust:

- Steering head




a. Remove the lock washer "1", the upper ring nut "2", and the rubber washer "3".



b. Loosen the lower ring nut "4" first, then use the steering nut wrench "5" and retighten the nut with the specified torque. Next, check the steering by turning it to the right and left a few times.

### NOTE:

Set the torque wrench at a right angle to the steering nut wrench.



**Steering nut wrench**  
 90890-01403  
**Spanner wrench**  
 YU-33975



**Lower ring nut (initial tightening torque)**  
 38 Nm (3.8 m•kg, 2.8 ft•lb)

c. Loosen the lower ring nut "4" completely, and then use the steering nut wrench and retighten the nut with the specified torque.

EWA13140



**WARNING**

**Do not overtighten the lower ring nut.**



**Lower ring nut (final tightening torque)**  
 4 Nm (0.4 m•kg, 2.9 ft•lb)

d. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings.

Refer to "STEERING HEAD" on page 4-47.


e. Install the rubber washer "3".

f. Install the upper ring nut "2".

g. Finger tighten the upper ring nut "2", then align the slots of both ring nuts. If necessary, hold the lower ring nut and tighten the upper ring nut until their slots are aligned.

### NOTE:

Make sure the lock washer tabs "a" sit correctly in the ring nut slots "b".



5. Install:
- Upper bracket  
Refer to "STEERING HEAD" on page 4-47.

EAS21530

## CHECKING THE FRONT FORK


1. Stand the vehicle on a level surface.

EWA13120



**Securely support the vehicle so that there is no danger of it falling over.**

2. Check:
- Inner tube  
Damage/scratches → Replace.
  - Oil seal  
Oil leakage → Replace.
3. Hold the vehicle upright and apply the front brake.
4. Check:
- Front fork operation  
Push down hard on the handlebar several times and check if the front fork rebounds smoothly.  
Rough movement → Repair.  
Refer to "FRONT FORK" on page 4-39.



EAS21590

## ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY

EWA13120



**Securely support the vehicle so that there is no danger of it falling over.**

### Spring preload

ECA13590

**CAUTION:**

**Never go beyond the maximum or minimum adjustment positions.**

1. Adjust:
- Spring preload

**NOTE:**

Adjust the spring preload by removing the rear shock absorber.



- a. Adjust the spring preload with a ring nut wrench.



**Ring nut wrench**  
**90890-01268**  
**Spanner wrench**  
**YU-01268**


- b. Loosen the locknut "1".
- c. When you turn adjusting ring "2" in direction "a" or "b", spring length "c" changes and you can adjust the spring preload.


**Direction "a"**


**Spring preload is increased (suspension is harder).**

**Direction "b"**


**Spring preload is decreased (suspension is softer).**



	<b>Spring length "c"</b>
	Standard
	197.0 mm
	Minimum (hard)
	187.0 mm
	Maximum (soft)
	207.0 mm



d. Tighten the locknut.

	<b>Locknut</b>
	10 Nm (1.0 m•kg, 7.2 ft•lb)




EAS21650

## CHECKING THE TIRES

The following procedure applies to both of the tires.

- Check:
  - Tire pressure  
Out of specification → Regulate.



EWA13180

### WARNING

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding

speed.

- Operation of an overloaded vehicle could cause tire damage, an accident or an injury. **NEVER OVERLOAD THE VEHICLE.**



Tire air pressure (measured on cold tires)

Loading condition  
0–90 kg (0–198 lb)

Front  
125 kPa (18 psi) (1.25 kgf/cm<sup>2</sup>)

Rear  
150 kPa (22 psi) (1.50 kgf/cm<sup>2</sup>)

Loading condition  
90 kg–Maximum load

Front  
150 kPa (22 psi) (1.50 kgf/cm<sup>2</sup>)

Rear  
175 kPa (25 psi) (1.75 kgf/cm<sup>2</sup>)

High-speed riding

Front  
150 kPa (1.50 kgf/cm<sup>2</sup>)

Rear  
175 kPa (1.75 kgf/cm<sup>2</sup>)

Maximum load  
160 kg (353 lb)


\* Total weight of rider, passenger, cargo and accessories

EWA13190


### WARNING

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.

- Check:
  - Tire surfaces  
Damage/wear → Replace the tire.




- Tire tread depth
- Side wall
- Wear indicator

	Wear limit (front) 0.8 mm (0.03 in)
	Wear limit (rear) 0.8 mm (0.03 in)

EWA14080

**WARNING**

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using a tube tire, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.



Tube wheel	Tube tire only
Tubeless wheel	Tube or tubeless tire

EWA14090

**WARNING**

After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.

	Front tire
	Size 2.75-21 45P
	Manufacturer/model CHENG SHIN/C-6006
	Manufacturer/model DUNLOP/D605F

	Rear tire
	Size 120/80-18M/C 62P
	Manufacturer/model CHENG SHIN/C-6006
	Manufacturer/model DUNLOP/D605


EWA13210

**WARNING**

New tires have a relatively low grip on the road surface until they have been slightly worn. Therefore, approximately 100 km should be traveled at normal speed before any high-speed riding is done.

**NOTE:**

Align the mark "1" with the valve installation point.



EAS21670

**CHECKING THE WHEELS**

The following procedure applies to both of the wheels.

1. Check:
  - Wheel  
Damage/out-of-round → Replace.

EWA13260

**WARNING**

Never attempt to make any repairs to the wheel.

**NOTE:**

After a tire or wheel has been changed or replaced, always balance the wheel.


EAS21680

## CHECKING AND TIGHTENING THE SPOKES

The following procedure applies to all of the spokes.

1. Check:

- Spoke
  - Bends/damage → Replace.
  - Loose → Tighten.
  - Tap the spokes with a screwdriver.





**NOTE:**


A tight spoke will emit a clear, ringing tone; a loose spoke will sound flat.

2. Tighten:

- Spoke (Front/rear)
  - (with a spoke wrench “1” and torque wrench “2”)


	<b>Spoke (Front wheel)</b> 2 Nm (0.2 m•kg, 1.4 ft•lb)
---	--

	<b>Spoke wrench</b> 90890-01522
---	------------------------------------



3. Tighten:

- Spoke (Rear wheel)

	<b>Spoke (Rear wheel)</b> 4 Nm (0.4 m•kg, 2.9 ft•lb)
---	---

**NOTE:**

Be sure to tighten the spokes before and after break-in.

EAS21690

## CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

EWA13270



**Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.**

1. Check:
  - Outer cable
    - Damage → Replace.
2. Check:
  - Cable operation
    - Rough movement → Lubricate.

	<b>Recommended lubricant</b> Engine oil or a suitable cable lubricant
---	--


**NOTE:**

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

EAS21700

## LUBRICATING THE LEVERS

Lubricate the pivoting point and metal-to-metal moving parts of the levers.

	<b>Clutch lever</b> Lithium-soap-based grease
	<b>Brake lever</b> Silicone grease

EAS21710

## LUBRICATING THE PEDAL


Lubricate the pivoting point and metal-to-metal moving parts of the pedal.

	<b>Recommended lubricant</b> Lithium-soap-based grease
---	---

EAS21720

## LUBRICATING THE SIDESTAND


Lubricate the pivoting point and metal-to-metal moving parts of the sidestand.

	<b>Recommended lubricant</b> Lithium-soap-based grease
---	---

EAS21740

## LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.

	<b>Recommended lubricant</b> Molybdenum disulfide grease
---	---



EAS21750

## ELECTRICAL SYSTEM

EAS21760

### CHECKING AND CHARGING THE BATTERY

Refer to "ELECTRICAL COMPONENTS" on page 7-29.

EAS21770


### CHECKING THE FUSES

Refer to "ELECTRICAL COMPONENTS" on page 7-29.


EAS21780

### REPLACING THE HEADLIGHT BULB


- Remove:
  - Headlight cowling "1"




- Remove:
  - Headlight unit bolts "1"



- Disconnect:
  - Headlight coupler "1"
  - Bulb cover "2"



- Remove:
  - Headlight bulb holder "1"



EWA13320

### WARNING

Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has cooled down.

- Install:
  - Headlight bulb **New**
    - Secure the new headlight bulb with the headlight bulb holder.

ECA13690

### CAUTION:

Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

- Install:
  - Headlight bulb holder
  - Bulb cover
  - Headlight coupler
- Install:
  - Headlight unit



**Headlight unit bolt**  
7 Nm (0.7 m•kg, 5.1 ft•lb)

EAS21800


### ADJUSTING THE HEADLIGHT BEAM

- Adjust:
  - Headlight beam (vertically)



- Turn the adjusting screw "1" in direction "a" or "b".

**Direction "a"**  
Headlight beam is raised.  
**Direction "b"**  
Headlight beam is lowered.



---

# CHASSIS

<b>GENERAL CHASSIS .....</b>	<b>4-1</b>
<b>FRONT WHEEL .....</b>	<b>4-2</b>
REMOVING THE FRONT WHEEL .....	4-4
CHECKING THE FRONT WHEEL .....	4-4
DISASSEMBLING THE FRONT WHEEL.....	4-4
ASSEMBLING THE FRONT WHEEL.....	4-5
ADJUSTING THE FRONT WHEEL STATIC BALANCE .....	4-5
INSTALLING THE FRONT WHEEL (DISC).....	4-6
<b>REAR WHEEL.....</b>	<b>4-8</b>
REMOVING THE REAR WHEEL (DISC).....	4-10
DISASSEMBLING THE REAR WHEEL .....	4-10
CHECKING THE REAR WHEEL .....	4-10
CHECKING AND REPLACING THE REAR WHEEL SPROCKET .....	4-10
ASSEMBLING THE REAR WHEEL .....	4-11
ADJUSTING THE REAR WHEEL STATIC BALANCE .....	4-11
INSTALLING THE REAR WHEEL .....	4-11
<b>FRONT BRAKE.....</b>	<b>4-12</b>
INTRODUCTION.....	4-17
CHECKING THE FRONT BRAKE DISC .....	4-17
REPLACING THE FRONT BRAKE PADS .....	4-18
REMOVING THE FRONT BRAKE CALIPER.....	4-19
DISASSEMBLING THE FRONT BRAKE CALIPER.....	4-19
CHECKING THE FRONT BRAKE CALIPER .....	4-19
ASSEMBLING THE FRONT BRAKE CALIPER.....	4-20
INSTALLING THE FRONT BRAKE CALIPER .....	4-20
REMOVING THE FRONT BRAKE MASTER CYLINDER.....	4-21
CHECKING THE FRONT BRAKE MASTER CYLINDER .....	4-21
ASSEMBLING THE FRONT BRAKE MASTER CYLINDER .....	4-22
INSTALLING THE FRONT BRAKE MASTER CYLINDER .....	4-22
<b>REAR BRAKE.....</b>	<b>4-24</b>
INTRODUCTION.....	4-29
CHECKING THE REAR BRAKE DISC .....	4-29
REPLACING THE REAR BRAKE PADS .....	4-29
REMOVING THE REAR BRAKE CALIPER .....	4-30
DISASSEMBLING THE REAR BRAKE CALIPER .....	4-30
CHECKING THE REAR BRAKE CALIPER.....	4-31
ASSEMBLING THE REAR BRAKE CALIPER .....	4-31
INSTALLING THE REAR BRAKE CALIPER.....	4-31
REMOVING THE REAR BRAKE MASTER CYLINDER .....	4-32
CHECKING THE REAR BRAKE MASTER CYLINDER.....	4-33
ASSEMBLING THE REAR BRAKE MASTER CYLINDER .....	4-33
INSTALLING THE REAR BRAKE MASTER CYLINDER.....	4-33
<b>HANDLEBAR .....</b>	<b>4-35</b>
REMOVING THE HANDLEBARS .....	4-36

---


CHECKING THE HANDLEBAR .....	4-36
INSTALLING THE HANDLEBAR .....	4-36
<b>FRONT FORK .....</b>	<b>4-39</b>
REMOVING THE FRONT FORK LEGS.....	4-42
DISASSEMBLING THE FRONT FORK LEGS.....	4-42
CHECKING THE FRONT FORK LEGS .....	4-43
ASSEMBLING THE FRONT FORK LEGS.....	4-43
INSTALLING THE FRONT FORK LEGS .....	4-46
<b>STEERING HEAD .....</b>	<b>4-47</b>
REMOVING THE LOWER BRACKET .....	4-49
CHECKING THE STEERING HEAD.....	4-49
INSTALLING THE STEERING HEAD.....	4-49
<b>REAR SHOCK ABSORBER ASSEMBLY .....</b>	<b>4-51</b>
HANDLING THE REAR SHOCK ABSORBER.....	4-52
DISPOSING OF A REAR SHOCK ABSORBER .....	4-52
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-52
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-52
CHECKING THE CONNECTING ARM AND RELAY ARM.....	4-52
INSTALLING THE RELAY ARM .....	4-52
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-53
<b>SWINGARM .....</b>	<b>4-54</b>
REMOVING THE SWINGARM .....	4-55
CHECKING THE SWINGARM .....	4-55
INSTALLING THE SWINGARM.....	4-55
<b>CHAIN DRIVE .....</b>	<b>4-57</b>
REMOVING THE DRIVE CHAIN .....	4-58
CHECKING THE DRIVE CHAIN .....	4-58
CHECKING THE DRIVE SPROCKET .....	4-59
INSTALLING THE DRIVE CHAIN.....	4-59

# GENERAL CHASSIS

EAS21830

## GENERAL CHASSIS

### Removing the cowling




Order	Job/Parts to remove	Q'ty	Remarks
1	Seat	1	
2	Rear left side cover	1	
3	Rear right side cover	1	
4	Left fuel tank side cover	1	
5	Right fuel tank side cover	1	
6	Front left side cover	1	
7	Front right side cover	1	
8	Tool box	1	
			For installation, reverse the removal procedure.

EAS21870

## FRONT WHEEL


### Removing the front wheel and brake disc



Order	Job/Parts to remove	Q'ty	Remarks
			<b>NOTE:</b> Use a suitable stand to raise the front wheel off the ground.
1	Front wheel axle nut	1	
2	Front wheel axle	1	
3	Front wheel assembly	1	
4	Collar/dust seal	2/2	
5	Front brake disc	1	
			For installation, reverse the removal procedure.

# FRONT WHEEL



## Disassembling the front wheel




Order	Job/Parts to remove	Q'ty	Remarks
1	Oil seal	2	
2	Wheel bearing	2	
3	Spacer	1	
			For assembly, reverse the disassembly procedure.







- c. Remove the wheel bearings with a general bearing puller.



EAS21960

## ASSEMBLING THE FRONT WHEEL

1. Install:
- Wheel bearings
  - Oil seals **New**
  - Spacer



- a. Install the new wheel bearings and oil seals in the reverse order of disassembly.

EC3C51001

### CAUTION:

Do not contact the wheel bearing inner race "1" or balls "2". Support with the outer race "3".

### NOTE:

Use a socket "4" that matches the diameter of the wheel bearing outer race and oil seal.



EAS21970

## ADJUSTING THE FRONT WHEEL STATIC BALANCE

### NOTE:

- After replacing the tire, wheel or both, the front wheel static balance should be adjusted.
- Adjust the front wheel static balance with the brake disc installed.


1. Remove:
- Balancing weight(s)
2. Find:
- Front wheel's heavy spot

### NOTE:

Place the front wheel on a suitable balancing stand.




- a. Spin the front wheel.
- b. When the front wheel stops, put an "X<sub>1</sub>" mark at the bottom of the wheel.



- c. Turn the front wheel 90° so that the "X<sub>1</sub>" mark is positioned as shown.
- d. Release the front wheel.
- e. When the wheel stops, put an "X<sub>2</sub>" mark at the bottom of the wheel.

# FRONT WHEEL




- f. Repeat steps (d) through (f) several times until all the marks come to rest at the same spot.
- g. The spot where all the marks come to rest is the front wheel's heavy spot "X".



3. Adjust:
  - Front wheel static balance




- a. Install a balancing weight "1" onto the rim exactly opposite the heavy spot "X".



**NOTE:** \_\_\_\_\_  
Start with the lightest weight.

- b. Turn the front wheel 90° so that the heavy spot is positioned as shown.




- c. If the heavy spot does not stay in that position, install a heavier weight.
- d. Repeat steps (b) and (c) until the front wheel is balanced.



4. Check:
  - Front wheel static balance



- a. Turn the front wheel and make sure it stays at each position shown.



- b. If the front wheel does not remain stationary at all of the positions, rebalance it.



EAS22000


## INSTALLING THE FRONT WHEEL (DISC)

The following procedure applies to both of the brake discs.

1. Install:
  - Front brake disc  
Refer to "CHECKING THE FRONT BRAKE DISC" on page 4-17.
2. Lubricate:
  - Front wheel axle
  - Oil seal lips

	<b>Recommended lubricant</b> <b>Lithium-soap-based grease</b>
---	--

3. Tighten:
  - Front wheel axle nut "1"





**Front axle nut**  
**85 Nm (8.5 m•kg, 62 ft•lb)**

EWA13500



**WARNING**

**Make sure the brake hose is routed properly.**

ECA14140

**CAUTION:**

**Before tightening the wheel axle nut, push down hard on the handlebar(s) several times and check if the front fork rebounds smoothly.**


---

# REAR WHEEL

EAS22020

## REAR WHEEL


### Removing the rear wheel, brake disc and rear wheel sprocket



Order	Job/Parts to remove	Q'ty	Remarks
			<b>NOTE:</b> Use a suitable stand to raise the rear wheel off the ground.
1	Drive chain case	1	
2	Rear wheel axle nut	1	
3	Drive chain adjusting plate	2	
4	Rear wheel axle	1	
5	Drive chain	1	
6	Rear wheel assembly	1	
7	Collar/dust cover	1/1	
8	Collar/dust cover	1/1	
9	Rear brake disc	1	
10	Rear wheel sprocket	1	
			For installation, reverse the removal procedure.

# REAR WHEEL

## Disassembling the rear wheel



Order	Job/Parts to remove	Q'ty	Remarks
1	Oil seal	2	
2	Wheel bearing	3	
3	Spacer	1	
			For installation, reverse the removal procedure.

EAS22040

## REMOVING THE REAR WHEEL (DISC)

- Stand the vehicle on a level surface.

EWA13120




**Securely support the vehicle so that there is no danger of it falling over.**

### NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- Elevate:
  - Rear wheel
- Remove:
  - Drive chain case
  - Rear wheel axle nut
  - Drive chain adjusting plate "1"
  - Rear wheel axle "2"
  - Rear wheel "3"



### NOTE:

Push the rear wheel forward and remove the drive chain from the rear wheel sprocket.

EAS22080

## DISASSEMBLING THE REAR WHEEL

- Remove:
  - Oil seals
  - Wheel bearings

Refer to "DISASSEMBLING THE FRONT WHEEL" on page 4-4.

EAS22100

## CHECKING THE REAR WHEEL

- Check:
  - Rear wheel axle
  - Rear wheel
  - Wheel bearings
  - Oil seals

Refer to "CHECKING THE FRONT WHEEL" on page 4-4.
- Check:
  - Tire
  - Rear wheel

Damage/wear → Replace.

Refer to "CHECKING THE TIRES" on page 3-23 and "CHECKING THE WHEELS" on page 3-24.

- Check:
  - Spokes
  - Bends/damage → Replace.
  - Loose → Tighten.

Refer to "CHECKING THE FRONT WHEEL" on page 4-4.
- Measure:
  - Radial rear wheel runout
  - Lateral rear wheel runout

Refer to "CHECKING THE FRONT WHEEL" on page 4-4.




**Radial wheel runout limit**  
**2.0 mm (0.08 in)**  
**Lateral wheel runout limit**  
**2.0 mm (0.08 in)**

EAS22120

## CHECKING AND REPLACING THE REAR WHEEL SPROCKET

- Check:
  - Rear wheel sprocket

More than 1/4 tooth "a" wear → Replace the drive chain, drive sprocket, and rear wheel sprocket as a set.  
 Bent teeth → Replace the drive chain, drive sprocket, and rear wheel sprocket as a set.



- a. 1/4 wear
- b. Correct

1. Drive chain roller
2. Rear wheel sprocket

- Replace:
  - Rear wheel sprocket

- Remove the self-locking nuts and the rear wheel sprocket.
- Clean the rear wheel drive hub with a clean cloth, especially the surfaces that contact the sprocket.
- Install the new rear wheel sprocket.



# REAR WHEEL



**Rear wheel sprocket self-locking nut**  
**33 Nm (3.3 m•kg, 29 ft•lb)**

**NOTE:**

Tighten the self-locking nuts in stages and in a crisscross pattern.



**Recommended lubricant**  
**Lithium-soap-based grease**

3. Adjust:

- Drive chain slack  
Refer to “ADJUSTING THE DRIVE CHAIN SLACK” on page 3-20.



**Drive chain slack**  
**40.0–45.0 mm (1.57–1.77 in)**

4. Tighten:

- Rear wheel axle nut



**Rear wheel axle nut**  
**85 Nm (8.5 m•kg, 62 ft•lb)**



EAS22140

## ASSEMBLING THE REAR WHEEL

1. Install:

- Wheel bearings
- Oil seals **New**  
Refer to “ASSEMBLING THE FRONT WHEEL” on page 4-5.
- Spacer

EAS22150

## ADJUSTING THE REAR WHEEL STATIC BALANCE

**NOTE:**

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and drive sprocket installed.

1. Adjust:

- Rear wheel static balance  
Refer to “ADJUSTING THE FRONT WHEEL STATIC BALANCE” on page 4-5.

EAS22160

## INSTALLING THE REAR WHEEL

1. Install:

- Rear brake disc  
Refer to “CHECKING THE REAR BRAKE DISC” on page 4-29.


2. Lubricate:

- Rear wheel axle
- Oil seal lips

EAS22210

## FRONT BRAKE

### Removing the front brake pads




Order	Job/Parts to remove	Q'ty	Remarks
1	Front brake caliper support bolt	1	<b>NOTE:</b> Remove the lower parts only.
2	Front brake caliper assembly	1	<b>NOTE:</b> Lift and remove the front brake caliper assembly.
3	Front brake pad	2	
4	Brake pad shim	1	
5	Brake pad spring	2	
			For installation, reverse the removal procedure.




# FRONT BRAKE

## Removing the front brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the brake fluid		Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.
1	Right rear view mirror	1	
2	Brake lever	1	
3	Front brake light switch	1	
4	Union bolt	1	
5	Copper washer	2	
6	Front brake hose	1	
7	Brake master cylinder reservoir cap	1	
8	Brake master cylinder reservoir diaphragm holder	1	
9	Brake master cylinder reservoir diaphragm	1	
10	Front brake master cylinder holder	1	
11	Front brake master cylinder	1	
			For installation, reverse the removal procedure.


## Disassembling the front brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
1	Master cylinder kit	1	
			For assembly, reverse the disassembly procedure.

# FRONT BRAKE


## Removing the front brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the brake fluid		Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.
1	Union bolt	1	
2	Copper washer	2	
3	Front brake hose	1	
4	Front brake caliper support bolt	2	
5	Front brake caliper assembly	1	
6	Front brake pad	2	
7	Brake pad shim	1	
8	Brake pad spring	2	
9	Front brake caliper bracket	1	
			For installation, reverse the removal procedure.

# FRONT BRAKE

## Disassembling the front brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
1	Brake caliper piston	2	
2	Brake caliper piston seal	2	
3	Brake caliper dust seal	2	
4	Bleed screw	1	
			For assembly, reverse the disassembly procedure.

EAS22220

## INTRODUCTION

EWA14100

### **WARNING**

**Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:**

- **Never disassemble brake components unless absolutely necessary.**
  - **If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.**
  - **Never use solvents on internal brake components.**
  - **Use only clean or new brake fluid for cleaning brake components.**
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.**

- **Avoid brake fluid coming into contact with the eyes as it can cause serious injury.**

### **FIRST AID FOR BRAKE FLUID ENTERING THE EYES:**

**Flush with water for 15 minutes and get immediate medical attention.**




- a. Place the vehicle on a suitable stand so that the front wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection at the point 13 mm (front brake) or 14 mm (rear brake) below the edge of brake disc.



4. Measure:
  - Brake disc thickness  
 Measure the brake disc thickness at a few different locations.  
 Out of specification → Replace.


	<b>Brake disc thickness limit 3.0 mm (0.12 in)</b>
---	--



EAS22230

## CHECKING THE FRONT BRAKE DISC

1. Remove:
  - Front wheel  
 Refer to "FRONT WHEEL" on page 4-2.
2. Check:
  - Front brake disc  
 Damage/galling → Replace.
3. Measure:
  - Brake disc deflection  
 Out of specification → Correct the brake disc deflection or replace the brake disc.





5. Adjust:
  - Brake disc deflection




- a. Remove the brake disc.
- b. Turn the brake disc by one bolt hole.
- c. Install the brake disc.

**NOTE:** \_\_\_\_\_  
 Tighten the brake disc bolts in stages and in a crisscross pattern.

	<b>Brake disc deflection limit 0.15 mm (0.0059 in)</b>
---	--



	<p><b>Brake disc bolt</b>  <b>10 Nm (1.0 m•kg, 7.2 ft•lb)</b>  <b>Apply locking agent (LOC-TITE®)</b></p>
---	---

- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.



6. Install:
  - Front wheel
 Refer to "FRONT WHEEL" on page 4-2.


EAS22280


## REPLACING THE FRONT BRAKE PADS

### NOTE:

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

1. Measure:
  - Brake pad wear limit "a"  
 Out of specification → Replace the brake pads as a set.

	<p><b>Brake pad lining thickness (inner)</b>  <b>5.3 mm (0.21 in)</b>  <b>Limit</b>  <b>0.8 mm (0.03 in)</b>  <b>Brake pad lining thickness (outer)</b>  <b>5.3 mm (0.21 in)</b>  <b>Limit</b>  <b>0.8 mm (0.03 in)</b></p>
---	---




2. Install:
  - Brake pad shims (onto the inner brake pads)
  - Front brake pads
  - Brake pad spring


### NOTE:

Always install new brake pads, brake pad shims, and a brake pad spring as a set.

- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container. The oil pan must be under the hose end to receive the drain oil.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.



- c. Tighten the bleed screw.


	<p><b>Bleed screw</b>  <b>6 Nm (0.6 m•kg, 4.3 ft•lb)</b></p>
---	--

- d. Install new brake pads, new brake pad shims, and a new brake pad spring.



3. Lubricate:
  - Front brake caliper support bolt

# FRONT BRAKE

 **Front brake caliper support bolt**  
Silicone grease


ECA14150

**CAUTION:**

- Do not allow grease to contact the brake pads.
- Remove any excess grease.


4. Install:

- Front brake caliper

 **Brake caliper support bolt**  
32 Nm (3.2 m•kg, 24 ft•lb)

5. Check:

- Brake fluid level  
Below the minimum level mark “a” → Add the recommended brake fluid to the proper level. Refer to “CHECKING THE BRAKE FLUID LEVEL” on page 3-17.



6. Check:

- Brake fluid level  
Soft or spongy feeling → Bleed the brake system. Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” on page 3-19.

EAS22290

**REMOVING THE FRONT BRAKE CALIPER**

**NOTE:**

Before disassembling the brake caliper, drain the brake fluid from the entire brake system.

1. Remove:

- Union bolt
- Copper washers
- Brake hose

**NOTE:**


Put the end of the brake hose into a container and pump out the brake fluid carefully.

EAS22320

**DISASSEMBLING THE FRONT BRAKE CALIPER**

1. Remove:

- Brake caliper pistons “1”
- Brake caliper piston seals “2”
- Brake caliper dust seals “3”




- a. Blow compressed air into the brake hose joint opening “a” to force out the pistons from the brake caliper.

EWA13560

**WARNING**

- Cover the brake caliper pistons with a rag. Be careful not to get injured when the pistons are expelled from the brake caliper.
- Never try to pry out the brake caliper pistons.



- b. Remove the brake caliper piston seals and dust seals.



EAS22390


**CHECKING THE FRONT BRAKE CALIPER**

Recommended brake component replacement schedule	
Brake pads	If necessary
Piston seals / dust seals	Every two years
Brake hoses	Every four years
Brake fluid	Every four years and whenever the brake is disassembled

# FRONT BRAKE

## 1. Check:

- Brake caliper pistons “1”  
Rust/scratches/wear → Replace the brake caliper pistons.
- Brake caliper cylinders “2”  
Scratches/wear → Replace the brake caliper assembly.
- Brake caliper body “3”  
Cracks/damage → Replace the brake caliper assembly.
- Brake fluid delivery passages (brake caliper body)  
Obstruction → Blow out with compressed air.



EWA13610

### **WARNING**

Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

## 2. Check:

- Brake caliper bracket  
Cracks/damage → Replace.

EAS22400

## ASSEMBLING THE FRONT BRAKE CALIPER

EWA13620

### **WARNING**

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.



**Recommended fluid  
DOT 4**

EAS22420

## INSTALLING THE FRONT BRAKE CALIPER

### 1. Install:

- Front brake caliper bracket
- Front brake caliper (temporarily)

- Copper washers **New**
- Front brake hose
- Union bolt



**Front brake caliper bracket bolt  
40 Nm (4.0 m•kg, 29 ft•lb)  
Union bolt  
30 Nm (3.0 m•kg, 22 ft•lb)**

EWA13530


### **WARNING**

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” on page 2-25.

ECA14170

### **CAUTION:**

When installing the brake hose onto the brake caliper “1”, make sure the brake pipe “a” touches the projection “b” on the brake caliper.



### 2. Remove:

- Front brake caliper

### 3. Install:

- Brake pad springs
- Front brake pad
- Front brake caliper
- Brake caliper support bolt  
Refer to “REPLACING THE FRONT BRAKE PADS” on page 4-18.



**Brake caliper support bolt  
32 Nm (3.2 m•kg, 23 ft•lb)**

### 4. Fill:

- Brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



**Recommended fluid  
DOT 4**

EWA13090

### **WARNING**

- Use only the designated brake fluid. Other



brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.

- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

**CAUTION:**


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

5. Bleed:

- Brake system  
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.

6. Check:

- Brake fluid level  
Below the minimum level mark "a" → Add the recommended brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-17.



7. Check:

- Brake lever operation  
Soft or spongy feeling → Bleed the brake system.  
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.

EAS22490

**REMOVING THE FRONT BRAKE MASTER CYLINDER**

**NOTE:**

Before removing the front brake master cylinder, drain the brake fluid from the entire brake system.


1. Disconnect:

- Front brake light switch "1"

(from the brake switch)

**NOTE:**

Remove the master cylinder by pressing the projection.



2. Remove:

- Union bolt
- Copper washers
- Front brake hose

**NOTE:**


To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

EAS22500

**CHECKING THE FRONT BRAKE MASTER CYLINDER**

1. Check:

- Front brake master cylinder "1"  
Damage/scratches/wear → Replace.
- Brake fluid delivery passages "2"  
(brake master cylinder body)  
Obstruction → Blow out with compressed air.



2. Check:

- Brake master cylinder kit "1"  
Damage/scratches/wear → Replace.

3. Check:

- Brake master cylinder reservoir cap
- Brake master cylinder reservoir diaphragm holder
- Brake master cylinder reservoir diaphragm  
Cracks/damage → Replace.

4. Check:

- Front brake hose  
Cracks/damage/wear → Replace.

EAS22520

## ASSEMBLING THE FRONT BRAKE MASTER CYLINDER


EWA13520


### **WARNING**

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.


	<b>Recommended fluid DOT 4</b>
---	------------------------------------

1. Install:
  - Cylinder cup "1" **New**
  - Master cylinder piston "2"
 Use the cylinder cup installer "3" for installation.

	<b>Cylinder cup installer 90890-01996</b>
---	---




2. Install:
  - Master cylinder piston
  - Circlip "1" **New**
  - Dust boot "2"




EAS22530

## INSTALLING THE FRONT BRAKE MASTER CYLINDER


1. Install:
  - Front brake master cylinder "1"

	<b>Front brake master cylinder holder bolt 7 Nm (0.7 m•kg, 5.1 ft•lb)</b>
---	---

- NOTE:**
- Install the brake master cylinder holder with the "UP" mark facing up.
  - Align the end of the brake master cylinder holder with the punch mark "a" on the handlebar.
  - First, tighten the upper bolt, then the lower bolt.



2. Install:
  - Copper washers "1" **New**
  - Brake hose "2"
  - Union bolt "3"



	<b>Union bolt 30 Nm (3.0 m•kg, 22 ft•lb)</b>
---	--

EWA13530

### **WARNING**


**Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-25.**

- NOTE:**
- Hold the brake hose, and tighten the union bolt so that the hose comes within the angle as shown.
  - Turn the handlebar to the left and right to make sure the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.



### 3. Fill:

- Brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



EWA13540

### **WARNING**

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

### **CAUTION:**

**Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.**

### 4. Bleed:

- Brake system  
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” on page 3-19.

### 5. Check:

- Brake fluid level  
Below the minimum level mark “a” → Add the recommended brake fluid to the proper level. Refer to “CHECKING THE BRAKE FLUID LEVEL” on page 3-17.


### 6. Check:

- Brake lever operation  
Soft or spongy feeling → Bleed the brake system.  
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” on page 3-19.

EAS22550

## REAR BRAKE


### Removing the rear brake pads



Order	Job/Parts to remove	Q'ty	Remarks
	Rear wheel		Refer to "REAR WHEEL" on page 4-8.
1	Rear brake caliper cover	1	
2	Brake pad support bolt	2	
3	Rear brake pad	2	
4	Rear brake caliper bracket	1	
5	Brake pad spring	2	
6	Rear brake caliper assembly	1	
			For installation, reverse the removal procedure.


# REAR BRAKE

## Removing the rear brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the brake fluid		Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.
1	Union bolt	1	
2	Copper washer	2	
3	Rear brake hose	1	
4	Cotter pin	1	
5	Brake master cylinder reservoir cap	1	
6	Brake master cylinder reservoir diaphragm holder	1	
7	Brake master cylinder reservoir diaphragm	1	
8	Rear brake master cylinder	1	
			For installation, reverse the removal procedure.


## Disassembling the rear brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
1	Master cylinder kit	1	
			For assembly, reverse the disassembly procedure.

# REAR BRAKE


## Removing the rear brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the brake fluid		Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.
	Rear wheel		Refer to "REAR WHEEL" on page 4-8.
1	Rear brake caliper cover	1	
2	Rear brake hose	1	
3	Brake hose joint	1	
4	Copper washer	1	
5	Brake pad support bolt	2	
6	Rear brake pad	2	
7	Rear brake caliper bracket	1	
8	Brake pad spring	2	
9	Rear brake caliper assembly	1	
			For installation, reverse the removal procedure.

# REAR BRAKE

## Disassembling the rear brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
1	Brake caliper piston	1	
2	Brake caliper piston seal	2	
3	Brake caliper dust seal	2	
4	Bleed screw	1	
			For assembly, reverse the disassembly procedure.



EAS22560

## INTRODUCTION

EWA14100

### WARNING

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.


### FIRST AID FOR BRAKE FLUID ENTERING THE EYES:

Flush with water for 15 minutes and get immediate medical attention.

EAS22570

## CHECKING THE REAR BRAKE DISC


1. Remove:
  - Rear wheel  
Refer to "REAR WHEEL" on page 4-8.
2. Check:
  - Rear brake disk  
Damage/galling → Replace.
3. Measure:
  - Brake disc deflection  
Out of specification → Correct the brake disc deflection or replace the brake disc.  
Refer to "CHECKING THE FRONT BRAKE DISC" on page 4-17.

	<p><b>Brake disc deflection limit</b> 0.15 mm (0.0059 in)</p>
---	---

4. Measure:
  - Brake disc thickness  
Measure the brake disc thickness at a few different locations.  
Out of specification → Replace.  
Refer to "CHECKING THE FRONT BRAKE DISC" on page 4-17.

	<p><b>Brake disc thickness limit</b> 4.0 mm (0.16 in)</p>
---	---

5. Adjust:
  - Brake disc deflection  
Refer to "CHECKING THE FRONT BRAKE DISC" on page 4-17.

	<p><b>Brake disc bolt</b> 28 Nm (2.8 m•kg, 21 ft•lb) Apply locking agent (LOCTITE®)</p>
---	---


6. Install:
  - Rear wheel  
Refer to "REAR WHEEL" on page 4-8.


EAS22580

## REPLACING THE REAR BRAKE PADS

**NOTE:**  
When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.


1. Measure:
  - Brake pad wear limit "a"  
Out of specification → Replace the brake pads as a set.

	<p><b>Brake pad lining thickness (inner)</b> 5.2 mm (0.20 in) <b>Limit</b> 1.0 mm (0.04 in) <b>Brake pad lining thickness (outer)</b> 5.2 mm (0.20 in) <b>Limit</b> 1.0 mm (0.04 in)</p>
---	--



2. Lubricate:
  - Support pin  
(Rear brake caliper or rear brake caliper bracket)
  - Brake pad support bolt

# REAR BRAKE

	<b>Brake pad support bolt</b> <b>Silicone grease</b>
---	---

ECA14150

**CAUTION:**

- Do not allow grease to contact the brake pads.
- Remove any excess grease.

3. Install:


- Rear brake pad
- Brake pad spring
- Rear brake caliper bracket

**NOTE:**


Always install new brake pads, brake pad shims, and a brake pad spring as a set.



- a. Connect a clear plastic hose "2" tightly to the bleed screw "1". Put the other end of the hose into an open container. The oil pan must be under the hose end to receive the drain oil.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.



- c. Tighten the bleed screw.


	<b>Bleed screw</b> <b>6 Nm (0.6 m•kg, 4.3 ft•lb)</b>
---	---

- d. Install new brake pads and a new brake pad spring.




4. Install:

- Brake pad support bolt
- Rear brake caliper cover

	<b>Brake pad support bolt</b> <b>17 Nm (1.7 m•kg, 13 ft•lb)</b>
	<b>Rear brake caliper cover bolt</b> <b>7 Nm (0.7 m•kg, 5.1 ft•lb)</b>

5. Check:

- Brake fluid level  
Below minimum level mark "a" → Add the recommended brake fluid to proper level.  
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-17.



6. Check:

- Brake pedal operation  
Soft or spongy feeling → Bleed the brake system.  
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-19.

EAS22590

**REMOVING THE REAR BRAKE CALIPER**

**NOTE:**

Before disassembling the brake caliper, drain the brake fluid from the entire brake system.

1. Remove:

- Rear brake hose
- Brake hose joint
- Copper washers

**NOTE:**


Put the end of the brake hose into a container and pump out the brake fluid carefully.

EAS22600

**DISASSEMBLING THE REAR BRAKE CALIPER**

1. Remove:

- Brake caliper piston "1"
- Brake caliper piston seal "2"
- Brake caliper dust seal "3"





# REAR BRAKE




**Brake hose joint (caliper side)**  
26 Nm (2.6 m•kg, 19 ft•lb)  
**Brake hose joint (hose side)**  
14 Nm (1.4 m•kg, 10 ft•lb)

EWA13530

## WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “**CABLE ROUTING**” on page 2-25.



### 4. Remove:

- Rear wheel
- Rear brake caliper bracket
- Rear brake caliper

### 5. Install:

- Brake pad springs
- Rear brake caliper bracket
- Rear brake pads
- Brake pad support bolts
- Brake caliper

Refer to “**REPLACING THE REAR BRAKE PADS**” on page 4-29.



**Brake pad support bolt**  
17 Nm (1.7 m•kg, 13 ft•lb)

### 6. Install:

- Rear wheel  
Refer to “**REAR WHEEL**” on page 4-8.

### 7. Fill:

(with the specified amount of the recommended brake fluid)

- Brake master cylinder reservoir



**Recommended fluid**  
DOT 4

EWA13090

## WARNING

• Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor

brake performance.

- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

## CAUTION:


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

### 8. Bleed:

- Brake system  
Refer to “**BLEEDING THE HYDRAULIC BRAKE SYSTEM**” on page 3-19.

### 9. Check:

- Brake fluid level  
Below the minimum level mark “a” → Add the recommended brake fluid to the proper level. Refer to “**CHECKING THE BRAKE FLUID LEVEL**” on page 3-17.



### 10. Check:

- Brake pedal operation  
Soft or spongy feeling → Bleed the brake system.  
Refer to “**BLEEDING THE HYDRAULIC BRAKE SYSTEM**” on page 3-19.

EAS22700

## REMOVING THE REAR BRAKE MASTER CYLINDER

Before disassembling the rear brake master cylinder, drain the brake fluid from the entire brake system.

### 1. Remove:

- Union bolt
- Copper washers
- Brake hose

## NOTE:

To collect any remaining brake fluid, place a


# REAR BRAKE

container under the master cylinder and the end of the brake hose.

EAS22710

## CHECKING THE REAR BRAKE MASTER CYLINDER

- Check:
  - Rear brake master cylinder "1"  
Damage/scratches/wear → Replace.
  - Brake fluid delivery passages "2"  
(brake master cylinder body)  
Obstruction → Blow out with compressed air.



- Check:
  - Brake master cylinder kit "1"  
Damage/scratches/wear → Replace.
- Check:
  - Brake master cylinder reservoir cap
  - Brake master cylinder reservoir diaphragm holder
  - Brake master cylinder reservoir diaphragm  
Cracks/damage → Replace.
- Check:
  - Rear brake hose  
Cracks/damage/wear → Replace.

EAS22730

## ASSEMBLING THE REAR BRAKE MASTER CYLINDER


EWA13520


### **WARNING**

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.


	<b>Recommended fluid DOT 4</b>
---	------------------------------------

- Install:
  - Cylinder cup "1" **New**
  - Master cylinder piston "2"  
Install it using with cylinder cup installer "3".

	<b>Cylinder cup installer 90890-01996</b>
---	---




- Assemble:
  - Spring "1"
  - Master cylinder piston "2"
  - Adjusting rod "3"
  - Circlip "4" **New**
  - Dust boot "5"



EAS22750

## INSTALLING THE REAR BRAKE MASTER CYLINDER

- Install:
  - Copper washers **New**
  - Brake hoses
  - Union bolt

	<b>Brake hose union bolt 30 Nm (3.0 m•kg, 22 ft•lb)</b>
---	---

EWA13530



### **WARNING**

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-25.

ECA14160

### **CAUTION:**

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection "a" as shown.



2. Add the recommended brake fluid to the proper level.
  - Brake master cylinder reservoir



EWA13090

**WARNING**

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

**CAUTION:**

**Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.**


3. Bleed:
  - Brake system  
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” on page 3-19.
4. Check:
  - Brake fluid level  
Below the minimum level mark “a” → Add the recommended brake fluid to the proper level. Refer to “CHECKING THE BRAKE FLUID LEVEL” on page 3-17.

5. Check:
  - Brake lever operation  
Soft or spongy feeling → Bleed the brake system.  
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” on page 3-19.

EAS22840

## HANDLEBAR

### Removing the handlebar



Order	Job/Parts to remove	Q'ty	Remarks
1	Back view mirror	2	
2	Front brake light switch	1	
3	Front brake master cylinder holder	1	
4	Front brake master cylinder assembly	1	
5	Right handlebar switch	1	
6	Throttle cable housing	1	
7	Throttle cable	2	
8	Throttle grip	1	
9	Clutch cable	1	
10	Clutch switch	1	
11	Clutch lever holder	1	
12	Clutch lever assembly	1	
13	Left handlebar switch	1	
14	Handlebar grip	1	
15	Special washer	1	
16	Handlebar holder	2	
17	Handlebar	1	
			For installation, reverse the removal procedure.

EAS22860

## REMOVING THE HANDLEBARS

1. Stand the vehicle on a level surface.

EWA13120


### WARNING

Securely support the vehicle so that there is no danger of it falling over.

2. Remove:
  - Front brake light switch
  - Clutch switch

### NOTE:


Release the key by pressing its projection, and remove the handlebar from the master cylinder assembly or clutch lever assembly.



3. Remove:
  - Handlebar grip "1"

### NOTE:

Blow compressed air between the handlebar and the handlebar grip, and gradually push the grip off the handlebar.



EAS22880

## CHECKING THE HANDLEBAR

1. Check:
  - Handlebar

Bends/cracks/damage → Replace.

EWA13690

### WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.

EAS22921

## INSTALLING THE HANDLEBAR


1. Stand the vehicle on a level surface.

EWA13120

### WARNING

Securely support the vehicle so that there is no danger of it falling over.

2. Install:
  - Handlebar "1"
  - Upper handlebar holders "2"

	<b>Handlebar holder bolt</b> <b>23 Nm (2.3 m•kg, 17 ft•lb)</b>
---	---



EC3CS1009

### CAUTION:

First, tighten the bolts on the front side of the handlebar holder, and then on the rear side.

### NOTE:

- Align mark "a" of the handlebar with the top face of upper bracket.
- The upper handlebar holders should be installed with the arrow marks "b" facing forward "A".



3. Install:
  - Special washer
  - Handlebar grip



- Slightly coat the handlebar left end with a rubber adhesive.
- Slide the handlebar grip over the left end of the handlebar.



# HANDLEBAR

- c. Clean the excessive rubber adhesive with a clean cloth. rubber adhesive

EWA13700

## WARNING


**Do not touch the handlebar grip until the rubber adhesive has fully dried.**

### 1. Install:

- Left handlebar switch "1"

#### NOTE:

- Align tab "a" of special washer with slot "b" of left handlebar switch.
- Align the matching surface of left handlebar switch with mark "c" of the handlebar.




### 2. Install:

- Clutch lever assembly "1"
- Clutch lever holder "2"

#### NOTE:

Align the mating surfaces of the clutch lever holder with the punch mark "a" on the handlebar.



### 3. Install:

- Throttle grip "1"
- Throttle cables "2"
- Throttle cable housing "3"

EWA13720


## WARNING

**Make sure the throttle grip operates smoothly.**

#### NOTE:

- Align projection "a" of slot cable housing with hole "b" of the handlebar.

- Slightly coat the end of slot cable and inside of throttle grip with Yamaha Grease B. Then, mount the throttle grip onto the handlebar.




### 4. Install:

- Right handlebar switch "1"

#### NOTE:

Align projection "a" of the right handlebar switch with hole "b" of the handlebar.



### 5. Install:


- Front brake master cylinder assembly "1"
- Front brake master cylinder holder "2"



**Front brake master cylinder assembly**  
**7 Nm (0.7 m•kg, 5.1 ft•lb)**

#### NOTE:

- Install the brake master cylinder holder with the "UP" mark facing up.
- Align the matching surface of brake master cylinder holder with mark "a" of handlebar.
- Tighten the upper bolt first, and then tighten the lower bolt.




6. Adjust:

- Clutch cable free play  
Refer to “ADJUSTING THE CLUTCH CABLE FREE PLAY” on page 3-12.

	<b>Clutch lever free play</b> <b>10.0–15.0 mm (0.39–0.59 in)</b>
---	---

7. Adjust:


- Throttle cable free play  
Refer to “ADJUSTING THE THROTTLE CABLE FREE PLAY” on page 3-7

	<b>Throttle cable free play</b> <b>3.0–5.0 mm (0.12–0.2 in)</b>
--	--

EAS22950

## FRONT FORK


### Removing the front fork legs



Order	Job/Parts to remove	Q'ty	Remarks
	Front wheel		Refer to "FRONT WHEEL" on page 4-2.
1	Brake hose holder	1	
2	Front brake caliper	1	
3	Mudguard	1	
4	Upper bracket pinch bolt	2	Loosen.
5	Front fork cap bolt	1	Loosen.
6	Lower bracket pinch bolt	2	Loosen.
7	Fork leg	1	
8	Dust boot	1	
			For installation, reverse the removal procedure.

# FRONT FORK


## Disassembling the front fork legs



Order	Job/Parts to remove	Q'ty	Remarks
1	Front fork cap bolt	1	
2	Cap bolt O-ring	1	
3	Spacer	1	
4	Spring seat	1	
5	Fork spring	1	
6	Dust seal	1	
7	Oil seal clip	1	
8	Damper rod bolt	1	
9	Copper washer	1	
10	Inner tube	1	
11	Oil seal	1	
12	Washer	1	
13	Outer tube bushing	1	
14	Oil flow stopper	1	
15	Spacer	1	
16	Spring	1	
17	Damper rod	1	
18	Rebound spring	1	
19	Inner tube bushing	1	
20	Outer tube	1	

# FRONT FORK

## Disassembling the front fork legs



Order	Job/Parts to remove	Q'ty	Remarks
			For assembly, reverse the disassembly procedure.

EAS22970

## REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.

EWA13120

### **WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

### NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.


2. Loosen:

- Upper bracket pinch bolt "1"
- Front fork cap bolt "2"
- Lower bracket pinch bolts "3"

EWA13640

### **WARNING**

**Before loosening the upper and lower bracket pinch bolts, support the front fork leg.**



EAS22980


## DISASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Drain:
  - Fork oil

### NOTE:

Stroke the outer tube several times while draining the fork oil.




2. Remove:

- Dust seal "1"
- Oil seal clip "2" (with a flat-head screwdriver)

ECA14180

### **CAUTION:**

**Do not scratch the inner tube.**



3. Remove:


- Damper rod assembly bolt
- Copper washer

### NOTE:

While holding the damper rod assembly with the damper rod holder "1" and T-handle "2", loosen the damper rod bolt.



**Damper rod holder**  
90890-01460



4. Remove:
- Inner tube




- Hold the front fork leg horizontally.
- Securely clamp the brake caliper bracket in a vise with soft jaws.
- Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

ECA14190

**CAUTION:**

- Excessive force will damage the oil seal and bushing. A damaged oil seal or bushing must be replaced.
- Avoid bottoming the inner tube into the outer tube during the above procedure, as the oil flow stopper will be damaged.



EAS23010

**CHECKING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs.

- Check:
  - Inner tube
  - Outer tube
 Bends/damage/scratches → Replace.

EWA13650


**WARNING**

Do not attempt to straighten a bent inner tube as this may dangerously weaken it.

- Measure:
  - Spring free length "a"
 Out of specification → Replace.



**Fork spring free length**  
 482.0 mm (18.98 in)  
**Limit**  
 472.3 mm (18.59 in)



- Check:
  - Damper rod  
 Damage/wear → Replace.  
 Obstruction → Blow out all of the oil passages with compressed air.
  - Oil flow stopper  
 Damage → Replace.

ECA14200

**CAUTION:**

- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.

- Check:
  - Cap bolt  
 Damage/wear → Replace.

EAS23020

**ASSEMBLING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs.

EWA13660

**WARNING**

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

# FRONT FORK

**NOTE:**

- When assembling the front fork leg, be sure to replace the following parts:
  - Inner tube bushing
  - Outer tube bushing
  - Oil seal
  - Dust seal
- Before assembling the front fork leg, make sure all of the components are clean.


1. Install:

- Inner tube bushing "1" **New**
- Damper rod "2"
- Rebound spring
- Spring "3"
- Spacer "4"
- Oil flow stopper "5"

EC3C51002

**CAUTION:**

Allow the damper rod assembly to slide slowly down the inner tube "6" until it appears from the bottom of the inner tube. Be careful not to damage the inner tube.




2. Lubricate:

- Inner tube's outer surface

	<b>Recommended oil</b> Yamaha fork oil 15WT
---	--

3. Tighten:

- Damper rod bolt "1"


	<b>Damper rod bolt</b> 18 Nm (1.8 m•kg, 13 ft•lb) LOCTITE®204 Apply locking agent (LOCTITE®)
---	---

**NOTE:**

While holding the damper rod assembly with the damper rod holder "2" and T-handle "3", tighten the damper rod assembly bolt.



**Damper rod holder**  
90890-01460  
**T-handle**  
90890-01326  
**T-handle 3/8" drive 60 cm long**  
YM-01326




4. Install:

- Outer tube bushing "1" **New**
- Washer "2"  
(with the fork seal driver weight "3" and fork seal driver attachment "4")



**Fork seal driver weight**  
90890-01367  
**Replacement hammer**  
YM-A9409-7  
**Fork seal driver attachment (ø35)**  
90890-01369  
**Replacement 35 mm**  
YM-A9409-5



5. Install:

- Oil seal "1" **New**  
(with the fork seal driver weight "2" and fork seal driver attachment "3")

ECA14220

**CAUTION:**

**Make sure the numbered side of the oil seal faces up.**



**NOTE:**

- Before installing the oil seal, lubricate its lips with lithium soap base grease.




# FRONT FORK

- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag to protect the oil seal during installation.




6. Install:
- Oil seal clip "1"

**NOTE:** Adjust the oil seal clip so that it fits into the outer tube's groove.



7. Install:
- Dust seal "1"  
(with the fork seal driver weight "2")

	<p><b>Fork seal driver weight</b> 90890-01367 <b>Replacement hammer</b> YM-A9409-7</p>
--	--




8. Fill:
- Front fork leg  
(with the specified amount of the recommended fork oil)

	<p><b>Quantity</b> 385.0 cm<sup>3</sup> (13.02 US oz) (13.58 Imp.oz) <b>Recommended oil</b> Yamaha fork oil 15WT</p>
--	--

	<p><b>Level</b> 125.0 mm (4.92 in) <b>At position "a" from the inner tube top end when the inner tube is fully compressed in the outer tube</b></p>
--	---

- NOTE:**
- While filling the front fork leg, keep it upright.
  - After filling, slowly pump the front fork leg up and down to distribute the fork oil.



9. Install:
- Fork spring
  - Spring seat
  - Spacer
  - Front fork cap bolt

- NOTE:**
- Before installing the cap bolt, lubricate its O-ring with grease.
  - Temporarily tighten the cap bolt.

EAS23050

## INSTALLING THE FRONT FORK LEGS


The following procedure applies to both of the front fork legs.

1. Install:
  - Dust boot
  - Clamp screw (temporarily)
2. Install:
  - Front fork leg

Temporarily tighten the upper and lower bracket pinch bolts.

**NOTE:**

The inner tube top face must match the upper bracket top face.



3. Tighten:
  - Lower bracket pinch bolt "1"



**Lower bracket pinch bolt**  
23 Nm (2.3 m•kg, 17 ft•lb)

- Front fork cap bolt "2"



**Front fork cap bolt**  
23 Nm (2.3 m•kg, 17 ft•lb)

- Upper bracket pinch bolt "3"





**Upper bracket pinch bolt**  
23 Nm (2.3 m•kg, 17 ft•lb)

EWA13680



**WARNING**


Make sure the brake hoses are routed properly.



4. Install:
  - Dust boots "1"
  - Clamp screw

**NOTE:**


Direct air-bleeding hole "a" of the dust boot outward of the vehicle, and press and assemble the dust boot top end to the lower bracket.



EAS23090

## STEERING HEAD


Removing the head light unit, meter assembly and front fender



Order	Job/Parts to remove	Q'ty	Remarks
	Tool box		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 6-1.
	Handlebar		Refer to "HANDLEBAR" on page 4-35.
	Fork leg		Refer to "FRONT FORK" on page 4-39.
1	Head light cowling	1	
2	Headlight unit	1	
3	Headlight coupler	1	Disconnect.
4	Turn signal light connector	2	Disconnect.
5	Front turn signal light/rear turn signal light	1/1	
6	Meter assembly coupler	3	Disconnect.
7	Meter assembly	1	
8	Brake hose holder	1	
9	Head light unit stay	1	
10	Front fender	1	
11	Brake hose holder bracket	1	
			For installation, reverse the removal procedure.

# STEERING HEAD

## Removing the lower bracket



Order	Job/Parts to remove	Q'ty	Remarks
	Headlight unit/meter assembly/front fender		Refer to "STEERING HEAD" on page 4-47.
1	Main switch coupler	1	
2	Steering stem nut	1	
3	Upper bracket	1	
4	Lock washer	1	
5	Upper ring nut	1	
6	Rubber washer	1	
7	Lower ring nut	1	
8	Lower bracket	1	
9	Bearing cover	1	
10	Washer	1	
11	Upper bearing	1	
12	Lower bearing	1	
13	Bearing races	2	
			For installation, reverse the removal procedure.

# STEERING HEAD

EAS23110

## REMOVING THE LOWER BRACKET

1. Stand the vehicle on a level surface.

EWA13120



**WARNING**

Securely support the vehicle so that there is no danger of it falling over.

2. Remove:

- Upper ring nut
- Rubber washer
- Lower ring nut “1”

**NOTE:**

Remove both upper and lower ring nuts using the ring nut wrench.




Ring nut wrench  
90890-01268  
Spanner wrench  
YU-01268

EWA13730



**WARNING**

Securely support the lower bracket so that there is no danger of it falling.



EAS23120

## CHECKING THE STEERING HEAD

1. Wash:

- Bearings
- Bearing races



Recommended cleaning solvent  
Kerosene

2. Check:

- Bearings
  - Bearing races
- Damage/pitting → Replace.

3. Replace:

- Bearings
- Bearing races

a. Remove the bearing races from the steering head pipe with a long rod “1” and hammer.

b. Remove the bearing from the lower bracket with a floor chisel “2” and hammer.

c. Install new bearing races.



ECA14270

**CAUTION:**

If the bearing race is not installed properly, the steering head pipe could be damaged.

**NOTE:**

Always replace the bearings and bearing races as a set.



4. Check:

- Upper bracket
  - Lower bracket
- (along with the steering stem)  
Bends/cracks/damage → Replace.

EAS23140

## INSTALLING THE STEERING HEAD

1. Lubricate:

- Upper bearing
- Lower bearing
- Bearing races



Recommended lubricant  
Lithium-soap-based grease

2. Install:

- Lower bracket
- Lower ring nut “1”
- Rubber washer “2”


# STEERING HEAD

- Upper ring nut “3”
- Lock washer “4”

Refer to “CHECKING AND ADJUSTING THE STEERING HEAD” on page 3-21.

**NOTE:** \_\_\_\_\_

Portion “a” having the large tapered area must face downward when the lower ring nut is mounted.



3. Install:

- Upper bracket
- Steering stem nut

**NOTE:** \_\_\_\_\_

Temporarily tighten the steering stem nut.

4. Install:

- Front fork legs
- Refer to “FRONT FORK” on page 4-39.

**NOTE:** \_\_\_\_\_

Temporarily tighten the lower bracket pinch bolts.

5. Tighten:

- Steering stem nut




**Steering stem nut**  
**110 Nm (11.0 m•kg, 80 ft•lb)**

# REAR SHOCK ABSORBER ASSEMBLY

EAS23160

## REAR SHOCK ABSORBER ASSEMBLY

### Removing the rear shock absorber assembly



Order	Job/Parts to remove	Q'ty	Remarks
	Rear left side cover/rear right side cover		Refer to "GENERAL CHASSIS" on page 4-1.
1	Connecting arm	2	
2	Relay arm	1	
3	Rear shock absorber assembly	1	
4	Spacer	1	
5	Spacer	1	
6	Spacer	1	
7	Oil seal	6	
8	Bearing	1	
9	Bushing	3	
			For installation, reverse the removal procedure.

# REAR SHOCK ABSORBER ASSEMBLY

EAS23180

## HANDLING THE REAR SHOCK ABSORBER

EWA13740

### WARNING

This rear shock absorber contains highly compressed nitrogen gas. Before handling the rear shock absorber, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber.

- Do not tamper or attempt to open the rear shock absorber.
- Do not subject the rear shock absorber to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber in any way. Rear shock absorber damage will result in poor damping performance.

EAS23190


## DISPOSING OF A REAR SHOCK ABSORBER

1. Gas pressure must be released before disposing of a rear shock absorber. To release the gas pressure, drill a 2–3-mm hole through the rear shock absorber at a point 60 mm from its end as shown.

EWA13760

### WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.



EAS23230

## REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the vehicle on a level surface.

EWA13120

### WARNING

Securely support the vehicle so that there is no danger of it falling over.

**NOTE:** \_\_\_\_\_

Place the vehicle on a suitable stand so that the rear wheel is elevated.

EAS23240

## CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

1. Check:
  - Rear shock absorber rod  
Bends/damage → Replace the rear shock absorber assembly.
  - Rear shock absorber  
Gas leaks/oil leaks → Replace the rear shock absorber assembly.
  - Spring  
Damage/wear → Replace the rear shock absorber assembly.
  - Bushings  
Damage/wear → Replace.
  - Bolts  
Bends/damage/wear → Replace.

EAS23260

## CHECKING THE CONNECTING ARM AND RELAY ARM

1. Check:
  - Connecting arms
  - Relay arm  
Damage/wear → Replace.
2. Check:
  - Bearings
  - Oil seals
  - Bushing  
Damage/pitting → Replace.
3. Check:
  - Spacers  
Damage/scratches → Replace.

EAS23270

## INSTALLING THE RELAY ARM


1. Lubricate:
  - Spacers
  - Bearings
  - Oil seal




2. Install:
  - Bearing “1”  
(to the relay arm “2”)
  - Bushing “3”  
to relay arm “2”



# REAR SHOCK ABSORBER ASSEMBLY

	Installed depth "a"
	4.5 mm
	Installed depth "b"
	3 mm
	Installed depth "c"
	4 mm



EAS23310

## INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

1. Install:


- Rear shock absorber assembly

### NOTE:


Install the rear shock absorber by facing its valve backward.

2. Tighten:


- Rear shock absorber assembly upper nut

	<b>Rear shock absorber assembly upper nut</b>
	<b>50 Nm (5.0 m•kg, 36 ft•lb)</b>


- Relay arm nut (frame side)

	<b>Relay-arm nut (frame side)</b>
	<b>50 Nm (5.0 m•kg, 36 ft•lb)</b>


- Rear shock absorber assembly lower nut

	<b>Rear shock absorber assembly lower nut</b>
	<b>40 Nm (4.0 m•kg, 29 ft•lb)</b>

- Connecting arm nut (relay-arm side)

	<b>Connecting arm nut (relay-arm side)</b>
	<b>59 Nm (5.9 m•kg, 43 ft•lb)</b>


- Connecting arm nut (swingarm side)

	<b>Connecting arm nut (swingarm side)</b>
	<b>59 Nm (5.9 m•kg, 43 ft•lb)</b>

EAS23330

## SWINGARM

### Removing the swingarm



Order	Job/Parts to remove	Q'ty	Remarks
	Rear wheel		Refer to "REAR WHEEL" on page 4-8.
	Rear shock absorber assembly		Refer to "REAR SHOCK ABSORBER ASSEMBLY" on page 4-51.
1	Brake hose holder	1	
2	Pivot shaft nut	1	
3	Pivot shaft	1	
4	Swingarm	1	
5	Front drive chain guide	1	
6	Rear drive chain guide	1	
7	Dust cover	2	
8	Spacer	1	
9	Bushing	2	
10	Spacer	1	
11	Oil seal	2	
12	Bushing	2	
			For installation, reverse the removal procedure.

EAS23350

## REMOVING THE SWINGARM

1. Stand the vehicle on a level surface.

EWA13120



**Securely support the vehicle so that there is no danger of it falling over.**

### NOTE:


Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Measure:

- Swingarm side play
- Swingarm vertical movement




a. Measure the tightening torque of the pivot shaft nut.

	<b>Pivot shaft nut</b> <b>80 Nm (8.0 m•kg, 58 ft•lb)</b>
---	---


b. Measure the swingarm side play “A” by moving the swingarm from side to side.

c. If the swingarm side play is out of specification, check the spacers, bearings, washers, and dust covers.

	<b>Swingarm up/down stroke limit at rear end position of the rear arm</b> <b>1.0 mm</b> <b>Swing arm play limit on the pivot shaft</b> <b>1.0 mm</b>
---	---

d. Check the swingarm vertical movement “B” by moving the swingarm up and down.

If swingarm vertical movement is not smooth or if there is binding, check the spacers, spacers, washers, and dust covers.



EAS23360

## CHECKING THE SWINGARM

1. Check:

- Swingarm  
Bends/cracks/damage → Replace.


2. Check:

- Pivot shaft  
Roll the pivot shaft on a flat surface.  
Bends → Replace.

EWA13770



**Do not attempt to straighten a bent pivot shaft.**



3. Wash:

- Pivot shaft
- Dust covers
- Spacer
- Washers
- Bushing

	<b>Recommended cleaning solvent</b> <b>Kerosene</b>
---	--

4. Check:


- Dust covers
- Spacer
- Washers
- Oil seals  
Damage/wear → Replace.
- Bushing  
Damage/pitting → Replace.

EAS23380

## INSTALLING THE SWINGARM

1. Lubricate:



- Bushing
- Spacers
- Dust covers
- Pivot shaft

	<b>Recommended lubricant</b> <b>Molybdenum disulfide grease</b>
---	--

2. Install:

- Bushing “1”

- Oil seal “2”
- Spacer “3”  
(to the swingarm “4”)



### 3. Install:

- Rear shock absorber assembly
- Rear wheel  
Refer to “REAR SHOCK ABSORBER ASSEMBLY” on page 4-51 and “REAR WHEEL” on page 4-8.

### 4. Adjust:


- Drive chain slack  
Refer to “ADJUSTING THE DRIVE CHAIN SLACK” on page 3-20.



EAS23400

## CHAIN DRIVE

### Removing the drive chain



Order	Job/Parts to remove	Q'ty	Remarks
	Swingarm		Refer to "SWINGARM" on page 4-54.
1	Drive sprocket cover	1	
2	Drive sprocket nut	1	
3	Lock washer	1	
4	Drive sprocket	1	
5	Drive chain	1	
			For installation, reverse the removal procedure.

EAS23420

## REMOVING THE DRIVE CHAIN

1. Stand the vehicle on a level surface.

EWA13120

### WARNING

**Securely support the vehicle so that there is no danger of it falling over.**

#### NOTE:


Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Remove:

- Drive sprocket nut “1”
- Lock washer “2”

#### NOTE:

- Straighten the lock washer tab.
- Operate the rear brake, and loosen the drive sprocket.
- After loosening the drive sprocket, remove the rear wheel and swingarm.



3. Remove:


- Swingarm
- Refer to “SWINGARM” on page 4-54.

EAS23441


## CHECKING THE DRIVE CHAIN

1. Measure:

- 15-link section “a” of the drive chain
- Out of specification → Replace the drive chain.


	<b>15-link length limit</b> 191.5 mm (7.54 in)
---	---

a. Measure the length “a” between the inner sides of the pins and the length “b” between the outer sides of the pins on a 15-link section of the drive chain as shown in the illustration.



b. Calculate the length “c” of the 15-link section, push down on the drive chain to increase its tension.

Drive chain 15-link section length “c” = (length “a” between pin inner sides + length “b” between pin outer sides)/2




#### NOTE:

- When measuring a 15-link section of the drive chain, make sure that the drive chain is taut.
- Perform this procedure 2–3 times, at a different location each time.

2. Check:

- Drive chain
- Stiffness → Clean, lubricate, or replace.



3. Clean:

- Drive chain



a. Wipe the drive chain with a clean cloth.

- b. Put the drive chain in kerosene and remove any remaining dirt.
- c. Remove the drive chain from the kerosene and completely dry it.


EC3C51003

**CAUTION:**


This vehicle has a drive chain with small rubber O-rings "1" between the drive chain side plates. Steam cleaning, high-pressure washing, certain solvents, and the use of a coarse brush can damage these O-rings.



4. Check:
  - O-rings "1"  
Damage → Replace the drive chain.
  - Drive chain rollers "2"  
Damage/wear → Replace the drive chain.
  - Drive chain side plates "3"  
Damage/wear → Replace the drive chain.  
Cracks → Replace the drive chain.



5. Lubricate:
  - Drive chain



**Recommended lubricant**  
Engine oil or chain lubricant  
suitable for O-ring chains

EAS23460

**CHECKING THE DRIVE SPROCKET**

1. Check:
  - Drive sprocket  
Refer to "CHECKING AND REPLACING THE REAR WHEEL SPROCKET" on page 4-10.

EAS23490

**INSTALLING THE DRIVE CHAIN**

1. Lubricate:
  - Drive chain




**Recommended lubricant**  
Engine oil or chain lubricant  
suitable for O-ring chains

2. Install:
  - Drive chain
  - Drive sprocket "1"
  - Lock washer "2" **New**
  - Drive sprocket nut "3"  
(temporarily)

**NOTE:**

While applying the drive sprocket, tighten the drive sprocket nut.




3. Install:
  - Swingarm  
Refer to "SWINGARM" on page 4-54.
  - Rear wheel  
Refer to "REAR WHEEL" on page 4-8.
4. Install:
  - Lock washer "1"
  - Drive sprocket "2"



**Drive sprocket nut**  
110 Nm (11.0 m•kg, 80 ft•lb)

**NOTE:**

- Tighten the drive sprocket nut by applying the rear drive.
- Be sure to bend the lock washer tab along to the nut side face.



5. Adjust:

- Drive chain slack

Refer to “ADJUSTING THE DRIVE CHAIN SLACK” on page 3-20



**Drive chain slack**  
40.0–45.0 mm (1.57–1.77 in)

ECA13550

**CAUTION:**

**A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swing-arm or cause an accident. Therefore, keep the drive chain slack within the specified limits.**



---

# ENGINE

<b>ENGINE REMOVAL</b> .....	<b>5-1</b>
INSTALLING THE ENGINE .....	5-4
INSTALLING THE SHIFT PEDAL .....	5-4
<b>CYLINDER HEAD</b> .....	<b>5-6</b>
REMOVING THE CYLINDER HEAD .....	5-8
CHECKING THE CYLINDER HEAD .....	5-9
CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER .....	5-9
CHECKING THE CAMSHAFT SPROCKET AND TIMING CHAIN GUIDE (EXHAUST SYSTEM SIDE) .....	5-9
CHECKING THE TIMING CHAIN TENSIONER .....	5-10
INSTALLING THE CYLINDER HEAD .....	5-10
<b>CAMSHAFT</b> .....	<b>5-13</b>
REMOVING THE ROCKER ARMS AND CAMSHAFT .....	5-14
CHECKING THE CAMSHAFT .....	5-14
CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS .....	5-15
INSTALLING THE CAMSHAFT AND ROCKER ARMS .....	5-15
<b>VALVES AND VALVE SPRINGS</b> .....	<b>5-17</b>
REMOVING THE VALVES .....	5-18
CHECKING THE VALVES AND VALVE GUIDES .....	5-18
CHECKING THE VALVE SEATS .....	5-20
CHECKING THE VALVE SPRINGS .....	5-21
INSTALLING THE VALVES .....	5-23
<b>CYLINDER AND PISTON</b> .....	<b>5-25</b>
REMOVING THE PISTON .....	5-26
CHECKING THE CYLINDER AND PISTON .....	5-26
CHECKING THE PISTON RINGS .....	5-27
CHECKING THE PISTON PIN .....	5-28
INSTALLING THE PISTON AND CYLINDER .....	5-28
<b>CLUTCH</b> .....	<b>5-30</b>
REMOVING THE CLUTCH .....	5-33
CHECKING THE FRICTION PLATES .....	5-33
CHECKING THE CLUTCH PLATES .....	5-33
CHECKING THE CLUTCH SPRINGS .....	5-33
CHECKING THE CLUTCH HOUSING .....	5-34
CHECKING THE CLUTCH BOSS .....	5-34
CHECKING THE PRESSURE PLATE .....	5-34
CHECKING THE CLUTCH PUSH RODS .....	5-34
CHECKING THE PRIMARY DRIVE GEAR .....	5-34
CHECKING THE PRIMARY DRIVEN GEAR .....	5-34
INSTALLING THE CLUTCH .....	5-34


---

<b>OIL PUMP AND BALANCER GEAR .....</b>	<b>5-38</b>
REMOVING THE BALANCER GEAR .....	5-40
CHECKING THE OIL PUMP .....	5-40
CHECKING THE OIL STRAINER .....	5-40
ASSEMBLING THE OIL PUMP .....	5-41
INSTALL THE OIL PUMP AND BALANCER GEAR .....	5-41
<b>SHIFT SHAFT .....</b>	<b>5-43</b>
CHECKING THE SHIFT SHAFT .....	5-44
CHECKING THE STOPPER LEVER .....	5-44
INSTALLING THE SHIFT SHAFT .....	5-44
<b>GENERATOR AND STARTER CLUTCH .....</b>	<b>5-45</b>
REMOVING THE GENERATOR .....	5-47
REMOVING THE STARTER CLUTCH .....	5-47
CHECKING THE STARTER CLUTCH .....	5-47
INSTALLING THE STARTER CLUTCH .....	5-48
INSTALLING THE GENERATOR .....	5-48
<b>ELECTRIC STARTER .....</b>	<b>5-50</b>
CHECKING THE STARTER MOTOR .....	5-52
ASSEMBLING THE STARTER MOTOR .....	5-53
<b>CRANKCASE .....</b>	<b>5-54</b>
DISASSEMBLING THE CRANKCASE .....	5-56
CHECKING THE CRANKCASE .....	5-56
CHECKING THE TIMING CHAIN, CRANKSHAFT SPROCKET, TIMING CHAIN GUIDE (INTAKE SIDE) .....	5-56
CHECKING THE BEARING AND OIL SEAL .....	5-56
ASSEMBLING THE CRANKCASE .....	5-56
<b>CRANKSHAFT ASSEMBLY .....</b>	<b>5-58</b>
REMOVING THE CRANKSHAFT ASSEMBLY .....	5-59
CHECKING THE CRANKSHAFT AND CONNECTING ROD .....	5-59
INSTALLING THE CRANKSHAFT ASSEMBLY .....	5-59
<b>TRANSMISSION .....</b>	<b>5-61</b>
CHECKING THE SHIFT FORKS .....	5-63
CHECKING THE SHIFT DRUM ASSEMBLY .....	5-63
CHECKING THE TRANSMISSION .....	5-63
INSTALLING THE SHIFT FORKS AND SHIFT DRUM ASSEMBLY .....	5-64

EAS23710

## ENGINE REMOVAL


### Removing the exhaust pipe



Order	Job/Parts to remove	Q'ty	Remarks
	Rear right side cover		Refer to "GENERAL CHASSIS" on page 4-1.
1	Muffler	1	
2	Exhaust pipe	1	
3	Exhaust pipe gasket	1	
			For installation, reverse the removal procedure.

# ENGINE REMOVAL


## Removing the shift pedal assembly and leads and hoses



Order	Job/Parts to remove	Q'ty	Remarks
	Carburetor		Refer to "CARBURETOR" on page 6-3.
	Drive sprocket		Refer to "CHAIN DRIVE" on page 4-57.
	Starter motor		Refer to "ELECTRIC STARTER" on page 5-50.
1	Cylinder head breather hose	1	Disconnect.
2	Spark plug cap	1	Disconnect.
3	Clutch cable	1	Disconnect.
4	Pickup coil coupler/stator assembly coupler	1/1	Disconnect.
5	Speed sensor coupler	1	Disconnect.
6	Horn	1	
7	Shift pedal assembly	1	
8	Neutral switch lead	1	Disconnect.
			For installation, reverse the removal procedure.

# ENGINE REMOVAL

## Removing the engine



Order	Job/Parts to remove	Q'ty	Remarks
			<b>NOTE:</b> _____ Use an appropriate vehicle stand and support the engine securely.
	Drain the engine oil		Refer to "CHANGING THE ENGINE OIL" on page 3-11.
1	Engine mounting bolt (upper side)	1	
2	Engine bracket bolt	2	
3	Right engine bracket	1	
4	Left engine bracket	1	
5	Engine mounting bolts (front upper side)	1	
6	Engine mounting bolt (front lower side)	1	
7	Down tube bolts (front side)	2	
8	Down tube bolts (rear side)	1	
9	Down tube	1	
10	Engine mounting bolt (rear lower side)	1	
11	Engine mounting bolt (rear upper side)	1	
12	Engine assembly	1	
			For assembly, reverse the removal procedure.

# ENGINE REMOVAL

EAS23720


## INSTALLING THE ENGINE

### 1. Install:

- Engine assembly “1”
- Engine mounting bolt (rear upper side)“2”
- Engine mounting bolt (rear lower side)“3”
- Down tube “4”
- Down tube bolt (Rear)“5”
- Down tube bolt (Front)“6”
- Engine mounting bolt (front lower side)“7”
- Engine mounting bolts (front upper side)“8”
- Left engine bracket “9”
- Right engine bracket “10”
- Engine bracket bolt “11”
- Engine mounting bolt (upper side)“12”


### NOTE:

The bolts and nuts must be tightened temporarily in this stage.(Temporarily tighten)




### 2. Tighten:


- Engine mounting nut (rear upper)




- Engine mounting nut (rear lower)




- Down tube nut (rear)




- Down tube nut (front)




- Engine mounting nut (front upper)




- Engine mounting nut (front upper)



- Engine bracket nut



- Engine mounting nut (upper)




EAS3C51004

## INSTALLING THE SHIFT PEDAL


### 1. Install:

- Shift pedal assembly “1”



### NOTE:

Align mark “a” of the shift shaft with mark “b” of the shift arm.



### 2. Adjust:

- Shift pedal position

### NOTE:


Loosen the lock nut “1” and turn shift rod “2” so that height “a” from the footrest to the shift pedal top face comes within 16 to 22 mm (0.63 to 0.79

# ENGINE REMOVAL

in). When this adjustment is complete, tighten the locknut "1".



**Locknut**  
**10 Nm (1.0 m•kg, 7.2 ft•lb)**




# CYLINDER HEAD

EAS24100

## CYLINDER HEAD

### Removing the cylinder head




Order	Job/Parts to remove	Q'ty	Remarks
	Tool box		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 6-1.
	Left engine bracket/Right engine bracket		Refer to "ENGINE REMOVAL" on page 5-1.
1	Spark plug	1	
2	Timing mark accessing screw	1	
3	Crankshaft end cover	1	
4	Camshaft sprocket cover	1	
5	Breather plate	1	
6	Breather plate gasket	1	
7	Intake tappet cover	1	
8	Exhaust tappet cover	1	
9	Camshaft sprocket bolt	1	
10	Timing chain tensioner	1	
11	Timing chain tensioner gasket	1	
12	Camshaft sprocket plate	1	
13	Camshaft sprocket	1	
14	Dowel pin	1	
15	Intake manifold	1	



# CYLINDER HEAD

## Removing the cylinder head



Order	Job/Parts to remove	Q'ty	Remarks
16	Air induction system pipe	1	
17	Air induction system pipe gasket	1	
18	Cylinder head	1	
19	Cylinder head gasket	1	
20	Dowel pin	2	
21	Timing chain guide (exhaust side)	1	
			For installation, reverse the removal procedure.

# CYLINDER HEAD


EAS24130

## REMOVING THE CYLINDER HEAD

1. Disconnect:
  - Wire harness

**NOTE:** \_\_\_\_\_

Disconnect the wire harness from the T-stud of vehicle frame.




2. Align:

- Mark "a" of the camshaft sprocket (with mark "b" of the cylinder head)




- a. Turn the crankshaft counterclockwise.
- b. When the piston is in the compression stroke, align camshaft sprocket mark "a" with cylinder head mark "b". (Compression stroke TDC)



**NOTE:** \_\_\_\_\_


Make sure that generator rotor mark "c" aligns with generator rotor cover mark "d".



3. Loosen:
  - Camshaft sprocket bolt

**NOTE:** \_\_\_\_\_

Tighten the generator rotor bolts but loosen the camshaft sprocket bolts using a wrench.




4. Remove:

- Timing chain tensioner (along with the gasket)
- Camshaft sprocket plate
- Camshaft sprocket

**NOTE:** \_\_\_\_\_

To prevent the timing chain from falling into the crankcase, fasten it with a wire.




5. Remove:

- Cylinder head

**NOTE:** \_\_\_\_\_

- Loosen the cylinder head bolts in the correct sequence as shown.
- Loosen each cylinder head bolt for a half turn at a time. When all cylinder head bolts are fully loosened, remove them.



EAS24160

## CHECKING THE CYLINDER HEAD


### 1. Eliminate:

- Combustion chamber carbon deposits (with a rounded scraper)

### NOTE:

Do not use a sharp instrument to avoid damaging or scratching:

- Spark plug bore threads
- Valve seats



### 2. Check:

- Cylinder head  
Damage/scratches → Replace.

### 3. Measure:

- Cylinder head warpage  
Out of specification → Resurface the cylinder head.




**Warpage limit**  
**0.03 mm (0.0012 in)**

- Place a straightedge "1" and a thickness gauge "2" across the cylinder head.
- Measure the warpage.
- If the limit is exceeded, resurface the cylinder head as follows.
- Place a 400–600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

### NOTE:

To ensure an even surface, turn the cylinder

head several times.



- When the cylinder head warpage is out of specification after resurfacing, replace the cylinder head.



EAS23940

## CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER

The following procedure applies to both of the tappet covers and O-rings.

### 1. Check:

- Tappet cover
- Camshaft sprocket cover


EAS3C51005

## CHECKING THE CAMSHAFT SPROCKET AND TIMING CHAIN GUIDE (EXHAUST SYSTEM SIDE)

Check the camshaft sprocket and the timing chain guide (exhaust system side) as follows.

### 1. Check:

- Camshaft sprocket  
Wear of 1/4 or more teeth "a" → Replace the camshaft sprocket as a set, timing chain, and crankshaft sprocket.



- a. 1/4 tooth wear
- b. Normal

- 1. Timing chain
- 2. Camshaft sprocket

# CYLINDER HEAD

2. Check:
  - Timing chain guide (exhaust side)  
Crack/wear → Replace.

EAS24200

## CHECKING THE TIMING CHAIN TENSIONER


1. Check:
  - Timing chain tensioner  
Cracks/damage/rough movement → Replace.



- a. Lightly press the timing chain tensioner rod into the timing chain tensioner housing by hand.

**NOTE:** While pressing the timing chain tensioner rod, wind it clockwise with a thin screwdriver "1" until it stops.


- b. Remove the screwdriver and slowly release the timing chain tensioner rod.
- c. Make sure that the timing chain tensioner rod comes out of the timing chain tensioner housing smoothly. If there is rough movement, replace the timing chain tensioner.



EAS24230


## INSTALLING THE CYLINDER HEAD

1. Install:
  - Cylinder head
  - Cylinder head bolts (226 mm)
  - Cylinder head bolts (45 mm)

	<b>Cylinder head bolt (226 mm) 22 Nm (2.2 m•kg, 16 ft•lb) Cylinder head bolt (45 mm) 20 Nm (2.0 m•kg, 15 ft•lb)</b>
---	---

**NOTE:** Apply an engine oil to the seating face of cylinder head bolt (226-mm long), and apply a molybdenum disulfide oil to the bolt threads.


- Tighten the cylinder head bolts in two stages in the correct sequence as shown.



2. Install:
  - Dowel pin
  - Camshaft sprocket
  - Timing chain



- a. Make sure that generator rotor mark "a" aligns with generator rotor cover mark "b". If not, align them by turning the crankshaft counterclockwise.




- b. Align camshaft sprocket mark "c" with cylinder head mark "d".
- c. Install the timing chain onto the camshaft sprocket, and then install the camshaft sprocket onto the camshaft.

**NOTE:** When installing the camshaft sprocket, be sure to keep the timing chain as tight as possible on the exhaust side. Align the dowel pin with the slot of camshaft sprocket. Assemble the camshaft sprocket by facing its die stamp outward of the vehicle.

ECA13770

**CAUTION:** Do not turn the crankshaft when installing the camshaft sprockets to avoid damage or improper valve.



- d. While holding the camshafts, temporarily tighten the camshaft sprocket bolts.
- e. Remove the wire from the timing chain.




3. Install:
- Timing chain tensioner



- a. Push down the timing chain tensioner rod end by your finger, and fully wind up the tensioner clockwise using a small flat-blade screwdriver "1".

**NOTE:**

The timing chain tensioner rod must be held by the flat-blade screwdriver until the timing chain tensioner bolt is tightened.




- b. Assemble the timing chain tensioner and the gasket in the cylinder.

	<b>Timing chain tensioner bolt</b> 10 Nm (1.0 m•kg, 7.2 ft•lb)
--	---

- c. Install the gasket and timing chain tensioner cap bolt.

	<b>Timing chain tensioner cap bolt</b> 8 Nm (0.8 m•kg, 5.8 ft•lb)
--	--



- 4. Tighten:
  - Camshaft sprocket bolts

	<b>Camshaft sprocket bolt</b> 60 Nm (6.0 m•kg, 43 ft•lb)
--	---

ECA13750


**CAUTION:**


Be sure to tighten the camshaft sprocket bolts to the specified torque to avoid the possibility of the bolts coming loose and damaging the engine.

**NOTE:**

Secure the generator rotor bolts and tighten the camshaft sprocket bolts using a wrench.

- 5. Turn:
  - Crankshaft (several turns counterclockwise)
- 6. Check:
  - Mark "a"
  - Make sure that generator rotor mark "a" aligns with generator rotor cover mark "b".
  - Mark "c"
  - Make sure that camshaft sprocket mark "c" aligns with cylinder head mark "d".
  - Not aligned → Reassemble.
  - See the following assembling procedure.





7. Measure:

- Bulb clearance


Out of specification → Adjust.

Refer to “ADJUSTING THE VALVE CLEAR-  
ANCE” on page 3-5.

EAS3C51006

## CAMSHAFT

### REMOVING THE ROCKER ARMS AND CAMSHAFT




Order	Job/Part	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-6.
1	Camshaft retainer	1	
2	Camshaft	1	
3	Intake rocker arm shaft	1	
4	Rocker arm	2	
5	Exhaust rocker arm shaft	1	
6	Locknut	2	
7	Valve clearance adjusting screws	2	
			For installation, reverse the removal procedure.

EAS23770

## REMOVING THE ROCKER ARMS AND CAMSHAFT


1. Loosen:
  - Locknuts "1"
  - Valve clearance adjusting screws "2"
2. Remove:
  - Camshaft retainer "3"



3. Remove:
  - Camshaft "1"

### NOTE:

- Screw 10-mm bolt "2" into the threaded end of the camshaft and then pull out the camshaft.
- Take care not to interfere and damage the rocker arm.




4. Remove:
  - Intake rocker arm shaft
  - Exhaust rocker arm shaft
  - Rocker arm (Intake and exhaust sides)

### NOTE:

Remove the rocker arm using the weight "1" and slide hammer bolt "2".



**Slide hammer bolt**  
 90890-01083  
**Slide hammer bolt 6 mm**  
 YU-01083-1  
**Weight**  
 90890-01084  
 YU-01083-3



EAS23840

## CHECKING THE CAMSHAFT

1. Check:
  - Camshaft lobes  
 Blue discoloration/pitting/scratches → Replace the camshaft.
2. Measure:
  - Camshaft lobe dimensions "a" and "b"  
 Out of specification → Replace the camshaft.



### Camshaft lobe dimension limit

#### Intake A

36.520–36.620 mm  
 (1.4378–1.4417 in)

#### Limit

36.460 mm (1.4354 in)

#### Intake B

30.201–30.301 mm  
 (1.1890–1.1930 in)

#### Limit

30.151 mm (1.1870 in)

#### Exhaust A

36.564–36.664 mm  
 (1.4395–1.4435 in)

#### Limit


36.514 mm (1.4376 in)

#### Exhaust B


30.216–30.316 mm  
 (1.1896–1.1935 in)

#### Limit

30.166 mm (1.1876 in)








3. Check:
  - Camshaft oil passage  
Obstruction → Blow out with compressed air.


EAS23880

## CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS

The following procedure applies to all of the rocker arms and rocker arm shafts.

1. Check:
  - Rocker arm  
Damage/wear → Replace.
2. Check:
  - Rocker arm shaft  
Blue discoloration/excessive wear/pitting/scratches → Replace or check the lubrication system.
3. Measure:
  - Rocker arm inside diameter "a"  
Out of specification → Replace.


	<p><b>Rocker arm inside diameter</b> 12.000–12.018 mm (0.4724–0.4731 in) <b>Limit</b> 12.036 mm (0.4739 in)</p>
---	---



4. Measure:
  - Rocker arm shaft outside diameter "a"  
Out of specification → Replace.



<p><b>Rocker arm shaft outside diameter</b> 11.981–11.991 mm (0.4717–0.4721 in) <b>Limit</b> 11.950 mm (0.4705 in)</p>
--



5. Calculate:
  - Rocker-arm-to-rocker-arm-shaft clearance

### NOTE:

Calculate the clearance by subtracting the rocker arm shaft outside diameter from the rocker arm inside diameter.

Out of specification → Replace the defective part(s).



<p><b>Rocker-arm-to-rocker-arm-shaft clearance</b> 0.009–0.037 mm (0.0004–0.0015 in)</p>
--

EAS24040

## INSTALLING THE CAMSHAFT AND ROCKER ARMS

1. Lubricate:
  - Rocker arm
  - Rocker arm shafts




<p><b>Recommended lubricant</b> Rocker arm Molybdenum-disulfide oil Rocker arm shaft Engine oil</p>
---

2. Install:
  - Exhaust rocker arm "1"
  - Exhaust rocker arm shaft "2"

### NOTE:

The exhaust rocker arm shaft must be inserted into the cylinder head completely.

# CAMSHAFT



**NOTE:**



Assemble the camshaft by inserting the 10-mm bolt into the camshaft hole and tightening it.

3. Install:

- Intake rocker arm
- Intake rocker arm shaft


**NOTE:**

- Insert cylinder head bolt “1” (226-mm long) into the cylinder head bolt hole.
- Keep slot “a” of intake rocker arm shaft in horizontal direction, align slot “b” of the shaft end with the cylinder head bolt hole, and assemble the camshaft.



4. Lubricate:

- Camshaft

	<b>Recommended lubricant</b>
	<b>Camshaft</b>
	<b>Molybdenum-disulfide oil</b>
	<b>Camshaft bearing</b>
	<b>Engine oil</b>

5. Install:


- Camshaft

# VALVES AND VALVE SPRINGS

EAS24270

## VALVES AND VALVE SPRINGS

### Removing the valves and valve springs



Order	Job/Parts to remove	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-6.
	Rocker arm/Camshaft		Refer to "CAMSHAFT" on page 5-13.
1	Valve cotter	4	
2	Valve spring retainer	2	
3	Outer valve spring	2	
4	Inner valve spring	2	
5	Intake valve	1	
6	Exhaust valve	1	
7	Valve stem seal	2	
8	Valve spring seat	2	
9	Valve guide	2	
			For installation, reverse the removal procedure.

# VALVES AND VALVE SPRINGS

EAS24280

## REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

**NOTE:** \_\_\_\_\_

Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.

1. Check:

- Valve sealing

Leakage at the valve seat → Check the valve face, valve seat, and valve seat width.

Refer to “CHECKING THE VALVE SEATS” on page 5-20.




a. Pour a clean solvent “a” into the intake and exhaust ports.

b. Check that the valves properly seal.

**NOTE:** \_\_\_\_\_

There should be no leakage at the valve seat “1”.




2. Remove:

- Valve cotters “1”

**NOTE:** \_\_\_\_\_

Remove the valve cotters by compressing the valve spring with the valve spring compressor “2”.

	<p><b>Valve spring compressor</b> 90890-04019 YM-04019</p>
---	--




3. Remove:

- Valve spring retainer “1”
- Outer valve spring “2”
- Inner valve spring “3”
- Valve “4”
- Valve stem seal “5”
- Valve spring seat “6”

**NOTE:** \_\_\_\_\_

Identify the position of each part very carefully so that it can be reinstalled in its original place.



EAS24290

## CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

1. Measure:

- Valve-stem-to-valve-guide clearance  
Out of specification → Replace the valve guide.

<p><b>Valve-stem-to-valve-guide clearance =</b> Valve guide inside diameter “a” - Valve stem diameter “b”</p>
---

# VALVES AND VALVE SPRINGS



**Valve-stem-to-valve-guide clearance**

**Valve-stem-to-valve-guide clearance (intake)**  
0.010–0.037 mm (0.0004–0.0015 in)

**Limit**



0.080 mm (0.0032 in)

**Valve-stem-to-valve-guide clearance (exhaust)**

0.025–0.052 mm (0.0010–0.0020 in)

**Limit**

0.100 mm (0.0039 in)




2. Replace:
- Valve guide

**NOTE:**


To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100°C (212°F) in an oven.




- a. Remove the valve guide with the valve guide remover “1”.



- b. Install the new valve guide with the valve guide installer “2” and valve guide remover “1”.



- c. After installing the valve guide, bore the valve guide with the valve guide reamer “3” to obtain the proper valve-stem-to-valve-guide clearance.



**NOTE:**

After replacing the valve guide, reface the valve seat.


# VALVES AND VALVE SPRINGS



**Valve guide remover ( $\phi 6$ )**  
**90890-04064**  
**Valve guide remover (6.0 mm)**  
**YM-04064-A**  
**Valve guide installer ( $\phi 6$ )**  
**90890-04065**  
**Valve guide installer (6.0 mm)**  
**YM-04065-A**  
**Valve guide reamer ( $\phi 6$ )**  
**90890-04066**  
**Valve guide reamer (6.0 mm)**  
**YM-04066**




**Valve stem runout**  
**Valve stem runout**  
**0.030 mm (0.0012 in)**



3. Eliminate:
  - Carbon deposits  
(from the valve face and valve seat)
4. Check:
  - Valve face  
Pitting/wear → Grind the valve face.
  - Valve stem end  
Mushroom shape or diameter larger than the body of the valve stem → Replace the valve.
5. Measure:
  - Valve margin thickness “a”  
Out of specification → Replace the valve.



**Valve margin thickness**  
**Valve margin thickness D (intake)**  
**0.80–1.20 mm (0.0315–0.0472 in)**  
**Valve margin thickness D (exhaust)**  
**0.80–1.20 mm (0.0315–0.0472 in)**



EAS24300


## CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.

1. Eliminate:
  - Carbon deposits  
(from the valve face and valve seat)
2. Check:
  - Valve seat  
Pitting/wear → Replace the cylinder head.
3. Measure:
  - Valve seat width “a”  
Out of specification → Replace the cylinder head.



**Limit of valve seat width (IN)**  
**1.7 mm**  
**Limit of valve seat width (EX)**  
**1.7 mm**



6. Measure:
  - Valve stem runout  
Out of specification → Replace the valve.


### NOTE:

- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the oil seal.



- a. Apply Mechanic’s blueing dye (Dykem) “b” onto the valve face.

# VALVES AND VALVE SPRINGS



- b. Install the valve into the cylinder head.
- c. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- d. Measure the valve seat width.

**NOTE:** \_\_\_\_\_  
 Where the valve seat and valve face contacted one another, the blueing will have been removed.



4. Lap:
- Valve face
  - Valve seat


**NOTE:** \_\_\_\_\_  
 After replacing the cylinder head or replacing the valve and valve guide, the valve seat and valve face should be lapped.



- a. Apply a coarse lapping compound "a" to the valve face.

ECA13790

**CAUTION:** \_\_\_\_\_  
**Do not let the lapping compound enter the gap between the valve stem and the valve guide.**




- b. Apply molybdenum disulfide oil onto the valve stem.
- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve


seat are evenly polished, then clean off all of the lapping compound.

**NOTE:** \_\_\_\_\_  
 For the best lapping results, lightly tap the valve seat while turning the valve back and forth between your hands.

- e. Apply a fine lapping compound to the valve face and repeat the above steps.
- f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.
- g. Apply Mechanic's blueing dye (Dykem) "b" onto the valve face.



- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width "c" again. If the valve seat width is out of specification, reface and lap the valve seat.



EAS24310

## CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.


- 1. Measure:
  - Valve spring free length "a"  
 Out of specification → Replace the valve spring.

# VALVES AND VALVE SPRINGS




## Valve spring free length

**Inner spring**  
 Free length (intake)  
 36.17 mm (1.42 in)  
 Free length (exhaust)  
 36.17 mm (1.42 in)  
**Outer spring**  
 Free length (intake)  
 36.63 mm (1.44 in)  
 Free length (exhaust)  
 36.63 mm (1.44 in)



### 2. Measure:

- Compressed valve spring force "1"  
Out of specification → Replace the valve spring.



- a. Compressed valve spring force
- b. Installed length




**Inner spring**  
 Installed compression spring force (intake)  
 75.00–91.70 N (16.86–20.61 lbf)  
 (7.65–9.35 kgf)  
 Installed length (intake)  
 30.50 mm (1.20 in)  
 Installed compression spring force (exhaust)  
 75.00–91.70 N (16.86–20.61 lbf)  
 (7.65–9.35 kgf)  
 Installed length (exhaust)  
 30.50 mm (1.20 in)  
**Outer spring**  
 Installed compression spring force (intake)  
 128.50–157.90 N (28.89–35.50 lbf)  
 (13.10–16.10 kgf)  
 Installed length (intake)  
 32.00 mm (1.26 in)  
 Installed compression spring force (exhaust)  
 128.50–157.90 N (28.89–35.50 lbf)  
 (13.10–16.10 kgf)  
 Installed length (exhaust)  
 32.00 mm (1.26 in)

### 3. Measure:

- Valve spring tilt "a"  
Out of specification → Replace the valve spring.



**Spring tilt limit**  
**Inner spring**  
 Spring tilt (intake)  
 2.5 °/1.6 mm  
 Spring tilt (exhaust)  
 2.5 °/1.6 mm  
**Outer spring**  
 Spring tilt (intake)  
 2.5 °/1.6 mm  
 Spring tilt (exhaust)  
 2.5 °/1.6 mm





# VALVES AND VALVE SPRINGS


EAS24340

## INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.



### 1. Deburr:

- Valve stem end  
(with an oil stone)



### 2. Lubricate:

- Valve stem "1"
- Valve stem seal "2"  
(with the recommended lubricant)





### 3. Install:

- Valve spring seat "1"
- Valve stem seal "2" **New**
- Valve "3"
- Inner valve spring "4"
- Outer valve spring "5"
- Valve spring retainer "6"  
(on to the cylinder cylinder head)

#### NOTE:

- Make sure each valve is installed in its original place. Refer to the following embossed marks.  
Intake valve: "5HO."  
Exhaust valve: "5BP"
- Install the valve springs with the larger pitch "a" facing up.




- a. Larger pitch
- b. Smaller pitch

### 4. Install:

- Valve cotters "1"

#### NOTE:

Install the valve cotters by compressing the valve spring with the valve spring compressor "2".



- 5. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.


ECA13800

#### CAUTION:

Hitting the valve tip with excessive force could damage the valve.

# VALVES AND VALVE SPRINGS

---




# CYLINDER AND PISTON

EAS24350

## CYLINDER AND PISTON

### Removing the cylinder and piston



Order	Job/Parts to remove	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-6.
1	Cylinder	1	
2	Dowel pin	2	
3	Cylinder gasket	1	
4	Oil delivery pipe	1	
5	Piston pin clip	2	
6	Piston pin	1	
7	Piston	1	
8	Top ring	1	
9	2nd ring	1	
10	Upper oil ring rail	1	
11	Lower oil ring rail	1	
12	Oil ring expander	1	
			For installation, reverse the removal procedure.

# CYLINDER AND PISTON

EAS24380

## REMOVING THE PISTON

1. Remove:
  - Piston pin clips "1"
  - Piston pin "2"
  - Piston "3"


ECA13810

### CAUTION:

**Do not use a hammer to drive the piston pin out.**

### NOTE:


- Before removing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.
- Before removing the piston pin, deburr the piston pin clip's groove and the piston's pin bore area.



2. Remove:
  - Top ring
  - 2nd ring
  - Oil ring

### NOTE:

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.



EAS24390

## CHECKING THE CYLINDER AND PISTON

1. Check:
  - Piston wall
  - Cylinder wall


Vertical scratches → Rebore or replace the cylinder, and replace the piston and piston rings as a set.

2. Measure:
  - Piston-to-cylinder clearance

- a. Measure cylinder bore "C" with the cylinder bore gauge.

### NOTE:

Measure cylinder bore "C" by taking side-to-side and front-to-back measurements of the cylinder. Then, find the average of the measurements.




	<b>Bore</b>
	74.000–74.0μ16 mm (2.9134–2.9140 in)
	<b>Wear limit</b>
	74.100 mm (2.9173 in)
	<b>Taper limit</b>
0.050 mm (0.0020 in)	
<b>Out of round limit</b>	
0.010 mm (0.0004 in)	

"C" = maximum of D <sub>1</sub> –D <sub>2</sub>
"T" = maximum of D <sub>1</sub> or D <sub>2</sub> - maximum of D <sub>5</sub> or D <sub>6</sub>
"R" = maximum of D <sub>1</sub> , D <sub>3</sub> or D <sub>5</sub> - maximum of D <sub>2</sub> , D <sub>4</sub> or D <sub>6</sub>

- b. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter D "a" with the micrometer.

# CYLINDER AND PISTON



- a. Piston skirt diameter
- b. 11 mm (0.43 in) from the bottom edge of the piston

**Diameter D**  
**73.983–73.998 mm**  
**(2.9127–2.9133 in)**

- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

**Piston-to-cylinder clearance =**  
**Cylinder bore “C” -**  
**Piston skirt diameter “D”**

**Piston-to-cylinder clearance**  
**0.010–0.025 mm (0.0004–0.0010 in)**  
**Limit**  
**0.15 mm (0.0059 in)**

- f. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.




EAS24430

## CHECKING THE PISTON RINGS

1. Measure:
  - Piston ring side clearance
 Out of specification → Replace the piston and piston rings as a set.


**NOTE:** \_\_\_\_\_  
 Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

**Piston ring side clearance**  
**Top ring**  
**Ring side clearance**  
**0.030–0.065 mm (0.0012–0.0026 in)**  
**Limit**  
**0.115 mm (0.0045 in)**  
**2nd ring**  
**Ring side clearance**  
**0.020–0.055 mm (0.0008–0.0022 in)**  
**Limit**  
**0.115 mm (0.0045 in)**



2. Install:
  - Piston ring (into the cylinder)

**NOTE:** \_\_\_\_\_  
 Level the piston ring into the cylinder with the piston crown.





- a. 40 mm (1.57 in)

3. Measure:
  - Piston ring end gap
 Out of specification → Replace the piston ring.

**NOTE:** \_\_\_\_\_  
 The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

# CYLINDER AND PISTON

	<b>Piston ring end gap</b>
	<b>Top ring</b>
	<b>End gap (installed)</b> 0.19–0.31 mm (0.0075–0.0122 in)
	<b>Limit</b> 0.60 mm (0.0236 in)
	<b>2nd ring</b>
	<b>End gap (installed)</b> 0.30–0.45 mm (0.0118–0.0177 in)
	<b>Limit</b> 0.60 mm (0.0236 in)
	<b>Oil ring</b>
	<b>End gap (installed)</b> 0.10–0.35 mm (0.0039–0.0138 in)




- Calculate:
  - Piston-pin-to-piston-pin-bore clearance  
Out of specification → Replace the piston pin and piston as a set.


<b>Piston-pin-to-piston-pin-bore clearance</b> = <b>Piston pin bore diameter “b” -</b> <b>Piston pin outside diameter “a”</b>
--

EAS24440


## CHECKING THE PISTON PIN


- Check:
  - Piston pin  
Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.
- Measure:
  - Piston pin outside diameter “a”  
Out of specification → Replace the piston pin.

	<b>Piston pin outside diameter</b>
	<b>15.991–16.000 mm</b> (0.6296–0.6299 in)
	<b>Limit</b> 15.971 mm (0.6288 in)



- Measure:
  - Piston pin bore diameter “b”  
Out of specification → Replace the piston.

	<b>Piston pin bore inside diameter</b>
	<b>16.002–16.013 mm</b> (0.6300–0.6304 in)
	<b>Limit</b> 16.043 mm (0.6316 in)


	<b>Piston-pin-to-piston-pin-bore clearance</b>
	<b>0.002–0.022 mm (0.0001–0.0009 in)</b>

EAS24450

## INSTALLING THE PISTON AND CYLINDER

- Install:
  - Top ring “1”
  - 2nd ring “2”
  - Lower oil ring rail “3”
  - Upper oil ring rail “4”
  - Oil ring expander “5”

**NOTE:** Be sure to install the top ring and 2nd ring so that the manufacturer’s marks or numbers face up.




- Install:
  - Piston “1”
  - Piston pin “2”
  - Piston pin clips “3” **New**

**NOTE:** Apply engine oil to the piston pin.

# CYLINDER AND PISTON

- Make sure the arrow mark “a” on the piston points towards the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the clip from falling into the crankcase.

(exhaust side) through the timing chain cavity.




### 3. Lubricate:

- Piston
- Piston rings
- Cylinder  
(with the recommended lubricant)

	<b>Recommended lubricant</b> <b>Engine oil</b>
---	---

### 4. Offset:


- Piston ring end gaps



- a. Top ring
- b. Upper oil ring rail
- c. Oil ring expander
- d. Lower oil ring rail
- e. 2nd ring
- f. 20 mm (0.79 in)

### 5. Install:

- Cylinder

	<b>Cylinder bolt</b> <b>10 Nm (1.0 m•kg, 7.2 ft•lb)</b>
---	--


### NOTE:

- While compressing the piston rings with one hand, install the cylinder with the other hand.
- Pass the timing chain and timing chain guide

EAS25061

## CLUTCH


### Removing the clutch cover



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the engine oil		Refer to "CHANGING THE ENGINE OIL" on page 3-11.
	Exhaust pipe		Refer to "ENGINE REMOVAL" on page 5-1.
1	Cotter pin	1	
2	Brake pedal	1	
3	Oil filter element cover	1	
4	Oil filter element	1	
5	Oil delivery pipe	1	Disconnect.
6	Clutch cover	1	
7	Clutch cover gasket	1	
8	Dowel pin	2	
9	Gasket	1	
			For installation, reverse the removal procedure.




## Removing the clutch



Order	Job/Parts to remove	Q'ty	Remarks
1	Clutch spring	5	
2	Pressure plate	1	
3	Adjusting screw	1	
4	Push plate	1	
5	Friction plate	6	
6	Clutch plate	5	
7	Clutch damper spring	1	
8	Clutch damper spring seat	1	
9	Primary drive gear nut	1	
10	Lock washer	1	
11	Claw washer	1	
12	Clutch boss nut	1	
13	Lock washer	1	
14	Clutch boss	1	
15	Thrust washer	1	
16	Clutch housing	1	
17	Ball	1	
18	Clutch push rod	1	
19	Primary drive gear	1	
			For installation, reverse the removal procedure.

## Removing the push lever shaft



Order	Job/Parts to remove	Q'ty	Remarks
	Air cut-off valve		Refer to "AIR INDUCTION SYSTEM" on page 6-9.
	Generator rotor cover		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-45.
1	Clutch cable	1	
2	Ignition coil	1	
3	Push lever shaft	1	
4	Push lever spring	1	
5	Circlip	1	
6	Oil seal	1	
7	Bearing	1	
			For installation, reverse the removal procedure.


EAS25070

## REMOVING THE CLUTCH

1. Straighten the lock washer tab.
2. Loosen:
  - Primary drive gear nut "1"

### NOTE:


Insert aluminum plate "a" between primary drive gear "2" and primary driven gear "3", and loosen the primary drive gear nut.



3. Loosen:
  - Clutch boss nut "1"

### NOTE:

While holding the clutch boss "3" with the universal clutch holder "2", loosen the clutch boss nut.



EAS25100



## CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:
  - Friction plate  
Damage/wear → Replace the friction plates as a set.
2. Measure:
  - Friction plate thickness  
Out of specification → Replace the friction plates as a set.

### NOTE:

Measure the friction plate at four places.





EAS25110

## CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:
  - Clutch plate  
Damage → Replace the clutch plates as a set.
2. Measure:
  - Clutch plate warpage  
(with a surface plate and thickness gauge "1")  
Out of specification → Replace the clutch plates as a set.




EAS25140


## CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:
  - Clutch spring  
Damage → Replace the clutch springs as a set.
2. Measure:

- Clutch spring free length “a”  
Out of specification → Replace the clutch springs as a set.

	<b>Clutch spring free length</b>
	<b>40.10 mm (1.58 in)</b>
	<b>Limit</b>
	<b>38.10 mm (1.50 in)</b>




EAS25150

## CHECKING THE CLUTCH HOUSING

1. Check:
  - Clutch housing dogs  
Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

**NOTE:**  
Pitting on the clutch housing dogs will cause erratic clutch operation.




EAS25160

## CHECKING THE CLUTCH BOSS

1. Check:
  - Clutch boss splines  
Damage/pitting/wear → Replace the clutch boss.

**NOTE:**  
Pitting on the clutch boss splines will cause erratic clutch operation.



EAS25170


## CHECKING THE PRESSURE PLATE

1. Check:
  - Pressure plate  
Cracks/damage → Replace.

EAS25190

## CHECKING THE CLUTCH PUSH RODS

1. Check:
  - Clutch push rod
  - Adjusting screw
  - Ball  
Cracks/damage/wear → Replace the defective part(s).
2. Measure:
  - Push rod bending limit  
Out of specification → Replace.

	<b>Push rod bending limit</b>
	<b>0.500 mm (0.0197 in)</b>

EAS25200

## CHECKING THE PRIMARY DRIVE GEAR

1. Check:
  - Primary drive gear  
Damage/wear → Replace the primary drive and primary driven gears as a set.  
Excessive noise during operation → Replace the primary drive and primary driven gears as a set.

EAS25210

## CHECKING THE PRIMARY DRIVEN GEAR

1. Check:
  - Primary driven gear  
Damage/wear → Replace the primary drive and primary driven gears as a set.  
Excessive noise during operation → Replace the primary drive and primary driven gears as a set.

EAS25260



## INSTALLING THE CLUTCH

1. Install:
  - Primary drive gear “1”

- Clutch housing “2”
- Thrust washer
- Clutch boss “3”
- Lock washer “4” **New**
- Claw washer “5”
- Lock washer “6” **New**

**NOTE:**

- Assemble the primary drive gear by facing its flat face “a” toward the crankcase.
- Align lock washer projection “b” with the clutch boss slit during assembling.
- Align lock washer projection “c” with the claw washer slit during assembling.



2. Install:
  - Clutch boss nut
  - Primary drive gear nut
3. Tighten:
  - Clutch boss nut “1”




**Clutch boss nut**  
75 Nm (7.5 m•kg, 54 ft•lb)

**NOTE:**

While holding the clutch boss “3” with the universal clutch holder “2”, tighten the clutch boss nut.



**Universal clutch holder**  
90890-04086  
YM-91042




4. Tighten:
  - Primary drive gear nut “1”



**Primary drive gear nut**  
80 Nm (8.0 m•kg, 58 ft•lb)

**NOTE:**

Insert aluminum plate “a” between primary drive gear “2” and primary driven gear “3”, and tighten the primary drive gear nut.



5. Be sure to bend the lock washer tab along to the nut side face.
6. Lubricate:
  - Friction plates
  - Clutch plates (with the recommended lubricant)




**Recommended lubricant**  
Engine oil

7. Install:
  - Clutch damper spring seat “1”
  - Clutch damper spring “2”
  - Friction plates
  - Clutch plates

**NOTE:**

- Assemble the clutch damper spring seat and the clutch damper spring as shown.
- First, install the friction plate and then alternate between the clutch plates and friction plates.





**8. Install:**

- Pressure plate
- Adjusting screw
- Pressure plate
- Clutch springs

**NOTE:**

Tighten the clutch spring bolts in two stages and in a crisscross pattern.

	<p><b>Adjusting screw lock nut</b> 8 Nm (0.8 m•kg, 5.8 ft•lb)</p> <p><b>Clutch spring bolt</b> 8 Nm (0.8 m•kg, 5.8 ft•lb)</p>
---	---




**9. Check:**

- Push lever position  
Push lever mark “a” and crankcase mark “b” not aligned → Correct.

**NOTE:**

Move the push lever in the arrow direction with your fingers, and check that it feels heavier when its mark aligns.



**10. Adjust:**

- Push lever position




- Loosen the locknut “1”.
- Turn the adjusting screw “2” in or out until the marks are aligned.
- Hold the adjusting screw to prevent it from moving and then tighten the locknut to specification.

ECA13820

**CAUTION:**


**Do not overtighten the locknut since this will remove the free play between both push rods.**

	<p><b>Locknut</b> 8 Nm (0.8 m•kg, 5.8 ft•lb)</p>
---	--



**11. Install:**


- Clutch cover “1”

	<p><b>Clutch cover bolt</b> 10 Nm (1.0 m•kg, 7.2 ft•lb)</p>
---	---

**NOTE:**

Tighten the bolts diagonally.

- M6 × 25 mm bolt “2”
- M6 × 35 mm bolt “3”
- M6 × 50 mm bolt “4”
- M6 × 50 mm bolt (with gasket) “5”
- M6 × 55 mm bolt (with gasket) “6”



12.Adjust:


- Clutch cable free play  
Refer to "ADJUSTING THE CLUTCH CABLE FREE PLAY" on page 3-12.

# OIL PUMP AND BALANCER GEAR

EAS3C51007

## OIL PUMP AND BALANCER GEAR

### Removing oil pump and balancer gear





Order	Job/Part	Q'ty	Remarks
	Primary drive gear		Refer to "CLUTCH" on page 5-30.
1	Balancer driven gear nut	1	
2	Lock washer	1	
3	Buffer boss	1	
4	Balancer driven gear	1	
5	Absorber plate	1	
6	Spring	6	
7	Dowel pin	3	
8	Straight key	1	
9	Spacer	1	
10	Circlip	1	
11	Oil pump driven gear	1	
12	Oil pump assembly	1	
13	Oil pump gasket	1	
14	Balancer drive gear	1	
15	Oil strainer	1	
			For installation, reverse the removal procedure.



# OIL PUMP AND BALANCER GEAR

## Disassembling the oil pump



 7 Nm (0.7 m · kg, 5.1 ft · lb)

Order	Job/Part	Q'ty	Remarks
1	Oil pump cover	1	
2	Dowel pin	1	
3	Oil pump shaft	1	
4	Dowel pin	2	
5	Inner rotor	1	
6	Outer rotor	1	
7	Oil pump housing	1	
			For assembly, reverse the disassembly procedure.

# OIL PUMP AND BALANCER GEAR


EAS3C51008

## REMOVING THE BALANCER GEAR

1. Straighten the lock washer tab.
2. Loosen:
  - Balancer driven gear unit "1"

### NOTE:

Insert aluminum plate "a" between balancer drive gear "2" and balancer driven gear "3", and loosen the balancer driven gear nut.



3. Remove:
  - Balancer drive gear
 Refer to "CLUTCH" on page 5-30.

EAS24960

## CHECKING THE OIL PUMP

1. Check:
  - Oil pump driven gear
  - Oil pump housing
  - Oil pump housing cover
 Cracks/damage/wear → Replace the defective part(s).
2. Measure:
  - Inner-rotor-to-outer-rotor-tip clearance "a"
  - Outer-rotor-to-oil-pump-housing clearance "b"
  - Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance "c"
 Out of specification → Replace the oil pump.



Inner-rotor-to-outer-rotor-tip clearance

0.150 mm (0.0059 in)

Limit

0.200 mm (0.0079 in)

Outer-rotor-to-oil-pump-housing clearance

0.100–0.151 mm (0.0039–0.0059 in)

Limit


0.221 mm (0.0087 in)

Oil-pump-housing-to-inner-and-outer-rotor clearance

0.04–0.09 mm (0.0016–0.0035 in)

Limit

0.16 mm (0.0063 in)



1. Inner rotor
2. Outer rotor
3. Oil pump housing

3. Check:
  - Oil pump operation
 Rough movement → Repeat steps (1) and (2) or replace the defective part(s).

EAS24990

## CHECKING THE OIL STRAINER

1. Check:
  - Oil strainer
 Damage → Replace.  
 Contaminants → Clean with solvent.

# OIL PUMP AND BALANCER GEAR

EAS25000


## ASSEMBLING THE OIL PUMP

- Lubricate:
  - Inner rotor
  - Outer rotor
  - Oil pump shaft  
(with the recommended lubricant)




- Install:
  - Oil pump housing "1"
  - Dowel pin
  - Outer rotor "2"
  - Inner rotor "3"

**NOTE:** \_\_\_\_\_  
Align outer rotor mark "a" with inner rotor mark "b" and assemble them in the oil pump housing.



- Install:
  - Oil pump cover
  - Oil pump shaft
  - Dowel pin



**NOTE:** \_\_\_\_\_  
When installing the oil pump cover, align the dowel pin of oil pump shaft with the inner rotor slot.

- Check:
  - Oil pump operation  
Refer to "CHECKING THE OIL PUMP" on page 5-40.


EAS3C51009

## INSTALL THE OIL PUMP AND BALANCER GEAR

- Install:
  - Oil strainer

**NOTE:** \_\_\_\_\_  
Assemble the oil strainer in the crankcase in the

arrow direction as shown.



- Install:
  - Balancer drive gear

**NOTE:** \_\_\_\_\_  
Direct the balancer drive gear mark outward of the vehicle during assembling.

- Install:
  - Oil pump gasket **New**
  - Oil pump




ECA13890

**CAUTION:** \_\_\_\_\_  
**After tightening the bolts, make sure the oil pump turns smoothly.**

- Install:
  - Oil pump driven gear "1"

**NOTE:** \_\_\_\_\_  
Direct stamp "a" of the oil pump driven gear outward of the vehicle.





- Install:
  - Balancer driven gear "1"
  - Buffer boss "2"
  - Dowel pin "3"
  - Spring "4"  
(To driven gear)

**NOTE:** \_\_\_\_\_  
Align mark "a" of the balancer driven gear with slot "b" of the buffer boss.

## OIL PUMP AND BALANCER GEAR

- Assemble the dowel pin on the spring as shown.



9. Be sure to bend the lock washer tab along to the nut side face.

### 6. Install:

- Balancer driven gear "1"
- Lock washer **New**
- Balancer driven gear nut

### NOTE:

Align mark "a" of the balancer drive gear with mark "b" of the balancer driven gear.



### 7. Tighten:

- Primary drive gear nut  
Refer to "CLUTCH" on page 5-30.

### 8. Tighten:

- Balancer driven gear nut "1"



**Balancer driven gear nut**  
**55 Nm (5.5 m•kg, 40 ft•lb)**


### NOTE:

Insert aluminum plate "a" between balancer drive gear "2" and balancer driven gear "3", and tighten the balancer driven gear nut.

EAS25410

## SHIFT SHAFT

### Removing the shift shaft and stopper lever



Order	Job/Parts to remove	Q'ty	Remarks
	Shift pedal assembly		Refer to "ENGINE REMOVAL" on page 5-1.
	Clutch housing		Refer to "CLUTCH" on page 5-30.
1	Shift shaft assembly	1	
2	Stopper lever	1	
3	Stopper lever spring	1	
			For installation, reverse the removal procedure.

EAS25420

## CHECKING THE SHIFT SHAFT

1. Check:
  - Shift shaft
  - Shift lever
    - Bends/damage/wear → Replace.
  - Shift lever spring
    - Damage/wear → Replace.

EAS25430

## CHECKING THE STOPPER LEVER

1. Check:
  - Stopper lever
    - Bends/damage → Replace.
    - Roller turns roughly → Replace the stopper lever.

EAS25450

## INSTALLING THE SHIFT SHAFT


1. Install:
  - Stopper lever “1”
  - Stopper lever spring



**Stopper lever bolt**  
**10 Nm (1.0 kg•m)**  
**Apply locking agent (LOC-**  
**TITE®)**

### NOTE:


- Hook the ends of the stopper lever spring onto the stopper lever and the crankcase boss.
- Mesh the stopper lever with the shift drum segment assembly.



2. Install:
  - Shift shaft assembly “1”

### NOTE:


Align shaft spring “2” with stopper “3” and assemble the shift shaft assembly.



# GENERATOR AND STARTER CLUTCH

EAS3C51010


## GENERATOR AND STARTER CLUTCH



Order	Job/Parts to remove	Q'ty	Remarks
	Drain the engine oil		Refer to "CHANGING THE ENGINE OIL" on page 3-11.
	Rear left side cover		Refer to "GENERAL CHASSIS" on page 4-1.
	Drive sprocket cover		Refer to "CHAIN DRIVE" on page 4-57.
	Shift pedal assembly		Refer to "ENGINE REMOVAL" on page 5-1.
1	Pickup coil coupler/stator assembly coupler	1/1	Disconnect.
2	Starter clutch Idle gear cover	1	
3	Starter clutch idle gear1	1	
4	Starter clutch idle gear shaft1	1	
5	Generator rotor cover	1	
6	Generator rotor cover gasket	1	
7	Dowel pin	2	
8	Stator assembly	1	
9	Starter clutch idle gear2	1	
10	Starter clutch idle gear shaft2	1	
11	Generator rotor	1	
12	Woodruff key	1	
13	Starter clutch gear	1	

# GENERATOR AND STARTER CLUTCH

## Removing the generator rotor and starter clutch



Order	Job/Parts to remove	Q'ty	Remarks
14	Bearing	1	
15	Starter clutch	1	
			For installation, reverse the removal procedure.



# GENERATOR AND STARTER CLUTCH


EAS24490

## REMOVING THE GENERATOR

1. Remove:
  - Generator rotor bolt "1"
  - Washer

### NOTE:

- While holding the generator rotor "2" with the sheave holder "3", loosen the generator rotor bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



2. Remove:
  - Generator rotor "1"  
(with the flywheel puller "2" )
  - Woodruff key



ECA13880

### CAUTION:

To protect the end of the crankshaft, place an appropriate sized socket between the flywheel puller set center bolt and the crankshaft.

### NOTE:

Make sure the flywheel puller is centered over the generator rotor.




EAS24560

## REMOVING THE STARTER CLUTCH

1. Remove:
  - Starter clutch bolt "1"

### NOTE:

- While holding the generator rotor "3" with the sheave holder "2", remove the starter clutch bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



EAS24570

## CHECKING THE STARTER CLUTCH

1. Check:
  - Starter clutch rollers  
Damage/wear → Replace.
2. Check:
  - Starter clutch idle gear 1, 2
  - Starter clutch gear  
Burrs/chips/roughness/wear → Replace the defective part(s).
3. Check:
  - Starter clutch gear's contacting surfaces  
Damage/pitting/wear → Replace the starter clutch gear.
4. Check:
  - Starter clutch operation



# GENERATOR AND STARTER CLUTCH




**Generator rotor cover bolt**  
**10 Nm (1.0 m•kg, 7.2 ft•lb)**

**NOTE:**

Tighten the bolts diagonally.


- M6 × 30 mm bolt “2”
- M6 × 40 mm bolt “3”
- M6 × 45 mm bolt “4”



EAS24780

## ELECTRIC STARTER


### Removing the starter motor



Order	Job/Parts to remove	Q'ty	Remarks
	Carburetor		Refer to "CARBURETOR" on page 6-3.
	Exhaust pipe		Refer to "ENGINE REMOVAL" on page 5-1.
1	Clutch cable holder	1	
2	Starter motor lead	1	Disconnect.
3	Starter motor	1	
			For installation, reverse the removal procedure.

# ELECTRIC STARTER

## Disassembling the starter motor



Order	Job/Parts to remove	Q'ty	Remarks
1	Starter motor front cover	1	
2	Lock washer	1	
3	Armature assembly	1	
4	Starter motor yoke	1	
5	Starter motor rear cover	1	
6	Brush	2	
7	Brush spring	2	
			For assembly, reverse the disassembly procedure.



- Gear teeth  
Damage/wear → Replace the gear.
8. Check:
- Bearing
  - Oil seal  
Damage/wear → Replace the defective part(s).

EAS24800


## ASSEMBLING THE STARTER MOTOR

1. Install:

- Lock washer "1"

### NOTE:

Align the tab "a" on the brush seat with the slot "b" in the starter motor rear cover.




2. Install:

- Starter motor yoke "1"
- Starter motor front cover "2"
- Starter motor rear cover "3"

### NOTE:


Align the match marks on the starter motor yoke with the match marks on the front and starter motor rear covers.



EAS25540

## CRANKCASE

### Separating the crankcase




Order	Job/Parts to remove	Q'ty	Remarks
	Engine		Refer to "ENGINE REMOVAL" on page 5-1.
	Piston		Refer to "CYLINDER AND PISTON" on page 5-25.
	Balancer drive gear		Refer to "OIL PUMP AND BALANCER GEAR" on page 5-38.
	Shift shaft		Refer to "SHIFT SHAFT" on page 5-43.
	Generator rotor		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-45.
1	Timing chain guide (intake side)	1	
2	Timing chain	1	
3	Crankshaft sprocket	1	
4	Straight key	1	
5	Speed sensor	1	
6	Speed sensor rotor	1	
7	Neutral switch	1	
8	Right crankcase	1	
9	Dowel pin	2	
10	Left crankcase	1	
			For installation, reverse the removal procedure.



# CRANKCASE

## Removing the Bearing



Order	Job/Parts to remove	Q'ty	Remarks
	Crankshaft assembly		Refer to "CRANKSHAFT ASSEMBLY" on page 5-58.
	Main axle assembly/Drive axle assembly		Refer to "TRANSMISSION" on page 5-61.
1	Bearing retainer	1	
2	Oil seal	2	
3	Bearing	7	
			For installation, reverse the removal procedure.

# CRANKCASE

EAS25570

## DISASSEMBLING THE CRANKCASE

1. Remove:
  - Crankcase bolts


### NOTE:

Loosen each bolt 1/4 of a turn at a time, in two stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.

2. Turn:
  - Shift drum segment

### NOTE:

Turn the shift drum segment to the position shown in the illustration. In this position, the shift drum segment's teeth will not contact the crankcase during crankcase separation.



3. Remove:
  - Right crankcase

EC3C51004

### CAUTION:

- Tap on one side the crankcase with a soft-face hammer. Tap only reinforced portions of the crankcase.
- Do not damage the crankcase mating surfaces.
- Remove the crankcase right halves first.

EAS25580

## CHECKING THE CRANKCASE

1. Thoroughly wash the crankcase halves in a mild solvent.
2. Thoroughly clean all the gasket surfaces and crankcase mating surfaces.
3. Check:
  - Crankcase
    - Cracks/damage → Replace.
    - Obstruction → Blow out with compressed air.

EAS3C51011

## CHECKING THE TIMING CHAIN, CRANKSHAFT SPROCKET, TIMING CHAIN GUIDE (INTAKE SIDE)

1. Check:
  - Timing chain

Crack/stiffness → Replace the camshaft sprocket, timing chain, and crankshaft sprocket as a set.

2. Check:
  - Crankshaft sprocket
    - Refer to "CYLINDER HEAD" on page 5-6.
3. Check:
  - Timing chain guide (intake side)
    - Damage/wear → Replace.

EAS3C51012

## CHECKING THE BEARING AND OIL SEAL

1. Check:
  - Bearing
    - Abnormal sound/rough movement/looseness → Replace.
2. Check:
  - Oil seal
    - Damage/wear → Replace.

EAS25700

## ASSEMBLING THE CRANKCASE


1. Thoroughly clean all the gasket mating surfaces and crankcase mating surfaces.
2. Apply:
  - Sealant
    - (onto the crankcase mating surfaces)



**Yamaha bond No. 1215 (Three Bond No.1215®)**  
**90890-85505**

### NOTE:

Do not allow any sealant to come into contact with the oil gallery.



3. Install:
  - Right crankcase
    - (to the left crankcase)



**Crankcase bolt**  
**10 Nm (1.0 m•kg, 7.2 ft•lb)**



### NOTE:

- Turn the shift drum segment as shown so that the shift drum segment teeth do not contact the

crankcase during its assembling.

- Tighten the bolts diagonally in two (2) stages, with 1/4 turn each.

- M6 × 70 mm bolt (with gasket) "1"
- M6 × 60 mm bolt "2"
- M6 × 55 mm bolt "3"
- M6 × 45 mm bolt "4"




4. Install:

- Crankshaft sprocket "1"

**NOTE:**

Assemble the crankshaft sprocket by facing its chamfered side "a" toward the crankcase.




# CRANKSHAFT ASSEMBLY

EAS30C51013

## CRANKSHAFT ASSEMBLY

### Crankshaft assembly and balancer



Order	Job/Part	Q'ty	Remarks
	Separate the crank case.		Refer to "CRANKCASE" on page 5-54.
1	Balancer	1	
2	Crankshaft assembly	1	
3	Dowel pin	1	
4	Plunger pin	1	
5	Bearing	1	
			For installation, reverse the removal procedure.

# CRANKSHAFT ASSEMBLY

EAS26000

## REMOVING THE CRANKSHAFT ASSEMBLY


1. Remove:
  - Crankshaft assembly "1"

### NOTE:

Remove the crankshaft assembly using crankshaft separating tool "2".




**Crankcase separating tool**  
90890-01135  
**Crankcase separator**  
YU-01135-B



2. Remove:
  - Dowel pin "1"
  - Plunger pin "2"
  - Spring "3"

### NOTE:

Slightly press the plunger pin and pull out the dowel pin. Then, remove the plunger pin and the spring.



EAS3C51014

## CHECKING THE CRANKSHAFT AND CONNECTING ROD


1. Measure:
  - Crankshaft runout  
Out of specification → Replace the crankshaft assembly, bearing or both.

### NOTE:

Turn the crankshaft slowly.



**Runout limit C**  
0.030 mm (0.0012 in)



2. Measure:
  - Big end side clearance  
Out of specification → Replace the crankshaft assembly.



**Big end side clearance D**  
0.350–0.850 mm (0.0138–0.0335 in)

3. Measure:
  - Crankshaft width  
Out of specification → Replace the crankshaft assembly.



**Width A**  
69.25–69.30 mm (2.726–2.728 in)

4. Check:
  - Bearing  
Cracks/damage/wear → Replace the crankshaft assembly.
5. Check:
  - Crankshaft journal oil passage  
Obstruction → Blow out with compressed air.

EAS26210



## INSTALLING THE CRANKSHAFT ASSEMBLY

1. Install:
  - Spring "1"
  - Plunger pin "2"
  - Dowel pin "3"

### NOTE:

Press the plunger pin by your fingers, and make sure that it operates smoothly.

# CRANKSHAFT ASSEMBLY



2. Install:

- Crankshaft assembly "1"

**NOTE:**

Install the crankshaft assembly using spacer "2", adapter (M10) "3", crankshaft installer "4", and crankshaft installer bolt "5".



**Crankshaft installer pot**  
90890-01274  
**Installing pot**  
YU-90058  
**Crankshaft installer bolt**  
90890-01275  
**Bolt**  
YU-90060  
**Adapter (M10)**  
90890-01383  
**Adapter #2**  
YU-90062  
**Spacer**  
90890-01288

ECA13970

**CAUTION:**

To avoid scratching the crankshaft and to ease the installation procedure, lubricate the oil seal lips with lithium-soap-based grease and each bearing with engine oil.


**NOTE:**

Hold the connecting rod at top dead center (TDC) with one hand while turning the nut of the crankshaft installer bolt with the other. Turn the crankshaft installer bolt until the crankshaft assembly bottoms against the bearing.

EAS26241


## TRANSMISSION

Removing the transmission, shift drum assembly, and shift forks



Order	Job/Parts to remove	Q'ty	Remarks
	Crankcase separation		Refer to "CRANKCASE" on page 5-54.
1	Shift fork guide bar	1	
2	Shift drum assembly	1	
3	Shift fork-R	1	
4	Shift fork-C	1	
5	Shift fork-L	1	
6	Main axle assembly	1	
7	Drive axle assembly	1	
			For installation, reverse the removal procedure.

## Disassembling the transmission



Order	Job/Parts to remove	Q'ty	Remarks
1	2nd pinion gear	1	
2	5th pinion gear	1	
3	3rd/4th pinion gear	1	
4	Main axle/1st pinion gear	1	
5	Circlip	1	
6	1st wheel gear	1	
7	Dog clutch	1	
8	Circlip	1	
9	Lock washer	1	
10	3rd wheel gear	1	
11	4th wheel gear	1	
12	5th wheel gear	1	
13	Circlip	1	
14	Lock washer	1	
15	2nd wheel gear	1	
16	Drive axle	1	
			For assembly, reverse the disassembly procedure.




EAS26260

## CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks.

1. Check:
  - Shift fork cam follower "1"
  - Shift fork pawl "2"
 Bends/damage/scoring/wear → Replace the shift fork.



2. Check:
  - Shift fork guide bar
 Roll the shift fork guide bar on a flat surface.  
 Bends → Replace.

EWA12840

### WARNING


**Do not attempt to straighten a bent shift fork guide bar.**

3. Check:
  - Shift fork movement  
(along the shift fork guide bar)
 Rough movement → Replace the shift forks and shift fork guide bar as a set.

EAS26270

## CHECKING THE SHIFT DRUM ASSEMBLY

1. Check:
  - Shift drum groove  
Damage/scratches/wear → Replace the shift drum assembly.
  - Shift drum segment "1"  
Damage/wear → Replace the shift drum assembly.
  - Shift drum bearing "2"  
Damage/pitting → Replace the shift drum assembly.




EAS26290

## CHECKING THE TRANSMISSION


1. Measure:
  - Main axle runout  
(with a centering device and dial gauge "1")
 Out of specification → Replace the main axle.

	<b>Main axle runout limit</b> <b>0.08 mm (0.0032 in)</b>
--	---



2. Measure:
  - Drive axle runout  
(with a centering device and dial gauge "1")
 Out of specification → Replace the drive axle.

	<b>Drive axle runout limit</b> <b>0.08 mm (0.0032 in)</b>
--	--



## 3. Check:


- Transmission gears  
Blue discoloration/pitting/wear → Replace the defective gear(s).
- Transmission gear dogs  
Cracks/damage/wear → Replace the defective gear(s).

## 4. Check:

- Transmission gear engagement  
(each pinion gear to its respective wheel gear)  
Incorrect → Reassemble the transmission axle assemblies.

### NOTE:

When reassembling the main axle "1", press the 2nd pinion gear "2" onto it as shown.



a. 102.2–102.4 mm

## 5. Check:

- Transmission gear movement  
Rough movement → Replace the defective part(s).

## 6. Check:

- Circlips  
Bends/damage/looseness → Replace.

EAS26320


## INSTALLING THE SHIFT FORKS AND SHIFT DRUM ASSEMBLY

### 1. Install:

- Shift fork-L "1"
- Shift fork-C
- Shift fork-R "2"
- Shift drum assembly "3"
- Shift fork guide bars "4"

### NOTE:

The embossed marks ("R"/"C"/"L") on the shift forks should face towards the right side of the engine.




## 2. Check:

- Transmission  
Rough movement → Repair.

### NOTE:

Oil each gear, shaft, and bearing thoroughly.



---

## FUEL SYSTEM


<b>FUEL TANK .....</b>	<b>6-1</b>
CHECKING THE FUEL COCK.....	6-2
<b>CARBURETOR .....</b>	<b>6-3</b>
CHECKING THE CARBURETOR.....	6-6
ASSEMBLING THE CARBURETOR.....	6-7
INSTALLING THE CARBURETOR.....	6-8
<b>AIR INDUCTION SYSTEM .....</b>	<b>6-9</b>
CHECKING THE AIR INDUCTION SYSTEM .....	6-12

# FUEL TANK

EAS26620

## FUEL TANK

### Removing the fuel tank




Order	Job/Parts to remove	Q'ty	Remarks
	Left fuel tank side cover/right fuel tank side cover		Refer to "GENERAL CHASSIS" on page 4-1.
1	Fuel hose	1	Disconnect.
2	Fuel tank	1	
3	Fuel cock	1	
			For installation, reverse the removal procedure.

EAS26650

## CHECKING THE FUEL COCK


1. Check:
  - Fuel cock
    - Cracks/damage/wear → Replace.
2. Check:
  - Fuel cock strainer “1”
    - Obstruction → clean.
    - Blow out the jets with compressed air.
    - Damage → Replace.



EAS26720


## CARBURETOR

### Removing the carburetor



Order	Job/Parts to remove	Q'ty	Remarks
	Fuel tank		Refer to "FUEL TANK" on page 6-1.
	Air cut-off valve		Refer to "AIR INDUCTION SYSTEM" on page 6-9.
1	Throttle cable	2	
2	Starter plunger	1	
3	Carburetor warmer coupler	1	Disconnect.
4	Fuel hose	1	
5	Intake manifold clamp screw	1	Loosen.
6	Carburetor joint clamp screw	1	Loosen.
7	Air filter case bolt	1	
8	Battery/electrical components box bolt	3	<b>NOTE:</b> Remove the air filter case bolts and the battery/electric parts box bolts, and then slide both the air filter case and the battery/electric parts box backward.
9	Carburetor assembly	1	
10	Carburetor air vent hose	2	
11	Carburetor fuel drain hose	1	
			For installation, reverse the removal procedure.


## Disassembling the carburetor



Order	Job/Parts to remove	Q'ty	Remarks
1	Throttle stop screw	1	
2	Vacuum chamber cover	1	
3	Piston valve spring	1	
4	Jet needle holder	1	
5	Spring	1	
6	Jet needle kit	1	
7	Piston valve	1	
8	Coasting enricher cover	1	
9	Coasting enricher spring	1	
10	Coasting enricher diaphragm	1	
11	Carburetor warmer lead	1	
12	Carburetor warmer	1	
13	Pilot screw set	1	
14	Float chamber	1	
15	Float chamber rubber gasket	1	
16	Float pin	1	
17	Float	1	
18	Needle valve	1	
19	Needle valve seat	1	
20	Main jet	1	

# CARBURETOR

## Disassembling the carburetor



Order	Job/Parts to remove	Q'ty	Remarks
21	Main jet holder	1	
22	Needle jet	1	
23	Pilot jet	1	
			For assembly, reverse the disassembly procedure.



EAS26760

## CHECKING THE CARBURETOR

### 1. Check:

- Carburetor body
- Float chamber
- Jet housing

Cracks/damage → Replace.

### 2. Check:


- Fuel passages

Obstruction → Clean.



a. Wash and clean the carburetor with a kerosene. Never use a poor volatile carburetor cleaner.

b. Clean all carburetor passages by air blow.



### 3. Check:

- Float chamber body
- Dirt → Clean.


### 4. Check:

- Float
- Damage → Replace.

### 5. Check:

- Needle valve "1"
- Needle valve seat "2"


Damage/obstruction/wear → Replace the needle valve and needle valve seat.



### 6. Check:

- Piston valve "1"
- Piston valve diaphragm "2"

Cracks/tears → Replace.



### 7. Check:


- Vacuum chamber cover
  - Piston valve spring
- Cracks/damage → Replace.

### 8. Check:

- Coasting enricher cover
  - Coasting enricher spring
  - Coasting enricher diaphragm
- Cracks/damage → Replace.

### 9. Check:

- Jet needle holder "1"
  - Jet needle kit "2"
  - Needle jet "3"
  - Pilot screw set "4"
  - Pilot jet "5"
  - Main jet "6"
  - Main jet holder "7"
- Bends/damage/wear → Replace.  
Obstruction → Blow out with compressed air.



### 10. Check:

- Piston valve movement
- Insert the piston valve into the carburetor body and move it up and down.  
Tightness → Replace the piston valve.

### 11. Check:

- Starter plunger
  - Starter plunger spring
- Bends/cracks/damage → Replace.

### 12. Check:

- Hose joints

# CARBURETOR

Cracks/damage → Replace.

## 13. Check:

- Carburetor air vent hose
- Carburetor fuel drain hose
- Fuel hoses

Cracks/damage/wear → Replace.

Obstruction → Clean.

Blow out the hoses with compressed air.

EAS26800

## ASSEMBLING THE CARBURETOR


ECA14110

### CAUTION:

- Before assembling the carburetor, wash all of the parts in a petroleum-based solvent.
- Always use a new gasket.

## 1. Install:

- Needle jet
- Main jet holder
- Main jet "1"
- Pilot jet "2"
- Needle valve seat "3"




## 2. Install:

- Needle valve
- Float "1"
- Float pin "2"

### NOTE:

Install the float pin in the reverse direction of arrow "a".




## 3. Check:

- Float height (dimension H) "a"  
Remove the float chamber rubber gasket, and measure the height from the float cham-

ber matching face to the float top face.




**Float height**  
**11.9 mm (0.47 in)**



### NOTE:

Temporarily lift the float, and check the oil level when the needle valve end slightly touches the float tongue.

Out of specification → Bend the float tongue "1" and adjust.




## 4. Install:

- Float chamber
- Pilot screw "1"




**Pilot screw turn out**  
**2-1/2**



## 5. Install:

- Piston valve
- Jet needle holder
- Jet needle kit "1"

## Clip position



EAS26890

## INSTALLING THE CARBURETOR


### 1. Adjust:

- Engine idling speed  
Refer to “ADJUSTING THE ENGINE IDLING SPEED” on page 3-8.




### 2. Adjust:

- Throttle cable free play  
Refer to “ADJUSTING THE THROTTLE CABLE FREE PLAY” on page 3-9.



EAS27040

AIR INDUCTION SYSTEM




# AIR INDUCTION SYSTEM

---

1. Cylinder head
2. Air induction system pipe
3. Air induction system hose (from the air cut-off valve to the cylinder head)
4. Air induction system vacuum hose
5. Air cut-off valve
6. Air induction system hose (from the air filter to the air cut-off valve)
7. Air filter case

# AIR INDUCTION SYSTEM

## Removing the air cut-off valve and hose



Order	Job/Part	Q'ty	Remarks
	Fuel tank		Refer to "FUEL TANK" on page 6-1.
1	Air induction system vacuum hose	1	
2	Air induction system hose (from the air cut-off valve to the cylinder head)	1	
3	Air cut-off valve	1	
4	Air induction system hose (from the air filter to the air cut-off valve)	1	
			For installation, reverse the removal procedure.

EAS27060

## CHECKING THE AIR INDUCTION SYSTEM


### Air induction

The air induction system burns unburned exhaust gases by injecting fresh air (secondary air) into the exhaust port, reducing the emission of carbon monoxide. When there is negative pressure at the exhaust port, the reed valve opens, allowing secondary air to flow into the exhaust port. The required temperature for burning the unburned exhaust gases is approximately 600 to 700°C.

### Air cut-off valve

The air cut-off valve is controlled by the intake gas pressure from the intake manifold. Ordinarily, the air cut-off valve opens to allow the air to flow during idle and closes to cut-off the flow when the vehicle is being driven. If the pressure drops when the engine speed is high, the air-cut-off valve is closed automatically.

Cracks/damage → Replace the reed valve.



- A. From the air filter
- B. From the intake manifold
- C. To the cylinder head

#### 1. Check:

- Hoses  
Loose connections → Connect properly.  
Cracks/damage → Replace.
- Pipes  
Cracks/damage → Replace.  
Refer to "CYLINDER HEAD" on page 5-6.

#### 2. Check:

- Air cut-off valve





---

# ELECTRICAL SYSTEM

<b>IGNITION SYSTEM</b> .....	<b>7-1</b>
CIRCUIT DIAGRAM .....	7-1
TROUBLESHOOTING .....	7-3
<b>ELECTRIC STARTING SYSTEM</b> .....	<b>7-5</b>
CIRCUIT DIAGRAM .....	7-5
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION.....	7-7
TROUBLESHOOTING .....	7-9
<b>CHARGING SYSTEM</b> .....	<b>7-11</b>
CIRCUIT DIAGRAM .....	7-11
TROUBLESHOOTING .....	7-13
<b>LIGHTING SYSTEM</b> .....	<b>7-15</b>
CIRCUIT DIAGRAM .....	7-15
TROUBLESHOOTING .....	7-17
<b>SIGNALING SYSTEM</b> .....	<b>7-19</b>
CIRCUIT DIAGRAM .....	7-19
TROUBLESHOOTING .....	7-21
<b>CARBURETOR HEATING SYSTEM</b> .....	<b>7-25</b>
CIRCUIT DIAGRAM .....	7-25
TROUBLESHOOTING .....	7-27
<b>ELECTRICAL COMPONENTS</b> .....	<b>7-29</b>
CHECKING THE SWITCHES .....	7-33
CHECKING THE BULBS AND BULB SOCKETS .....	7-36
CHECKING THE FUSE.....	7-37
CHECKING AND CHARGING THE BATTERY.....	7-37
CHECKING THE RELAYS .....	7-40
CHECKING THE TURN SIGNAL RELAY .....	7-41
CHECKING THE DIODE.....	7-42
CHECKING THE SPARK PLUG CAP .....	7-42
CHECKING THE IGNITION COIL.....	7-43
CHECKING THE PICKUP COIL .....	7-44
CHECKING THE STATOR COIL .....	7-44
CHECKING THE RECTIFIER/REGULATOR.....	7-45
CHECKING THE HORN.....	7-45
CHECKING THE SPEED SENSOR.....	7-46
CHECKING THE THERMO SWITCH .....	7-46
CHECKING THE CARBURETOR WARMER.....	7-47



# IGNITION SYSTEM

---

1. Pickup coil
2. A.C. magneto
4. Fuse
6. Battery
9. Main switch
10. Right handlebar switch
11. Engine stop switch
13. Diode
15. Sidestand switch
16. Starting circuit cut-off relay
17. Diode 3
18. Neutral switch
19. C.D.I. unit
20. Ignition coil
21. Spark plug

EAS27130

## TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

### NOTE:

Before troubleshooting, remove the following part(s):

1. Seat
2. Rear side cover
3. Tool box
4. Fuel tank
5. Carburetor assembly
6. Starter (choke) knob

<p>1. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.</p>	NG→	<p>Replace the fuse(s).</p>
OK↓		
<p>2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.</p>	NG→	<ul style="list-style-type: none"> <li>● Clean the battery terminals.</li> <li>● Recharge or replace the battery.</li> </ul>
OK↓		
<p>3. Check the spark plug. Refer to "CHECKING THE SPARK PLUG" on page 3-8.</p>	NG→	<p>Re-gap or replace the spark plug.</p>
OK↓		
<p>4. Check the spark plug cap. Refer to "CHECKING THE SPARK PLUG CAP" on page 7-42.</p>	NG→	<p>Replace the spark plug cap.</p>
OK↓		
<p>5. Check the ignition coil. Refer to "CHECKING THE IGNITION COIL" on page 7-43.</p>	NG→	<p>Replace the ignition coil.</p>
OK↓		
<p>6. Check the pickup coil. Refer to "CHECKING THE PICKUP COIL" on page 7-44.</p>	NG→	<p>Replace the pickup coil/stator assembly.</p>
OK↓		
<p>7. Check the stator coil. Refer to .</p>	NG→	<p>Replace the pickup coil/stator assembly.</p>
OK↓		
<p>8. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 7-33.</p>	NG→	<p>Replace the main switch.</p>
OK↓		
<p>9. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 7-33.</p>	NG→	<p>Poor conducting of engine stop switch. Replace the right handlebar switch.</p>
OK↓		

## IGNITION SYSTEM

10. Check the sidestand switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

OK↓

NG→

Replace the sidestand switch.

11. Check the clutch switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

OK↓

NG→

Replace the clutch switch.

12. Checking the entire ignition system's wiring.  
Refer to "CIRCUIT DIAGRAM" on page 7-1.

OK↓

NG→

Properly connect or repair the ignition system's wiring.

Replace the C.D.I. unit.


# ELECTRIC STARTING SYSTEM

EAS27160

## ELECTRIC STARTING SYSTEM

EAS27170

## CIRCUIT DIAGRAM



# ELECTRIC STARTING SYSTEM

---

4. Fuse
5. Starter relay
6. Battery
7. Starter motor
8. Diode 1
9. Main switch
10. Right handlebar switch
11. Engine stop switch
12. Start switch
13. Diode 2
14. Clutch switch
15. Sidestand switch
16. Starting circuit cut-off relay
17. Diode 3
18. Neutral switch

# ELECTRIC STARTING SYSTEM


EAS27180

## STARTING CIRCUIT CUT-OFF SYSTEM OPERATION

If the engine stop switch is set to “○” and the main switch is set to “ON” (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral switch is closed).
- The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cut-off relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cut-off relay is open so current cannot reach the starter motor. If any of the above has occurred and if the starting circuit cut-off relay is turned ON, you can start the engine by pressing starter switch “○”.





# ELECTRIC STARTING SYSTEM

---

- a. WHEN THE TRANSMISSION IS IN NEUTRAL
  - b. WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR
- 
- 1. Battery
  - 2. Fuse
  - 3. Main switch
  - 4. Diode2
  - 5. Clutch switch
  - 6. Sidestand switch
  - 7. Engine stop switch
  - 8. Neutral switch
  - 9. Diode3
  - 10. Starting circuit cut-off relay
  - 11. Start switch
  - 12. Diode1
  - 13. Starter relay
  - 14. Starter motor

# ELECTRIC STARTING SYSTEM

EAS27190

## TROUBLESHOOTING

The starter motor fails to turn.

### NOTE:

Before troubleshooting, remove the following part(s):

- 1.Seat
- 2.Rear side cover
- 3.Tool box
- 4.Fuel tank
- 5.Carburetor assembly

1. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.	NG→	<ul style="list-style-type: none"><li>● Clean the battery terminals.</li><li>● Recharge or replace the battery.</li></ul>
OK↓		
3. Check the starter motor. Refer to "CHECKING THE STARTER MOTOR" on page 5-52.	NG→	Repair or replace the starter motor.
OK↓		
4. Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 7-40.	NG→	Replace the starting circuit cut-off relay.
OK↓		
5. Check the diode2. Refer to "CHECKING THE DIODE" on page 7-42.	NG→	Replace the diode2.
OK↓		
6. Check the diode3. Refer to "CHECKING THE DIODE" on page 7-42.	NG→	Replace the diode3.
OK↓		
7. Check the starter relay. Refer to "CHECKING THE RELAYS" on page 7-40.	NG→	Replace the starter relay.
OK↓		
8. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the main switch.
OK↓		
9. Checking the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Poor conducting of engine stop switch. Replace the right handlebar switch.
OK↓		

## ELECTRIC STARTING SYSTEM


10. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the right handlebar switch.
OK↓		
11. Check the neutral switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the neutral switch.
OK↓		
12. Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the sidestand switch.
OK↓		
13. Check the clutch switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the clutch switch.
OK↓		
14. Check the start switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Poor conducting of engine stop switch. Replace the right handlebar switch.
OK↓		
15. Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-5.	NG→	Properly connect or repair the starting system's wiring
OK↓		
The starting system circuit is OK.		

EAS27200

## CHARGING SYSTEM

EAS27210

## CIRCUIT DIAGRAM



## CHARGING SYSTEM

---

2. A.C. magneto
3. Rectifier/regulator
4. Fuse
6. Battery

EAS27220

## TROUBLESHOOTING

The battery is not being charged.

### NOTE:

Before troubleshooting, remove the following part(s):

1. Seat
2. Rear side cover
3. Fuel tank
4. Carburetor assembly

1. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.	NG→	Replace the fuse.
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.	NG→	<ul style="list-style-type: none"><li>● Clean the battery terminals.</li><li>● Recharge or replace the battery.</li></ul>
OK↓		
3. Check the stator coil. Refer to "CHECKING THE STATOR COIL" on page 7-44.	NG→	Replace the stator assembly.
OK↓		
4. Check the rectifier/regulator. Refer to "CHECKING THE RECTIFIER/REGULATOR" on page 7-45.	NG→	Replace the rectifier/regulator.
OK↓		
5. Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-11.	NG→	Properly connect or repair the charging system's wiring.
OK↓		
This circuit is OK.		







- 4. Fuse
- 6. Battery
- 9. Main switch
- 19. C. D. I. unit
- 22. Meter assembly
- 26. High beam indicator light
- 29. Tail/brake light
- 31. Front turn signal light (right)
- 32. Front turn signal light (left)
- 34. Headlight
- 38. Headlight relay
- 40. Left handlebar switch
- 42. Dimmer switch

EAS27260

## TROUBLESHOOTING

Any of the following fail to light: headlight, high beam indicator light, taillight, license light or meter light.

### NOTE:

Before troubleshooting, remove the following part(s):

1. Seat
2. Rear side cover
3. Tool box

<p>1. Check the each bulbs and bulb sockets condition. Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 7-36.</p>	NG→	<p>Replace the bulb(s), bulb socket(s) or both.</p>
OK↓		
<p>2. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.</p>	NG→	<p>Replace the fuse(s).</p>
OK↓		
<p>3. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.</p>	NG→	<ul style="list-style-type: none"> <li>● Clean the battery terminals.</li> <li>● Recharge or replace the battery.</li> </ul>
OK↓		
<p>4. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 7-33.</p>	NG→	<p>Replace the main switch.</p>
OK↓		
<p>5. Check the dimmer switch. Refer to "CHECKING THE SWITCHES" on page 7-33.</p>	NG→	<p>The dimmer switch is faulty. Replace the left handlebar switch.</p>
OK↓		
<p>6. Check the headlight relay (on/off). Refer to "CHECKING THE RELAYS" on page 7-40.</p>	NG→	<p>Replace the headlight relay.</p>
OK↓		
<p>7. Check the headlight relay (dimmer). Refer to "CHECKING THE RELAYS" on page 7-40.</p>	NG→	<p>Replace the headlight relay.</p>
OK↓		
<p>8. Check the entire lighting system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-15.</p>	NG→	<p>Properly connect or repair the lighting system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		




EAS27270

## SIGNALING SYSTEM

EAS27280

## CIRCUIT DIAGRAM



4. Fuse
6. Battery
9. Main switch
18. Neutral switch
19. C. D. I. unit
22. Meter assembly
23. Neutral indicator light
24. Multi-function display
25. Speedometer
27. Turn signal indicator light
28. Speed sensor
29. Tail/brake light
30. Rear turn signal light (right)
31. Front turn signal light (right)
32. Front turn signal light (left)
33. Rear turn signal light (left)
35. Rear brake light switch
36. Front brake light switch
37. Turn signal relay
39. Horn
40. Left handlebar switch
41. Horn switch
43. Turn signal switch

EAS27290

## TROUBLESHOOTING

- Any of the following fail to light: turn signal light, brake light or an indicator light.
- The horn fails to sound.
- The speedometer fails to operate.

**NOTE:**

Before troubleshooting, remove the following part(s):

1. Seat
2. Rear side cover
3. Tool box

1. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.	NG→	<ul style="list-style-type: none"><li>● Clean the battery terminals.</li><li>● Recharge or replace the battery.</li></ul>
OK↓		
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the main switch.
OK↓		
4. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-19.	NG→	Properly connect or repair the signaling system's wiring.
OK↓		
This circuit is OK.		

### Check the signaling system

The horn fails to sound.

1. Check the horn switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Poor conducting of horn switch. Replace the left handlebar switch.
OK↓		
2. Check the horn. Refer to "CHECKING THE HORN" on page 7-45.	NG→	Replace the horn.
OK↓		
3. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-19.	NG→	Properly connect or repair the signaling system's wiring.
OK↓		
This circuit is OK.		

# SIGNALING SYSTEM

The tail/brake light fails to come on.

1. Check the tail/brake light bulb and socket.  
Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 7-36.

NG→

Replace the tail/brake light bulb, socket or both.

OK↓

2. Check the front brake light switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

NG→

Replace the front brake light switch.

OK↓

3. Check the rear brake light switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

NG→

Replace the rear brake light switch.

OK↓

4. Check the entire signaling system's wiring.  
Refer to "CIRCUIT DIAGRAM" on page 7-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

This circuit is OK.

The turn signal light, turn signal indicator light or both fail to blink.

1. Check the turn signal light bulb and socket.  
Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 7-36.

NG→

Replace the turn signal light bulb, socket or both.

OK↓

2. Check the turn signal switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

NG→

Poor conducting of turn signal switch.  
Replace the left handlebar switch.

OK↓

3. Check the turn signal relay.  
Refer to "CHECKING THE RELAYS" on page 7-40.

NG→

Replace the turn signal relay.

OK↓

4. Check the entire signaling system's wiring.  
Refer to "CIRCUIT DIAGRAM" on page 7-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

Meter assembly

# SIGNALING SYSTEM

The neutral indicator light fails to come.

1. Check the neutral switch.  
Refer to "CHECKING THE SWITCHES" on page 7-33.

NG→

Replace the neutral switch.

OK↓

2. Check the entire signaling system's wiring.  
Refer to "CIRCUIT DIAGRAM" on page 7-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

This circuit is OK.

The speedometer fails to operate.

1. Check the speed sensor.  
Refer to "CHECKING THE SPEED SENSOR" on page 7-46.

NG→

Replace the speed sensor.

OK↓

2. Check the entire signaling system's wiring.  
Refer to "CIRCUIT DIAGRAM" on page 7-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

Replace the meter assembly.







## CARBURETOR HEATING SYSTEM

---

- 4. Fuse
- 6. Battery
- 9. Main switch
- 44. Thermo switch
- 45. Carburetor warmer

# CARBURETOR HEATING SYSTEM

EAS27510

## TROUBLESHOOTING

The carburetor warmer system fails to operate.

### NOTE:

Before troubleshooting, remove the following part(s):

- 1.Seat
- 2.Rear side cover
- 3.Tool box
- 4.Fuel tank
- 5.Carburetor assembly
- 6.Rectifier/regulator

1. Check the fuse. Refer to "CHECKING THE FUSE" on page 7-37.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 7-37.	NG→	<ul style="list-style-type: none"><li>● Clean the battery terminals.</li><li>● Recharge or replace the battery.</li></ul>
OK↓		
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 7-33.	NG→	Replace the main switch.
OK↓		
4. Check the thermo switch. Refer to "CHECKING THE THERMO SWITCH" on page 7-46.	NG→	Replace the thermo switch.
OK↓		
5. Check the carburetor warmer. Refer to "CHECKING THE CARBURETOR WARMER" on page 7-47.	NG→	Replace the carburetor warmer.
OK↓		
6. Check the entire carburetor heating system's wiring. Refer to "CIRCUIT DIAGRAM" on page 7-25.	NG→	Properly connect or repair the carburetor heating system's wiring.
OK↓		
This circuit is OK.		

# CARBURETOR HEATING SYSTEM


---

# ELECTRICAL COMPONENTS

EAS27971

## ELECTRICAL COMPONENTS

EAS3C51017




# ELECTRICAL COMPONENTS

---

1. Main switch
2. Diode1
3. Diode3
4. Diode2
5. Fuse
6. Starter relay
7. Battery
8. Rectifier/regulator
9. Sidestand switch
10. Rear brake light switch
11. Headlight relay
12. Starting circuit cut-off relay
13. Wire harness

# ELECTRICAL COMPONENTS





## ELECTRICAL COMPONENTS


---

1. Horn
2. CDI unit
3. Thermo switch
4. Speed sensor
5. Neutral switch
6. Carburetor warmer
7. Carburetor warmer lead
8. Ignition coil
9. Spark plug cap

# ELECTRICAL COMPONENTS

EAS27980

## CHECKING THE SWITCHES



# ELECTRICAL COMPONENTS

---

1. Horn switch
2. Dimmer switch
3. Turn signal switch
4. Clutch switch
5. Sidestand switch
6. Main switch
7. Engine stop switch
8. Start switch
9. Front brake light switch
10. Neutral switch
11. Rear brake light switch

# ELECTRICAL COMPONENTS

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

ECA14370


**CAUTION:**

Never insert the tester probes into the coupler terminal slots "a". Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



**NOTE:**

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.



The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on below.


The switch positions "a" are shown in the far left column and the switch lead colors "b" are shown in the top row in the switch illustration.

**NOTE:**

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

**The example illustration below shows that:**

This chart shows that the switch circuit is conductive when the switch is "ON" for Red, Brown/Blue, Blue/Black, and Blue/Yellow.





## Checking the condition of the bulb sockets

The following procedure applies to all of the bulb sockets.

1. Check:
  - Bulb socket (for continuity)  
(with the pocket tester)  
No continuity → Replace.



**Pocket tester**  
90890-03132

### NOTE:

Check each bulb socket for continuity in the same manner as described in the bulb section; however, note the following.

- a. Install a good bulb into the bulb socket.
- b. Connect the pocket tester probes to the respective leads of the bulb socket.
- c. Check the bulb socket for continuity. If any of the readings indicate no continuity, replace the bulb socket.

EAS28000

## CHECKING THE FUSE

The following procedure applies to all of the fuse.

EC3C51005

### CAUTION:

**To avoid a shortcircuit, disconnect the negative battery lead from the battery terminal before you check or replace the fuse.**

1. Remove:
  - Seat
  - Rear right side cover  
Refer to “GENERAL CHASSIS” on page 4-1.
2. Check:
  - Fuse

- a. Connect the pocket tester to the fuse and check the continuity.

### NOTE:

Set the pocket tester selector to “ $\Omega \times 1$ ”.



**Pocket tester**  
90890-03132

- b. If the pocket tester indicates “∞”, replace the fuse.

3. Replace:

- Blown fuse

- a. Set the main switch to “OFF”.
- b. Install a new fuse of the correct amperage rating.
- c. Set on the switches to verify if the electrical circuit is operational.
- d. If the fuse immediately blows again, check the electrical circuit.

Fuse	Amperage rating	Q'ty
Fuse	20 A	1
Reserve	20 A	1

EWA13310

### WARNING

**Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.**

4. Install:

- Rear right side cover
- Seat

Refer to “GENERAL CHASSIS” on page 4-1.

EAS28030

## CHECKING AND CHARGING THE BATTERY

EWA13290

### WARNING

**Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:**

- **Wear protective eye gear when handling or working near batteries.**
- **Charge batteries in a well-ventilated area.**
- **Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).**
- **DO NOT SMOKE when charging or handling batteries.**
- **KEEP BATTERIES AND ELECTROLYTE**

# ELECTRICAL COMPONENTS

## OUT OF REACH OF CHILDREN.

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.


## FIRST AID IN CASE OF BODILY CONTACT:

### EXTERNAL

- Skin — Wash with water.
- Eyes — Flush with water for 15 minutes and get immediate medical attention.

### INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.



3. Remove:

- Battery

4. Check:

- Battery charge

ECA13660

### CAUTION:

- This is a sealed battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
- Charging time, charging amperage and charging voltage for an MF battery are different from those of conventional batteries. The MF battery should be charged as explained in the charging method illustrations. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.

### NOTE:

Since MF batteries are sealed, it is not possible to check the charge state of the battery by measuring the specific gravity of the electrolyte. Therefore, the charge of the battery has to be checked by measuring the voltage at the battery terminals.

1. Remove:

- Seat
- Rear right side cover

Refer to "GENERAL CHASSIS" on page 4-1.

2. Disconnect:

- Battery band "1"  
Battery leads  
(from the battery terminals)

EC3C51008

### CAUTION:

Always disconnect negative battery lead "2" first, and then disconnect positive battery lead "3".

- a. Connect a pocket tester to the battery terminals.

Positive tester probe →  
Positive battery terminal  
Negative tester probe →  
Negative battery terminal

### NOTE:

- The charge state of an MF battery can be checked by measuring its open-circuit voltage (i.e., the voltage when the positive battery terminal is disconnected).
- No charging is necessary when the open-circuit voltage equals or exceeds 12.8 V.

- b. Check the charge of the battery, as shown in the charts and the following example.

Example  
Open-circuit voltage = 12.0 V  
Charging time = 6.5 hours  
Charge of the battery = 20–30%

5. Charge:

- Battery  
(refer to the appropriate charging method illustration)

EWA13300

### WARNING

Do not quick charge a battery.

EC3C51007

### CAUTION:

- Never remove the MF battery sealing caps.
- Do not use a high-rate battery charger. They force a high-amperage current into





# ELECTRICAL COMPONENTS

ter leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete.  
 12.7 V or less --- Recharging is required.  
 Under 12.0 V --- Replace the battery.




6. Install:
  - Battery
7. Connect:
  - Battery leads  
(to the battery terminals)

ECA13630

**CAUTION:**

**First, connect the positive battery lead "1", and then the negative battery lead "2".**



8. Check:
  - Battery terminals  
Dirt → Clean with a wire brush.  
Loose connection → Connect properly.
9. Lubricate:
  - Battery terminals

**Recommended lubricant**  
Dielectric grease

10. Install:
  - Battery band
11. Install:
  - Rear right side cover
  - Seat  
Refer to "GENERAL CHASSIS" on page 4-1.

EAS28040


**CHECKING THE RELAYS**

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, replace the relay.

**Pocket tester**  
90890-03132

1. Disconnect the relay from the wire harness.
2. Connect the pocket tester ( $\Omega \times 1$ ) and battery (12 V) to the relay terminal as shown. Check the relay operation. Out of specification → Replace.


**Starter relay**



1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe

**Result**  
Continuity  
(between "3" and "4")


**Starting circuit cut-off relay**




1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe

**Result**  
Continuity  
(between "3" and "4")

## Headlight relay



1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe



**Result**  
**Continuity**  
**(between "3" and "4")**

EAS3C51015

### CHECKING THE TURN SIGNAL RELAY

#### 1. Check:

- Turn signal light relay input voltages  
Out of specification → Poor circuit connection from main switch to turn signal light relay coupler. Repair.




**Turn signal light relay input voltage**  
**DC 12 V**

- a. Connect the pocket tester (DC 20 V) to the turn signal light and hazard relay coupler as shown.



**Pocket tester**  
**90890-03132**

**Positive probe of the tester**  
**Brown "1"**  
**Negative probe of the tester**  
**Ground to chassis frame**



- b. Turn the main switch "ON".
- c. Measure the input voltage of the turn signal light and hazard relay.

#### 2. Check:

- Turn signal light and hazard relay output voltage  
Out of specification → Replace the turn signal light and hazard relay.




**Turn signal light and hazard relay output voltage**  
**DC 12 V**

- a. Touch probes of the pocket tester (DC 20 V) to the turn signal light and hazard relay coupler as shown.



**Pocket tester**  
**90890-03132**

**Positive probe of the tester**  
**Brown/white "1"**  
**Negative probe of the tester**  
**Ground to chassis frame**



- b. Turn the main switch "ON".
- c. Measure the output voltage of the turn signal light and hazard relay.



EAS28050

## CHECKING THE DIODE

1. Check:

- Diode2
- Diode3

Out of specification → Replace.


	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

### NOTE:


The following lists the specifications if you use the pocket tester (90890-03132).

	<p><b>Diode2</b></p> <p><b>Continuity</b></p> <p>Positive tester probe → Blue/white “1”</p> <p>Negative tester probe → Blue/black “2”</p> <p><b>No continuity</b></p> <p>Positive tester probe → Blue/black “2”</p> <p>Negative tester probe → Blue/white “1”</p> <p><b>Diode3</b></p> <p><b>Continuity</b></p> <p>Positive tester probe → Sky blue “3”</p> <p>Negative tester probe → Light green “4”</p> <p><b>No continuity</b></p> <p>Positive tester probe → Light green “4”</p> <p>Negative tester probe → Sky blue “3”</p>
--	---

A



B



- A. Diode2
- B. Diode3



- Disconnect the diode from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$ ) to the diode coupler as shown.
- Check the diode for continuity.
- Check the diode for no continuity.



EAS28060

## CHECKING THE SPARK PLUG CAP

1. Check:


- Spark plug cap resistance
- Out of specification → Replace.

	<b>Resistance</b> 10.0 k $\Omega$
--	--------------------------------------



- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester ( $\Omega \times 1k$ ) to the spark plug cap as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------



- Measure the spark plug cap resistance.



# ELECTRICAL COMPONENTS

EAS28090

## CHECKING THE IGNITION COIL


1. Check:
  - Primary coil resistance  
Out of specification → Replace.

	<b>Primary coil resistance</b> 0.18–0.27 Ω
--	---

- a. Disconnect the ignition coil connectors from the wire harness.
- b. Connect the pocket tester ( $\Omega \times 1$ ) to the ignition coil as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

Positive tester probe  
Orange “1”  
Negative tester probe  
Ignition coil base “2”



- c. Measure the primary coil resistance.


2. Check:
  - Secondary coil resistance  
Out of specification → Replace.

	<b>Secondary coil resistance</b> 6.32–9.48 kΩ
--	--

- a. Disconnect the spark plug cap from the ignition coil.
- b. Connect the pocket tester ( $\Omega \times 1k$ ) to the ignition coil as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

Positive tester probe  
High tension code “1”  
Negative tester probe  
Orange “2”




- c. Measure the secondary coil resistance.

3. Check:
  - Ignition spark gap  
Out of specification → Follow Step 5 and later of the ignition system troubleshooting procedure.  
Refer to “TROUBLESHOOTING” on page 7-3.

**Minimum ignition spark gap**  
6.0 mm

- a. Disconnect the spark plug cap from the spark plug.
- b. Connect ignition check “1” to the spark plug as shown.

**Ignition checker**  
90890-06754  
Opama pet-4000 spark checker  
YM-34487



2. Spark plug cap
- c. Turn the main switch “ON” and set the engine stop switch to the “○”.
- d. Measure ignition spark gap “a”.
- e. Press start switch “⊕” to crank the engine, and gradually increase the spark plug gap until the engine misfires.



EAS28110

## CHECKING THE PICKUP COIL

1. Disconnect:
  - Pickup coil coupler (from the wire harness)
2. Check:
  - Pickup coil resistance
 Out of specification → Replace the pickup coil and stator assembly.


	<b>Pickup coil resistance</b> 279–341 Ω (Red–white)
--	--



- a. Connect the pocket tester ( $\Omega \times 100$ ) to the pickup coil terminal as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

Positive tester probe White “1” Negative tester probe Red “2”
--



- b. Measure the pickup coil resistance.



EAS28150

## CHECKING THE STATOR COIL

1. Disconnect:
  - Stator coil coupler (from the wire harness)
2. Check:
  - Stator coil resistance
 Out of specification → Replace the pickup coil and stator assembly.

	<b>Stator coil resistance</b> 0.560–0.840 Ω (White–white)
--	--




- a. Connect the pocket tester ( $\Omega \times 1$ ) to the stator coil coupler as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

Positive tester probe White “1” Negative tester probe White “2”
--

Positive tester probe White “1” Negative tester probe White “3”
--

Positive tester probe White “2” Negative tester probe White “3”
--



b. Measure the stator coil resistance.



EAS28170

## CHECKING THE RECTIFIER/REGULATOR

1. Check:

- Rectifier/regulator input voltage  
Out of specification → Replace the rectifier/regulator.



**Rectifier/regulator input voltage  
above 14 V at 5000 r/min**




- Connect a digital tachometer to the spark plug lead of the cylinder.
- Connect the pocket tester (DC 20 V) to the rectifier/regulator coupler as shown.



**Pocket tester  
90890-03132**

**Positive tester probe  
Red "1"  
Negative tester probe  
Ground to chassis frame**



- Start the engine and let it run at approximately 5000 r/min.
- Measure the rectifier/regulator input voltage.



EAS28180

## CHECKING THE HORN

1. Check:

- Horn resistance  
Out of specification → Replace.



**Horn resistance  
1.01–1.11 Ω at 20°C (68°F)**




- Disconnect the horn leads from the horn terminals.
- Connect the pocket tester ( $\Omega \times 1$ ) to the horn terminals.



**Pocket tester  
90890-03132**

**Positive tester probe  
Horn terminal "1"  
Negative tester probe  
Horn terminal "2"**



c. Measure the horn resistance.




2. Check:

- Horn sound  
Faulty sound → Adjust or replace.



- Connect a battery (12 V) to the horn.
- Turn the adjusting screw in direction "a" or "b" until the specified horn sound is obtained.



EAS28240

## CHECKING THE SPEED SENSOR

1. Disconnect:
  - Speed sensor coupler
2. Check:
  - Speed sensor resistance
 Out of specification → Replace.


	<b>Speed sensor resistance</b> 470–530 Ω 25 °C (77 °F)
--	---



- a. Connect the digital circuit tester to the speed sensor coupler (wire harness side).

	<b>Digital circuit tester</b> 90890-03174 Model 88 Multimeter with tachometer YU-A1927
--	---

<b>Positive tester probe</b> White “1” <b>Negative tester probe</b> Black “2”
--



- b. Measure the speed sensor resistance.



EAS28270

## CHECKING THE THERMO SWITCH

1. Remove:
  - Thermo switch
 (from the thermostat housing)

EWA13830

### ⚠ WARNING

- Handle the thermo switch with special care.
- Never subject the thermo switch to strong shocks. If the thermo switch is dropped, replace it.

2. Check:
  - Thermo switch continuity
 Out of specification → Replace the thermo switch.


Test step	Coolant temperature	Continuity
1	Less than 16°C (61°F)	YES
2	More than 16°C (61°F)	NO
3	More than 11°C (52°F)	NO
4	Less than 11°C (52°F)	YES

Step 1 and 2: Heating phase


Step 3 and 4: Cooling phase



- a. Connect the pocket tester ( $\Omega \times 1$ ) to the thermo switch “1” as shown.
- b. Immerse the thermo switch in a container filled with coolant “2”.
- c. Place a thermometer “3” in the coolant.



- d. Slowly heat the coolant, then let it cool down to the specified temperature.



- A. When the water temperature increases
  - B. When the water temperature decreases
- e. Check the thermo switch for continuity.



EAS28310

## CHECKING THE CARBURETOR WARMER

1. Check:
  - Carburetor warmer element resistance
 Out of specification → Replace.


	<b>Carburetor warmer resistance</b> 4.7–9.5 Ω 20°C (68°F)
--	--



- a. Remove the carburetor warmer leads from the carburetor.
- b. Connect the pocket tester ( $\Omega \times 1$ ) to the carburetor warmer as shown.

	<b>Pocket tester</b> 90890-03132
--	-------------------------------------

<b>Positive tester probe</b> Carburetor warmer terminal “1” <b>Negative tester probe</b> Carburetor warmer body “2”
--



- c. Measure the carburetor warmer resistance.



---

## TROUBLESHOOTING

<b>TROUBLESHOOTING .....</b>	<b>8-1</b>
GENERAL INFORMATION .....	8-1
STARTING FAILURES.....	8-1
INCORRECT ENGINE IDLING SPEED .....	8-1
POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE.....	8-2
FAULTY GEAR SHIFTING.....	8-2
SHIFT PEDAL DOES NOT MOVE.....	8-2
JUMPS OUT OF GEAR .....	8-2
FAULTY CLUTCH .....	8-2
OVERHEATING .....	8-3
POOR BRAKING PERFORMANCE.....	8-3
FAULTY FRONT FORK LEGS.....	8-3
UNSTABLE HANDLING.....	8-3
FAULTY LIGHTING OR SIGNALING SYSTEM.....	8-3

EAS28450

## TROUBLESHOOTING

EAS28460

### GENERAL INFORMATION

#### NOTE:

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

EAS28470

### STARTING FAILURES

#### Engine

1. Cylinder(s) and cylinder head(s)
  - Loose spark plug
  - Loose cylinder head or cylinder
  - Damaged cylinder head gasket
  - Damaged cylinder gasket
  - Worn or damaged cylinder
  - Incorrect valve clearance
  - Improperly sealed valve
  - Incorrect valve-to-valve-seat contact
  - Incorrect valve timing
  - Faulty valve spring
  - Seized valve
2. Piston(s) and piston ring(s)
  - Improperly installed piston ring
  - Damaged, worn or fatigued piston ring
  - Seized piston ring
  - Seized or damaged piston
3. Air filter
  - Improperly installed air filter
  - Clogged air filter element
4. Crankcase and crankshaft
  - Improperly assembled crankcase
  - Seized crankshaft

#### Fuel system

1. Fuel tank
  - Empty fuel tank
  - Clogged fuel filter
  - Clogged fuel strainer
  - Clogged fuel tank drain hose
  - Clogged rollover valve
  - Clogged rollover valve hose
  - Deteriorated or contaminated fuel
2. Fuel pump
  - Faulty fuel pump
  - Faulty fuel pump relay
3. Fuel cock
  - Clogged or damaged fuel hose
4. Carburetor(s)

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Damaged float
- Worn needle valve
- Improperly installed needle valve seat
- Incorrect fuel level
- Improperly installed pilot jet
- Clogged starter jet
- Faulty starter plunger
- Improperly adjusted starter cable

#### Electrical system

1. Battery
  - Discharged battery
  - Faulty battery
2. Fuse(s)
  - Blown, damaged or incorrect fuse
  - Improperly installed fuse
3. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
  - Fouled spark plug
  - Worn or damaged electrode
  - Worn or damaged insulator
  - Faulty spark plug cap
4. Ignition coil(s)
  - Cracked or broken ignition coil body
  - Broken or shorted primary or secondary coils
  - Faulty spark plug lead
5. Ignition system
  - Faulty ignitor unit
  - Faulty pickup coil
  - Broken generator rotor woodruff key
6. Switches and wiring
  - Faulty main switch
  - Faulty engine stop switch
  - Broken or shorted wiring
  - Faulty neutral switch
  - Faulty start switch
  - Faulty sidestand switch
  - Faulty clutch switch
  - Improperly grounded circuit
  - Loose connections
7. Starting system
  - Faulty starter motor
  - Faulty starter relay
  - Faulty starting circuit cut-off relay
  - Faulty starter clutch

EAS28490

### INCORRECT ENGINE IDLING SPEED

#### Engine

1. Cylinder(s) and cylinder head(s)

- Incorrect valve clearance
  - Damaged valve train components
2. Air filter
    - Clogged air filter element

## Fuel system

1. Carburetor(s)
  - Faulty starter plunger
  - Loose or clogged pilot jet
  - Loose or clogged pilot air jet
  - Damaged or loose carburetor joint
  - Improperly synchronized carburetors
  - Improperly adjusted engine idling speed (throttle stop screw)
  - Improper throttle cable free play
  - Flooded carburetor
  - Faulty air induction system

## Electrical system

1. Battery
  - Discharged battery
  - Faulty battery
2. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
  - Fouled spark plug
  - Worn or damaged electrode
  - Worn or damaged insulator
  - Faulty spark plug cap
3. Ignition coil(s)
  - Broken or shorted primary or secondary coils
  - Faulty spark plug lead
  - Cracked or broken ignition coil
4. Ignition system
  - Faulty ignitor unit
  - Faulty pickup coil
  - Broken generator rotor woodruff key

EAS28520

## POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING FAILURES" on page 8-1.

### Engine

1. Air filter
  - Clogged air filter element
2. Air intake system
  - Bent, clogged or disconnected carburetor air vent hose
  - Clogged or leaking air duct

## Fuel system

1. Carburetor(s)
  - Faulty diaphragm
  - Incorrect fuel level
  - Loose or clogged main jet
2. Fuel pump
  - Faulty fuel pump

EAS28530

## FAULTY GEAR SHIFTING

### Shifting is difficult

Refer to "Clutch drags".

EAS28540

## SHIFT PEDAL DOES NOT MOVE

### Shift shaft

- Improperly adjusted shift rod
- Bent shift shaft

### Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

### Transmission

- Seized transmission gear
- Foreign object between transmission gears
- Improperly assembled transmission

EAS28550

## JUMPS OUT OF GEAR

### Shift shaft

- Incorrect shift pedal position
- Improperly returned stopper lever

### Shift forks

- Worn shift fork

### Shift drum

- Incorrect axial play
- Worn shift drum groove

### Transmission

- Worn gear dog

EAS28560

## FAULTY CLUTCH

### Clutch slips

1. Clutch
  - Improperly assembled clutch
  - Improperly adjusted clutch cable
  - Loose or fatigued clutch spring
  - Worn friction plate
  - Worn clutch plate
2. Engine oil
  - Incorrect oil level
  - Incorrect oil viscosity (low)
  - Deteriorated oil

### Clutch drags

1. Clutch
  - Unevenly tensioned clutch springs
  - Warped pressure plate
  - Bent clutch plate
  - Swollen friction plate
  - Bent clutch push rod
  - Broken clutch boss
  - Burnt primary driven gear bushing
  - Match marks not aligned
2. Engine oil

- Incorrect oil level
- Incorrect oil viscosity (high)
- Deteriorated oil

EAS28590

## OVERHEATING

### Engine

1. Cylinder head(s) and piston(s)
  - Heavy carbon buildup
2. Engine oil
  - Incorrect oil level
  - Incorrect oil viscosity
  - Inferior oil quality

### Fuel system

1. Carburetor(s)
  - Incorrect main jet setting
  - Incorrect fuel level
  - Damaged or loose carburetor joint
2. Air filter
  - Clogged air filter element

### Chassis

1. Brake(s)
  - Dragging brake

### Electrical system

1. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
2. Ignition system
  - Faulty ignitor unit

EAS28620

## POOR BRAKING PERFORMANCE

- Worn brake pad
- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper kit
- Faulty brake caliper seal
- Loose the union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

EAS28660

## FAULTY FRONT FORK LEGS

### Leaking oil

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- Loose damper rod assembly bolt
- Damaged damper rod assembly bolt copper washer

- Cracked or damaged cap bolt O-ring

### Malfunction

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

EAS28690

## UNSTABLE HANDLING

1. Handlebar
  - Bent or improperly installed handlebar
2. Steering head components
  - Improperly installed upper bracket
  - Improperly installed lower bracket (improperly tightened ring nut)
  - Bent steering stem
  - Damaged ball bearing or bearing race
3. Front fork leg(s)
  - Uneven oil levels (both front fork legs)
  - Unevenly tensioned fork spring (both front fork legs)
  - Broken fork spring
  - Bent or damaged inner tube
  - Bent or damaged outer tube
4. Swingarm
  - Worn bearing or bushing
  - Bent or damaged swingarm
5. Rear shock absorber assembly(-ies)
  - Faulty rear shock absorber spring
  - Leaking oil or gas
6. Tire(s)
  - Uneven tire pressures (front and rear)
  - Incorrect tire pressure
  - Uneven tire wear
7. Wheel(s)
  - Incorrect wheel balance
  - Broken or loose spoke
  - Damaged wheel bearing
  - Bent or loose wheel axle
  - Excessive wheel runout
8. Frame
  - Bent frame
  - Damaged steering head pipe
  - Improperly installed bearing race

EAS28710

## FAULTY LIGHTING OR SIGNALING SYSTEM

### Headlight does not come on

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging

- Incorrect connection
- Improperly grounded circuit
- Poor contacts (main or light switch)
- Burnt-out headlight bulb

### **Headlight bulb burnt out**

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded circuit
- Faulty main switch
- Faulty light switch
- Headlight bulb life expired

### **Tail/brake light does not come on**

- Wrong tail/brake light bulb
- Too many electrical accessories
- Incorrect connection
- Burnt-out tail/brake light bulb

### **Tail/brake light bulb burnt out**

- Wrong tail/brake light bulb
- Faulty battery
- Incorrectly adjusted rear brake light switch
- Tail/brake light bulb life expired

### **Turn signal does not come on**

- Faulty turn signal switch
- Faulty turn signal relay
- Burnt-out turn signal bulb
- Incorrect connection
- Damaged or faulty wire harness
- Improperly grounded circuit
- Faulty battery
- Blown, damaged or incorrect fuse

### **Turn signal blinks slowly**

- Faulty turn signal relay
- Faulty main switch
- Faulty turn signal switch
- Incorrect turn signal bulb

### **Turn signal remains lit**

- Faulty turn signal relay
- Burnt-out turn signal bulb

### **Turn signal blinks quickly**

- Incorrect turn signal bulb
- Faulty turn signal relay
- Burnt-out turn signal bulb

### **Horn does not sound**

- Improperly adjusted horn
- Damaged or faulty horn
- Faulty main switch
- Faulty horn switch
- Faulty battery
- Blown, damaged or incorrect fuse
- Faulty wire harness

**WIRING DIAGRAM****XT250X/XT250XC 2008**

- 1.Pickup coil
- 2.A.C. magneto
- 3.Rectifier/regulator
- 4.Fuse
- 5.Starter relay
- 6.Battery
- 7.Starter motor
- 8.Diode 1
- 9.Main switch
- 10.Right handlebar switch
- 11.Engine stop switch
- 12.Start switch
- 13.Diode 2
- 14.Clutch switch
- 15.Sidestand switch
- 16.Starting circuit cut-off relay
- 17.Diode 3
- 18.Neutral switch
- 19.C. D. I. unit
- 20.Ignition coil
- 21.Spark plug
- 22.Meter assembly
- 23.Neutral indicator light
- 24.Multi-function display
- 25.Speedometer
- 26.High beam indicator light
- 27.Turn signal indicator light
- 28.Speed sensor
- 29.Tail/brake light
- 30.Rear turn signal light (right)
- 31.Front turn signal light (right)
- 32.Front turn signal light (left)
- 33.Rear turn signal light (left)
- 34.Headlight
- 35.Rear brake light switch
- 36.Front brake light switch
- 37.Turn signal relay
- 38.Headlight relay
- 39.Horn
- 40.Left handlebar switch
- 41.Horn switch
- 42.Dimmer switch
- 43.Turn signal switch
- 44.Thermo switch
- 45.Carburetor warmer

**COLOR CODE**

B	Black
Br	Brown
Ch	Chocolate
Dg	Dark green
G	Green
Gy	Gray
L	Blue
O	Orange
P	Pink
R	Red
Sb	Sky blue
W	White
Y	Yellow
B/G	Black/Green
B/L	Black/Blue
B/R	Black/Red
B/W	Black/White
B/Y	Black/Yellow
Br/G	Brown/Green
Br/L	Brown/Blue
Br/R	Brown/Red
Br/W	Brown/White
G/B	Green/Black
G/R	Green/Red
G/W	Green/White
G/Y	Green/Yellow
Gy/G	Gray/Green
Gy/R	Gray/Red
L/B	Blue/Black
L/R	Blue/Red
L/W	Blue/White
L/Y	Blue/Yellow
O/B	Orange/Black
P/W	Pink/White
R/B	Red/Black
R/G	Red/Green
R/L	Red/Blue

R/W	Red/White
R/Y	Red/Yellow
Sb/W	Sky blue/White
W/B	White/Black
W/R	White/Red
W/Y	White/Yellow
Y/B	Yellow/Black
Y/G	Yellow/Green
Y/L	Yellow/Blue
Y/R	Yellow/Red






YAMAHA MOTOR CO., LTD.  
2500 SHINGAI IWATA SHIZUOKA JAPAN


PRINTED IN U.S.A.



2008 XT250X/XT250XC WIRING DIAGRAM



# 2008 XT250X/XT250XC WIRING DIAGRAM



MAIN HARNESS CARB WARMER (BLACK)	MAIN HARNESS CARB WARMER (BLACK)
MAIN HARNESS SPEED SENSOR (GRAY)	MAIN HARNESS SPEED SENSOR (GRAY)
MAIN HARNESS TAIL LIGHT (BLACK)	MAIN HARNESS TAIL LIGHT (BLACK)